

Paily routine tasks can turn us into creatures of habit. And you know that habits can be good or bad.

For equipment, there's always daily or BEFORE PMCS inspections that must be done.

There's a problem. Whenever a maintenance task or inspection becomes too familiar, we have a tendency to do the job from memory.


Daily maintenance and inspections must be done by the book, but because we do checks daily, we think we can toss the TM and rely on our memory instead.

Performing preventive maintenance by memory is nothing more than maintenance by the seat of your pants, or maintenance on-the-fly, which ends up hit or miss.

Even though you think you know how to do a task or an inspection, you can't afford to not use the TM for those crucial step-by-step instructions. Failing to read the manual puts you and your equipment in harm's way.

Don't get in the habit of doing maintenance or inspections without TMs, ETMs, or IETMs. Always remember that the when, what and how of inspections and maintenance procedures change, so it's in your best interest **not** to do inspections or maintenance by memory. Your memories may be wrong or out-of-date.

THINK ABOUT IT. WOULD YOU STAKE YOUR LIFE, RIGHT NOW, ON THE CONDITION OF YOUR EQUIPMENT, IF YOU KNEW ITS INSPECTION WAS DONE BY MEMORY?





TB 43-P5-688, The Preventive Maintenance Monthly, is an official publication of the Department of the Army, providing information for all soldiers assigned to combat and combat support units and all soldiers with unit maintenance and supply duties. All information published has been reviewed and approved by the agency responsible for the equipment, publication or policy discussed. Application of the information is optional with the user. Masculine pronouns may refer to both genders.

ISSUE	688	MARCH 2010	
COMBAT VEHICLES	2	AVIATION 35	5
DA Form 2408-4 Electronic Gun Card Usage Ground Power Unit M88A1 Bil Acetylene Regulator Valve M88A1 Recovery Vehicle Boom M2/M3-Series Bradley Ammo Box Covers WHEELED VEHICLES	2-5 6-7 7 8 9	AH-64D Wire Bundle Placement       33         CH-47D/F Winch Emergency Use       33         OH-58D Gear Storage       33         UH-60 Series Main Rotor Sliding Door       33         Air Warrior MCG Vest Coolant Check       33         UH-60, CH-47, AH-64 Washing       44         Army Aviation PM Website       4	6 7 8 9
M149A2, M1112 Water Trailer Brake Light Drains HMMWV Hub Magnetic Drain Plug	s 10	COMMUNICATIONS 42	2
HMMWV Geared Hub Cover Seal HEMTT Wrecker Crane Grounding M915-Series Tractor Truck Battery Spacer Plate FMTV Rear Brake Caging Bolt FMTV Air Tank Check Lunette Trailer Power Cable Care	11 12 13 14 15 16-17	AN/PED-1 LLDR Rangefinder Software Error AN/TAS-8(V)1 & (V)2 LRAS3 GPS Battery 15-, 30-, 60-kW TQG Excitation Circuit Fuse 5- to 200-kW TQG Neutral to Ground Bar Jumper 46-4 SINCGARS LS-671 Cables 42-4	4 5 7
MISSILES	18	COMBAT ENGINEERING 48	3
Patriot Missile System Cable Keyways AN/TPQ-36(V)8, -46A/B Radar Trailer Leg	18 19	AN/PSS-14 Mine Detector Maintenance 48-51	1
CBRN	20	AN/PSS-14 Mine Detector Control Grip Cable 50-51	1
ICAM Operating Tips JBPDS BIDS Training Test Cards	20-21 20-21	LOGISTICS MANAGEMENT 52	2
SMALL ARMS	22	OCIE from Unauthorized Sources 52-5: OCIE Receipt Reminder 54-5:	5
CROWS II M240B MG Charging Handle Adapter Munitions Items Disposition Action System M2 Machine Gun Backplate Plug Position Machine Gun Hand Position When Charging ANPAS-13 Weapon Sight Batteries M4/M4A1 Carbine Pistol Grip MK 19 Machine Gun Grip Cap Screw NSN M240 Machine Gun Spring Pin Fix	22-23 23 24 24 25 25 26 26	ACH Chin Strap NSN 5: BII/COEI for Left Behind Equipment 5: Property Accountability Courses Available Online Blue Force Tracking System Accountability 5:	7 8

You are invited to send PS your ideas for improving maintenance procedures, questions on maintenance and supply problems and questions or comments on material published in PS.

Just write to:

MSG Half-Mast

PS, the Preventive Maintenance Monthly USAMC LOGSA (AMXLS-AM)

5307 Sparkman Circle Redstone Arsenal, AL 35898

Or email to:

logsa.psmag@conus.army.mil or

half.mast@us.army.mil Internet address:

Redstone Arsenal, AL 35898-5000.

https://www.logsa.army.mil/psmag/pshome.cfm

By order of the Secretary of the Army:

GEORGE W. CASEY, JR. General, United States Army Chief of Staff

Official:

Jorge E. Morins
JOYCE E. MORROW

Administrative Assistant to the Secretary of the Army

0935104

PS, The Preventive Maintenance Monthly (ISSN 0475-2953) is published monthly by the Department of the Army, Redstone Arsenal, AL 35898-5000. Periodical postage is paid at the Huntsville, AL post office and at additional mailing offices.

Postmaster: Send address changes to PS, The Preventive Maintenance Monthly, USAMC LOGSA (AMXLS-AM), 5307 Sparkman Circle,

## Electronic Gun Card Saves Time, Improves Accuracy





You've just returned from the firing range and boy, are you tired! Before you head off for some well-deserved R&R, make sure you take the time to update your DA Form 2408-4, Weapon Record Data Card.

The only way to determine gun tube life is to keep track of the number and types of rounds fired from your mortars, artillery and armor. If the data's not up-to-date, your gun tube could be condemned too soon. Even worse, it might not be condemned soon enough!

Before you reach for that stubby pencil, remember this: The DA Form 2408-4 is now electronic and available on the Army Electronic Product Support (AEPS) website. Only deployed units that have no Internet access are allowed to mail in their gun cards.

Active duty units with no access should mail in their cards each April and October. Reserve and National Guard units with no access should mail theirs in October. Send

them to: US Army TACOM
AMSTA-LC-LETT (AEPS Help Desk)
1 Rock Island Arsenal
Rock Island, IL 61299-7630

**Electronic Access** FOR ELECTRONIC GUN CARD ACCESS, GO TO THE AEPS WEBSITE: http://aeps.ria.armu.mil/aepspublic.cfm LOG IN WITH YOUR AKO USER NAME AND PASSWORD OR WITH YOUR COMMON ACCESS CARD (CAC). IF YOU DON'T HAVE EITHER, CLICK ON ACCESS REQUEST FORM AND FOLLOW THE DIRECTIONS Popular **Applications** AEPS Utilities VA MNAEPS VA AMC Field Support Cente Defense Log Service - Cat Tracking (CV) AMC NSN Search (myNSN tello David Cotton, Did you know that you can FEDLOG Army Acquisition Objective (AAO) reate your own AEPS Click here to find out ederal Log more about creating your own MyAEPS ield Suppo lomepage Click on Gun Card IPADS Softw for Demil Code Quer dividual Cl Firing Data ot Stock Distribution teorated L Other Web Portals: opistics Info Logistics Mo SELECT THE GUN CARD FIRING DATA BUTTON AMC Gun Card Home Page UNDER POPULAR APPLICATIONS, THEN CLICK ON VIEW/PRINT IN THE LEFT-HAND COLUMN. LOW THE INSTRUCTIONS FOR ACCESSING THE CARD FOR YOUR GUN TUBE. HOME COMMODITY SERVICES View/Print Gun Cards Click on List all Gun Cards by Commodity & Cannon Type. View/Print Commodity - Select A Commodity -Cannon Type - Select A Cannon -- > View / Print Or, Search by Tube S/N End Item S/N Get List | Active Cards | Closed Cards Pull Over Gauge ...then follow instructions (PS) MORE

PS 688 2 MAR 10

#### Store, Transfer, or Turn-in?

If you're getting ready to store, transfer or turn in a mortar, tank or other gun system vehicle, you've got a two-step process to follow.

**Step 1:** Make sure you notify Team Armor whenever you transfer, turn in, store or send your equipment for rebuild or overhaul. That allows them to update the Unit Identifier Code (UIC). Artillery units should notify their artillery POCs.

The UIC **must** be updated whenever there's a change in the personnel responsible for the equipment and its gun card. Without the update, new users will have problems accessing the equipment's electronic gun card.

**Step 2:** Make sure you include an updated hard copy of the gun card along with the mortar, tank or gun system. That's the word in DA Pam 750-8, *The Army Maintenance Management System (TAMMS) Users Manual.* 

5. End Item Identification SN: (Tank, Combat, FT: M1A1/M1A2)				B. RDS/EFC COMPUTATION			Condemn the cannon tube when 1500 EFC rounds have been fired. Comdemn the cannon when it reaches 4500		
7. Cannon Serial 8. Retubings 9. Rebushings 6589 2				ZONE EFC FACTORS					
Cumulativ	re EFC RDS fi	red for Canno	n: 534.00	0				EFC rounds.	
Tubes:	Status	Tube Serial	EFC Round	İs					
	Active	10000	123.000						
	Previous	5719	<u>5719</u> 369.000						
	Rebreeched	8826	42.000						
10. Date	Projectile Type	Zone or Charge	Rounds	EFC RDS Fired	Cumulative RDS fired	Life	Remarks: Recoil Ex Gage or V Reading, Inspection	Safety	Signature
01-01-200	5 (Previous 4 final en EFC)			.000	103	1,397.000			Doe, Johnny
09-16-200	5	MACO	368	0			BORESCO	OPE.	Doe, Johnny
11-04-200	5 TP-T	M83		0	106	1,394.000			Doe, Johnny
02-09-200		1				1,393.000			Doe, Johnny
02-09-200	ACCURATE STREET	UG. MAST	110	SARI	AYI	391.000			Doe, Johnny
02-20-2	915	1				890.000			Doe, Johnny
02-20-	N:	32			8	77.000			Doe, Johnny
10-23	ONCE Y MADE SL DATA C	IRE THE	AN	ND PL	ACE IT IN		count esti Willie Wro	MARKS: Round mated by ong matches ount fired.	False, Freddie
	ELECTRO ARD IS A	NIC GUN	III RE	CORD	FOLDER ANSFERS		9-1000-20	OPE. IAW TM 02-14	Wrong, Willie
		PLETE			VEHICLE		RECOIL E	XERCISE, IAW	Wrong, Willie
c	ᄭᅜᄼᄼᄼ	PLETE	JI WIT	H THE	= VEHICLE	.)			

#### **M1-Series Tanks**

Sure, you're supposed to update the electronic gun card after firing the main gun. But did you know you're also supposed to update the card after exercising the recoil?

If the main gun hasn't been fired in the last six months, it is a semiannual requirement to exercise the recoil and borescope the main gun. This can be done using the M3 oil pump, the gun mount exerciser or by firing the gun. Whichever method you use, update the gun card when you're finished.

An incomplete or inaccurate gun card now makes your tank NMC. You'll find this listed in PMCS Item 10 on WP 0258-21 of TM 9-2350-388-23-2-2 (Jan 09) and PMCS Item 12 on Page 2-20 of TM 9-2350-264-20-2-1 (Apr 03 w/Ch 3, Mar 08). Future updates to TMs 9-2350-264-10-1 and 9-2350-388-10-3 will also make the tanks NMC if the gun card is incomplete or inaccurate.

### M1128 & M1129A1 Stryker

Future updates to IETM 9-2355-321-13&P for the M1128 MGS Stryker and IETM 9-2355-311-13&P for the M1129A1 MCV-B Stryker will make both vehicles non-mission capable if the DA Form 2408-4 is incomplete or inaccurate.



## Questions?

If you have questions, here's who to contact:

#### Artillery:

Martin Nelson (M198, M777) DSN 793-7852 or (309) 782-7852 marty.nelson@us.army.mil

Barbara Vanopdorp (M119, M102) DSN 793-4079 or (309) 782-4079

barbara.vanopdorp@us.army.mil

Gary Rogers (M109) DSN 793-0030 or (309) 782-0030 gary.s.rogers@us.army.mil

#### Armor:

Gordon Bieri DSN 793-2189 or (309) 782-2189 **gordon.bieri@us.army.mil** 

#### Mortars:

Joe Schmidt DSN 786-87863 or (586) 574-8783 joe.schmidt@us.army.mil

### Stryker:

Thomas Durbin DSN 793-1172 or (309) 782-1172 thomas.m.durbin@us.army.mil





#### Dear Editor,

I'm an instructor at Aberdeen Proving Grounds, MD, for our Track Division. I instruct professional development automotive courses for NCOs and warrant officers.

We can't operate all of our equipment on a regular basis, so it has been very challenging to keep the batteries properly charged. Uncharged batteries keep our students from doing hands-on troubleshooting and training whenever necessary.

We overcame this problem by using the ground power unit (GPU) you listed on Page 8 of PS 622 (Sep 04). The GPU keeps the batteries on our tracked vehicles fully charged all the time. We've used the GPUs for the last two years with no lost training time.

We train well over 1,000 warrants and NCOs every year, but I am still amazed at how many of our students are unaware of the availability and capability of these units in the field.

Since it's been a few years, could you let Soldiers know about the benefits of these GPUs?

CW4 Roger Guillemette
Aberdeen Proven Grounds, MD

Editor's note: You bet, Sir! The most common GPU used for combat vehicles is the TIMV3000, NSN 6130-01-475-5321.

This GPU is a Class II item, weighs only 125 pounds and has wheels, so it's easy to move between vehicles.

You can recharge the GPU in about 75 minutes from a 110/220-volt or 240-volt outlet. In the field, you can pull a 24-volt back-charge from your vehicle through the NATO slave cable.

With the GPU, a maintenance team in a small vehicle can make repairs to a disabled vehicle, re-start it and send it back into action without needing another vehicle to provide slave power. The GPU also gives units the ability to operate under "silent watch" for short periods of time.

Based on feedback from Soldiers, the GPU now includes the following improvements:

- Hardwired AC line cord
- Run-flat tires
- Resettable circuit breaker
- Axle extensions
- Telescopic handle
- $\bullet \, Rugged \, shipping \, case$

The GPU works great with all combat, tactical and construction vehicles—anything that uses a 24-volt system. Check out the manufacturer's website:

### http://www.teslaind.com/

There you'll find more information about this and other GPUs, including the TIMV1000, NSN 6130-01-457-5313, the TIMV3000's "little brother."

### **M88A1 BII Regulator Valve**

Use NSN 4820-00-551-1094 to get the regulating flow valve for the acetylene bottle shown in the M88A1 recovery vehicle's basic issue items (BII). This NSN replaces the one shown as Item 39 on Page B-11 of TM 9-2350-256-10.

PS 688 6 MAR 10



boom in the stowed (travel lock) position when it's not in use.

If the boom has been in the full-raised position for an extended period of time, follow the instructions on Page 2-142 of TM 9-2350-256-10 to lower it.

M88A1

SHOULD SALUTE ALL

THE TIME.

**PS 688** 

## BURP THE AMMO BOXES?






Plastic food containers have one big advantage over your Bradley's AP and HE ammo ready boxes: You can burp their covers to make sure they're on tight.


Not so with the ammo boxes. It's up to you to visually make sure they're on good and tight.


If the lids aren't on just right, they'll come loose when the turret is traversed. Not only will the covers be crushed, but they can snag and rip loose cables and connectors.

It's an easy mistake to make, especially when you're in a hurry. So always make sure the rounded edges of the cover fit over the outside edges on both sides of the box before you close and latch it. That keeps the cover from popping open during operation.









#### Dear Editor,

Sitting in the motor pool, our M149A2 and M1112 water trailers are constantly exposed to the elements. Even though they're sealed, water can seep into the brake light housings when it rains.

The seals are still good enough to hold in that water, so when it gets deep enough, the system



We've prevented this problem by drilling a small '/e-in hole through the underside of the housing. The hole drains away any water from rain or condensation before the lights can short out.



SFC Eric Mathis
19th Maint
Ft Sill, OK

Editor's note: An excellent suggestion, Sergeant. Just be careful not to hit any of the wiring while drilling.

HMMWV...

HERE ARE SOME SOLUTIONS FOR YOUR HMMWV'S GEARED HUB LEAKS!




## Don't Flub Hub Plug Torque

Take it easy on the magnetic drain plug, NSN 4730-00-045-9769, on your HMMWV's geared hub when you remove or install it.

The plug already sees a lot of action. The hubs have to be drained at every semiannual service, before any repair work is done to the geared hub, and after any operation where water contaminates the gear oil.

It takes only a little torque —8-13 lb-ft—to keep the plug in place. That's like finger-tight plus a little twist of the wrench. Too tight and you'll strip the threads.

Use a <sup>3</sup>/s-in hex socket drive to remove the plug. You'll round off the plug head if you use anything else. That makes removal a whole lot harder next time.




## Keep Oil Where It Belongs

f you don't apply the HMMWV's geared hub cover seal the right way, two things will happen, mechanics. The hub oil won't stay in,

and water won't stay out! Some folks like the RTV

Some folks like the RTV method shown in Para 6-10 of TM 9-2320-280-20-2, but you've got to work fast. The RTV, NSN 8030-01-025-1692, will start to cure as soon as it's applied.

To make it work you've got to put the cover on quickly. Then put RTV on the capscrews and quickly torque them to 15 lb-ft.



HEMTT...

# KEEP WRECKER CRANE WORKING WITH WASHER





Your TM gives you what you need to maintain your equipment—usually. But there was a mistake when the base HEMTT IETM, TM 9-2320-279-14&P (EM 0290), was released in June 2009. The washer, NSN 5310-00-935-8984, is shown in the wrong place for axle number 4. That washer is shown as Item 26 in Fig 158 of the repair parts and special tools list (RPSTL).


If the star washer is missing from the ground wire, or is on the wrong side of the ground wire, the crane on your HEMTT wrecker could quit operating. But you can

put a stop to that.


Just put the washer in the right place the next time the wrecker comes in for service. Note and follow these steps until the figure in the IETM is corrected:

- **1.** Take off the nut, ground wire—and the misplaced star washer, if that applies.
- **2.** Scrape off the paint, about the size of a quarter, from around the bolt hole.
- **3.** Put on the star washer, then the ground wire and nut.
- **4.** Torque the nut to about 110 lb-ft.

Washer, NSN 5310-00-935-8984, goes between ground wire and frame, like so:



## BATTERY SPACER PLATES FATE



Dear Half-Mast,

While servicing M920 tractor trucks, I've noticed a recurring problem. The wooden spacer plate, NSN 5365-01-079-6540, that goes under the batteries often rots and needs replacing. That part costs almost \$50.

It sure would be nice to have this plate last longer in bad weather and battery leakage. Do you have a tip that can help us?

SGT B.L.R.

Dear Sergeant B.L.R.,

Certainly. You still have to use the spacer plate, but here's a tip that should help you out. Use battery box liner, NSN 6160-01-389-1966.

The battery box liner should absorb and neutralize battery acid and prevent corrosion to the box. You'll have to cut enough liner to cover the entire bottom of your truck's battery box.

Then replace it whenever you need to.


Half-Mast









The problem occurs while using the 5 <sup>1</sup>/<sub>4</sub>-in caging bolts, NSN 5306-01-500-8736, PN A-4X-1883, on the rear brake chambers. The rear shock absorbers are in the way of putting the bolts in the end of the chambers.



When you encounter this problem, just use the four shorter (3-in) caging bolts, NSN 5306-01-479-1492, PN 12422439. They are stored on the rear axle castings. These bolts were designed to fix this problem, so use them only for caging the rear brake chambers if the longer bolts don't fit. And store the longer caging bolts you won't be using on the holding fixture found on the side of the brake chamber housings.







When was the last time you took a really good look at your FMTV's air tanks? If you've got any -A1 model FMTV trucks with serial numbers 104,314 through 117,858 or M1082 and M1095 FMTV trailers with serial numbers 202,197 through 206,367, eyeball those air tanks right away! The air tanks made by RDS Manufacturing could be bad.

TACOM SOUM 09-032 tells you all about the trouble with your FMTV's RDS air tanks. That safety message was released in September 09, but there are still FMTVs with bad air tanks out there. All units that have FMTVs with the serial numbers above must report to TACOM's John Clary, DSN 786-6965, (586) 282-6965 or email:

john.d.clary@conus.army.mil

Your FMTV truck or trailer is NMC until a mechanic replaces the bad tank. Bad air tanks can rupture, causing the air brake system to fail.

By the way, there was a similar issue with the Caiman MRAPs. We told you about that on page 47 of PS 679 (Jun 09). Or you might have learned about it from TACOM SOUM 09-003.

Check to see if your FMTV's primary, secondary, wet, and trailer air tanks have "RDS MFG" on them. You may need to remove the paint with a wire brush to get to it. If you see "RDS MFG", get the needed replacement parts at no cost to your unit. Contact John Clary to order those parts.

Make sure you follow the instructions in TACOM SOUM 09-032. You can view it online:



https://aeps2.ria.army.mil/commodity/soum/tacom\_wn/soum09-032.html For more info, contact John Clary.




IF YOU DON'T DO YOUR JOB DURING HOOKUP AND MAINTENANCE, YOUR LUNETTE TRAILER'S INTERVEHICULAR CABLES WON'T DO THEIRS,


> THAT MEANS PROBLEMS WITH THE TRAILER'S LIGHTS.



#### **Before Connecting**

Before installing cables, take a close look at the connectors and receptacles for dirt and corrosion. Loose dirt can usually be blown out with the help of an air hose.






Stubborn dirt can be a little tougher. Try clipping off all but about <sup>1</sup>/<sub>2</sub> inch of the bristles on an acid swabbing brush, NSN 7920-00-514-2417. The shorter bristles make them stiff enough to brush dirt out of the connector and around the outside of the receptacle.



To remove corrosion, try spraying a light coat of corrosion preventive compound, NSN 8030-00-546-8637, and scrubbing with that short-bristled acid swabbing brush. The compound also displaces water, which should help prevent further corrosion down the road.

## No Drag, Cable's Glad

Be sure to hook up the cable so it doesn't drag. Dragging the cable as your truck pulls the trailer wears out the cable and can set it on fire.



When connecting cables, make sure the pins line up with the receptacle. Bent or broken pins are a sure cable killer.

The cable hooks up the brake lights and signal lights, so it's an honest mistake to stop connecting when you see the lights come on. But when you see the lights, keep pushing to ensure a good hook-up. That should prevent a dragging cable.

Remember, when the cable or connector goes bad, you have to replace the whole cable assembly.

16 MAR 10 PS 688 17 MAR 10



#### Dear Editor,

Many of the cables for the Patriot Missile System have keyways in their connectors to ensure the pins go in the right holes. You must line up the cable connector keyway to the keyway of the connector you're plugging it into to get a correct connection.


Unfortunately, it can be very difficult to see the keyways, especially if you're plugging the cables in at night. And that's even with a flashlight.

As a result, Soldiers often stick the cable connector on and twist it back and forth trying to line up the keyways. That damages lots and lots of pins every year. Too many times the whole cable must be replaced, which is expensive.

An easy way to help Soldiers find the keyways and prevent pin damage is to mark the keyways on the outside of both connectors with a thin line of bright paint. Yellow would be best. Then all Soldiers need to do is match the two lines to line up the keyways.

The paint will wear off over time so periodically units will need to repaint the lines. But the savings in cables and money are worth the effort.

SSG Benito Rosas SPC Matthew Reimer C Btry, 3-6 ADA Ft Bliss, TX



Editor's note: We can line up behind that excellent suggestion.

## Setting Trailer's Rear Leg


11-5840-380-10 doesn't give much info on setting the rear stabilizer jack leg for the trailers used with the AN/TPQ-36(V)8 and AN/TPQ-46A/B radars.


That's not good since the trailer is heavier to the rear because it doesn't have much tongue weight. That means if the jack leg isn't set properly the trailer's tongue can fly up when it's disconnected from the HMMWV or when weight is added to the rear of the trailer.


Warning: Never disconnect the trailer from the HMMWV before setting both the right and left trailer brakes and lowering the front and rear stabilizer legs. Only then is it OK to disconnect the trailer.

- **1.** Park the trailer on as level a surface as possible.
- **2.** Set the two handbrake levers to prevent any movement.

**3.** Pull out the pin that secures the rear stabilizer jack in the travel position







HOW TO

JACK LEG

SO THAT

DOESN'T

- **6.** Disconnect the trailer from the HMMWV by lowering the front landing leg and raising the tongue using the hand crank on the front landing leg. Move the HMMWV. **7.** Level the trailer using the crank on the
- **7.** Level the trailer using the crank on the front leg.
- **8.** On the rear jack, turn the leg base until it makes firm contact with the ground.
- **9.** If the jack model in use has the lock washer and nut on the leg base, they must be tightened firmly against the tube end.
- **10.** This information will be added to Para 2.7 in TM 11-5840-380-10.

## MONITOR THESE ICAM TIPS!



Dear Editor,

We are instructors at the U.S. Army CBRN School at Ft Leonard Wood. These are a few of the tips we give our students on how to get the most out of their ICAMs (improved chemical agent monitors).

 Remember that the ICAM is just the opposite of the ACADA when it comes to testing. For the ICAM, test first in the H mode, then in G.



- Use a nozzle filter to prevent contamination.
- The ideal distance from what you're checking is 1/2 inch from the ICAM's nozzle. If you're checking a person, move the ICAM horizontally and slowly. When you get to the person's torso, move the ICAM in a zigzag motion to slowly work completely down his body. It's best to monitor with two Soldiers—one checks the front of the person, the other the back. Don't forget to check the boot soles. The person could have stepped in agent.





- Use the ICAM's strap while you're monitoring. It gives your arm support and helps keep your hand steady.
- Don't kneel while monitoring. You could accidentally contaminate yourself.
- Remember to reinstall the nozzle protective cap when you're not using the ICAM. When you're operating, put the cap on the environmental cap at the rear of the ICAM so it won't get lost.
- Let the ICAM clear down before you shut it off. That will save time next time you operate.

SSG Luis Sanchez SSG Harold Cooper US Army CBRN School Ft Leonard Wood, MO

Editor's note: These are can-do ideas for your ICAM. Thanks for the help.


JBPDS BIDS... THE TRAINING CARRIER BOX 01-541-8943 JBPDS BIDS\* OF ORDER IN SOME CASES.


\*JOINT BIOLOGICAL POINT PETECTION SYSTEM BIOLOGICAL INTEGRATEP PETECTION SYSTEM

The training box has five carrier cards that yield a positive identification and 10 that produce a negative identification.

The positive cards should be in the 3, 6, 9, 12 and 15 positions in the box. But, due to a packaging error, some of the boxes have the positive cards in the 1, 4, 8, 11 and 13 positions, which could lead to unexpected readings.

Positive and negative cards can be moved around in the deck to support the training mission. Before you train, check that the positive cards are where you want them to support your training. The positive cards are labeled POSITIVE on their left side.





**S**ome of the M240B machine gun used on CROWS II (common remotely operated weapons station) have a new charging handle. But to use the new charging handle with CROWS II requires an adapter.

Weapons configured with the older charging handle don't need the new adapter and can be used with CROWS II without the adapter. Look at the picture on the next page to see which charging handle your M240B uses.

The adapter has been free-issued already to most affected units. The adapter (PN 13021845 and CAGE 19200) comes with NSN 5340-01-578-0847. If your unit hasn't received it, contact the CROWS II item manager, Charlie McIntyre, at DSN 793-7389, (309) 782-7389, or email **charlie.mcintyre@us.army.mil** 

To install the adapter, you need a 3mm hex-head wrench and a 7mm nut driver. The hex-head wrench is part of the CROWS II operator's tool kit.

The nut driver is being added to the tool kit. You can get a nut driver and the two attaching screws and lock nuts from your local CROWS II new equipment training team (NETT) representative, the local CROWS II support group (CROWS Nest), or from your TACOM-RI LAR.




- Nut driver, NSN 5120-01-278-6697
- 2 hex-head socket screws, NSN 5305-01-577-9519
- 2 self-locking nuts, NSN 5310-01-577-9651

Some of the first adapters sent to the field had the wrong SAE 8-32 attaching screws. Replace them with the metric hardware listed with the nut driver.



Push the adapter (2) onto the charging handle (1) until the surfaces (3) are in contact.

Use the hex-head wrench and nut driver to tighten the socket screw and lock nuts (4).





Ammo...

## Demil Questions? Ask MIDAS

If you're not sure what to do with unwanted munitions, you need to consult MIDAS. The Munitions Items Disposition Action System (MIDAS) was created by the US Army Defense Ammunition Center to provide a database of demilitarization and disposition information for unwanted munition items.

MIDAS offers these features:

**Databases**—Databases of munitions and their components that aid searches for munition materials, parts, and components to end items

Munition images - Diagram views of some munitions

Existing capabilities—Databases of which installations can do recovery and recycling of munitions

**Firing point/impact point**—Identification of materials that remain at the firing point or are released at impact. This information is essential for environmental range assessments.

To access MIDAS online you will need to register for a user ID and password. The MIDAS website URL is: https://midas.dac.army.mil

If you have questions about MIDAS, contact DSN 956-8084, (918) 420-8084, or email mcal.sjmac-td@conus.army.mil

22

MAR 10

## THREADED PLUG IN WRONG POSITION

Dear Editor,

While reading your article on M2 machine gun PM in PS 682 (Sep 09), I noticed on top of Page 31 the backplate threaded plug was shown in the wrong position.

The line on the plug is at the 1 and 7 o'clock positions, which means the plug is not locked into the backplate. In that position, the backplate could

come off during firing.

To lock the plug in, it should be tightened and then backed off until the headless shoulder pin is aligned in the notch. If the plug is locked in correctly, its line will be at the 3 and 9 o'clock positions. WP 0024 00-4 in TM 9-1005-213-23&P explains how to do this.

Curtis Bradley TACOM LAR Iraq r it should be acked off until r pin is aligned olug is locked will be at the itions. WP 9-1005-213- to do this.

Plug line should be at 3 and 9 o'clock positions

Editor's note: Excellent catch, Curtis. Several readers also wrote to point out that the M2 was not used in WWI. The M2 first entered the Army in the early 1930s. So it's been doing duty for close to 80 years. And another reader pointed out the picture on Page 31 of the two Soldiers carrying the M2 should have the Soldier's hands on the right completely under the receiver, not partly under the backplate. Thanks, readers, for paying attention. We'll pay more attention, too.

Machine Guns...

## PALM UP FOR CHARGING

Dear Editor,

In your article on the M2 machine gun in PS 682 (Sep 09) you show MSG Half-Mast charging the weapon with his palm down.

That is something every machine gunner should **not** do. When you charge the weapon with your palm down, your thumb is right next to the charging handle slot. If there is a malfunction and brass shoots out that slot, your thumb takes a direct hit. That could cripple you for life.

With your palm up, though, your hand is much better protected from flying brass. You should *always* charge all the machine guns-not just the M2-with your palm up.

Cameron Clark Rock Island, IL Editor's note: Good point, Cameron. This is something that should be stressed during training for all the machine guns. It might save a Soldier from serious injury.



Some units are trying to save money with their AN/PAS-13C and -13D thermal weapon sights by substituting standard alkaline batteries for L91 lithium AA batteries. Bad idea!

The L91 batteries have a life 3 to 10 times longer than alkaline batteries, which means fewer battery changes during operations and less weight to lug around in your pack.

Order L91s with NSN 6135-01-333-6101.




## Grip Cap Screw NSN?

Dear Half-Mast,

When I try to order the cap screws for the MK 19 machine gun's control grip assembly (Item 10 in Fig 8 of TM 9-1010-230-23&P), the NSN doesn't show up on FED LOG. What is the correct NSN?

CW2 R. N.







M240 Machine Gun...

## SPRING PIN TOO BIG? DO MIS

When you order the spring pin that holds the M240 machine gun's firing pin in the operating rod, you may get one that's too big to fit. (The pin, NSN 5315-01-033-8873, is Item 4 in WP 0037-001 in TM 9-1005-313-23&P.)

If that happens, substitute the spring pin, NSN 5315-01-033-3889, that's Item 5 in WP 0044 00-3. Cut the pin in half so that you have two pins 16mm (0.63 inch) long. File a chamfer around the end of the pin. You now can install the spring pin in the op rod.





Questions? Contact TACOM-RI's Dennis Bowrey at DSN 793-5943, (309) 782-5943, or email: **dennis.bowrey@us.army.mil** 







































































## MISHANDLING WIRE BUNDLES




Mechanics, the wire bundle that controls your AH-64D fire detection system and the helicopter air data system (HADS) doesn't belong in the storage clips for the power available spindle and the load demand spindle.

The clips are located above the engine particle separator blower on either side.

The next time you're working on the engine, follow the installation procedures in the TM. If there's slack within the wire bundle leading to connector (P1105) of engine 1 or connector (P1104) for engine 2, adjust the slack throughout the bundle and you're good to go. It's that simple.

Some mechanics think any slack in the bundle should be placed in the steel clips for safety. Not so!

Don't place the bundle in the sharp storage clips because they can cut the wiring and short out electronics and components like the HADS and the fire detection system.



PS 688




echanics, manual operation of your Chinook's winch using the winch control shutoff valve and the winch control valve in the heater closet is for emergency use only. Always pay attention when using these emergency controls. If you don't, you'll be doing major sheet metal damage repair.


After emergency operations, make sure the winch plunger on the winch control shutoff valve is returned to the centered detent position to disengage the winch. Always follow the winch emergency operator instructions stenciled on the panel above the control valve to avoid damage.

If you forget and leave the plunger pushed in and the winch control valve knob positioned either counterclockwise or clockwise, your bird will suffer damage. That's because the winch up/down limit switches are bypassed when using these emergency controls. The next time aircraft hydraulic power is applied to the bird, the winch will automatically engage.

For example, if the hook is on the winch cable and the knob is turned counterclockwise, the hydraulic power will pull the hook into and through the companionway floor like scissors cutting paper! If the hook is not installed, the cable is sucked into the winch drum and lost.

When using winch emergency controls, eyeball all the instructions on the panel and in TM 1-1520-240-240-10.










Careless tossing of equipment into the bay can also damage other components like COMSEC gear, SINCGARS radios, UHF and VHF antenna communication boxes and their cables.

Never use the avionics compartment area as a storage bin. When the mission is complete or the maintenance task is done, return all equipment, tools, TMs, and gear back in to where you signed them out.







WHEN IT COMES TO SHUTTING THE BLACK HAWK'S MAIN ROTOR SLIPING POOR, WHAM, BAM, SLAM IS WEITHER A GOOP PRACTICE NOR A GOOP SOUND, MECHANICS.

Go easy when closing the door. Slamming it shut like you're throwing a haymaker in a barroom brawl damages the main transmission fairing support holes.

Slamming the door against the support holes puts unnecessary stress on the holes. Consistently slamming the door elongates the holes and eventually causes cracks that'll need repair.

Then aircraft vibration from flying your bird does even more hole damage. Over time, the sliding door won't lock and you'll be calling the airframe shop for repair.

So avoid hole damage and be gentle with the door.



## ors gaine (2017 in libra)



If the heat's making you take off all your clothes, it might be that your microclimate cooling garment (MCG) or your microclimate cooling unit (MCU) doesn't have enough coolant.

When you sign out an MCG from the ALSE office, make sure both it and the MCU have been properly serviced with coolant. Check out EM 0250 and the -23 manuals for procedures on mixing and servicing the coolant.

If you hook an empty garment into your aircraft's cooling unit, the garment can pull all the fluid from the MCU. The opposite will happen if you have an MCG that is full and an empty MCU.


The coolant in the vest goes through the MCU to be cooled and if the garment is dry, it will put air in the system and will not cool as well.

If you do this a few times without servicing the MCU or the MCG, you'll eventually have a dry system. If that happens, the unit's pump may burn out. Then you'll **really** be hot under the collar.

Staying cool means making sure the MCG is serviced before you leave the ALSE shop. Don't forget that the coolant must be purged every 60 days and before you put the MCG and the MCU away for winter storage. Make sure vest has enough coolant before leaving ALSE shop



PS 688 39 D MAR 10





Mechanics, whenever you wash clothing, the rinse cycle is needed to get all the soap out. Guess what? The same goes for your aircraft.

For instance, when it's time to wash your bird's engines, the wash mix solution is tough on paint finishes.

After the wash solution is run through sections of the engines and the engines are rinsed, much of the engine wash solution runs down the side of your helicopter.

If you don't rinse the cleaning solution and soap residue off the airframe, the chemical residue dries on the airframe and gets baked on by the sun.







THERE IS A

ONE STOP SHOP—

JOINT TECHNICAL DATA

INTEGRATION (JTDI)—

AVAILABLE FOR THE

AVIATION COMMUNITY.

THOSE WHO HAVE
VALID AKO/CAC/PKI
CAPABILITIES CAN
REGISTER FOR ACCESS
TO THEIR PARTICULAR
AIRCRAFT:

http://www.jtdi.mil

On the site, you'll find PM contact information, technical publications info, newsletters, Air Worthiness Releases (AWR), AMCOM Aviation Safety Messages, Aviation Maintenance Actions Messages (AMAM), Aviation Safety Action Messages (ASAM), Maintenance Information Messages (MIM), Safety of Flight (SOF) Messages, and training information.


PM JTDI maintains the websites for various Army aviation PMs such as Aeromechanics, AH-64, Black Hawk, Chinook and Kiowa Warrior. Each website is managed separately by each PM. That means you do not have cross access to platforms other than your own airframe.

If you are a user of JTDI, check out the new and improved help desk:

https://www.jtdisos.us

Or you can call 1-888-JTDI-SOS (1-888-583-4767) for help.











SOME AN/PED-1 LIGHTWEIGHT LASER DESIGNATOR RANGE FINDERS (LLDR), NSN 1240-01-455-1791, HAVE A SERIOUS SAFETY HAZARD DUE TO A SOFTWARE ERROR.

THAT'S THE WORD IN CECOM LCMC SAFETY OF USE MESSAGE (SOUM) 2009-001 THAT CAME OUT IN SEPTEMBER OF LAST YEAR.

THE SOFTWARE ERROR AFFECTS LLDR'S TARGET LOCATOR MODULES (TLM), NSN 1240-01-510-1022, ON LLDRS WITH A SERIAL NUMBER BETWEEN 1301 AND 1900.



THE ERROR MAKES THE GPS CIRCUIT CARD IN THE TLM UNABLE TO UPDATE THE MAGNETIC VARIANCE (MAGVAR) ANGLE.



THIS COULD RESULT IN A GROSS ERROR IN TARGET LOCATIONS CALCULATED BY THE TLM.



HOPEFULLY, BY NOW, ALL LLDRS HAVE BEEN FIXED AND THE PROBLEM IS NO LONGER A PROBLEM.

BUT, JUST IN CASE A FEW WERE MISSED HERE'S HOW YOU CAN MAKE SURE YOUR LLDR IS CLEAN AND GREEN.



Start by checking the LLDR serial number to see if it is between 1301 and 1900. If it's not, stop. You're good to go.

If it is, bring up the system information screen. The top line will say APP PART NO. and then give a string of numbers. If no string of numbers is shown after APP PART NO., or if the last three digits are 011, you're good to go.


If the last three digits of that string are 008, 009 or 010, then the TLM has software that needs to be updated.

This update must be done by the manufacturer. If possible, contact your local CECOM or TACOM LAR to get the information you need to turn in your LLDR for updating. They will also have a copy of the SOUM.

If you cannot contact a LAR, call or email: Paul Woodman, DSN 654-3481, (703) 704-3481, paul.woodman@us.army.mil, or Mauricio Martinez, DSN 654-3320, (703) 704-3320, mauricio.d.martinez@us.army.mil

If you must use the LLDR before you get the updated software, there is a work-around that can temporarily solve the problem. You'll need the operator's manual for the LLDR, TM 11-5855-315-12&P. Make sure you have the latest version of the manual dated 15 May 08.


Manually input the local MAGVAR by following the instructions on Page 2-35 of the TM. Check that the MAGVAR was correctly entered by powering the TLM down, then up and following the instructions again from the TM. Remember to verify the MAGVAR is the most current for your area before providing coordinates that will require a call for fire based solely on the LLDR coordinates.



PS 688

DID IT

SAYZ



#### Dear Editor,


I am an ILS manager for the long range scout surveillance system (LRAS3) AN/TAS-8(V)1 & (V)2. I need to get the word out to units using LRAS3 systems that there is one, *and only one*, battery to use to maintain the GPS crypto data when the system is off. That battery is the non-rechargeable, BA-5372/U, NSN 6135-01-214-6441.

Some of you are trying to use a regular 3V lithium ion battery. *This battery does not work!* The right battery has reverse polarity. The positive end of the battery is flat and the negative end is pointed.

If you use the wrong battery, you will damage the system and lose the GPS data when no power is being applied to the sight sensor. This means the crypto load in the GPS is lost. Without crypto, the GPS system cannot transition to the precise positioning service, resulting in reduced GPS and target location accuracy.

So, all operators, maintainers, warrants and sensor LARs, make sure there are plenty of BA-5372/U batteries on hand for each LRAS3 and that everyone involved in switching out an LRAS3 battery knows not to use a different 3V lithium ion.

Robert E. Youngblood LRAS3, ILS Manager Ft Belvoir, VA Editor's note: As always, Robert, you have good, absolutely need-to-know info for LRAS3 users. Users, find a way to make reading this info a permanent part of the backup battery replacement routine.




Tave you noticed an extra fuse in the excitation circuit of your MEP-804A, MEP-805A or MEP-806A tactical quiet generator (TQG)? New generators, and those coming out of RESET, should have that extra fuse.

Why?

The voltage regulation system on these generators can fail and damage the main alternator windings. The new fuse protects the alternator from that damage.

NSN


MAR 10



If you don't, get a copy of TB 11-6115-741-24 through regular pubs' channels, your CECOM LCMC LAR or the LOGSA website:


## https://www.logsa.army.mil/etmpdf/files/080000/082917.pdf

Paragraph 5.3 of that TB lists 15 steps for installing the new fuse.





5- to 200-kW TOG...

## NEUTRAL TO GROUND BAR SAFETY TSSUE



...YOU NEED TO ADD AN IMPORTANT WARNING TO THE "DESCRIPTION AND USE OF OPERATOR CONTROLS AND INDICATORS" OR THE "ASSEMBLY AND PREPARATION FOR USE, INSTALLATION OF LOAD CABLES" SECTIONS OF THE TM.





Change the words under the FUNCTION heading in Table 10, Key 1 for the MEP-809 and Key 6 for the MEP-807, GND Jumper, to read: "Jumper bonds the Neutral to ground. This bar shall NOT be removed unless the system level equipment being powered requires an ungrounded system."

Now change or add the following WARNING above Table 10, Output Load Board Terminal TB2 Connections in the MEP-807 and -809 TMs and at the beginning of the "Assembly and Preparation for Use, Installation of Load Cables" section of the 5-, 60-kW TOG's TMs. WARNING "Do not remove the Bonding Jumper between GND and N unless the weapon system requires an ungrounded system. Failure to comply can cause death or serious injury. Refer to applicable Weapon System TM for specific guidance on power and connection requirements."

These changes need to be made immediately. And inform all operators and maintainers of the TQGs, immediately.

When the TMs are updated, the pages with the new information will be added.

In the meantime, you **must** make these corrections on whatever page addresses the output load terminal board TB2 showing the ground bar jumper.

SINCGARS...

# Cabling the LS-671

THE SPECIAL PURPOSE CABLE, CX-13292/VRC, THAT CONNECTS THE LS-671/VRC LOUDSPEAKER TO THE SINCGARS RAPIO, COMES IN MANY LENGTHS.

THESE LENGTHS ALLOW THE LOUDSPEAKER
TO BE INSTALLED IN DIFFERENT
CONFIGURATIONS TO MEET THE NEEDS OF
DIFFERENT TYPES OF VEHICLES.

AN APPED BENEFIT TO THESE MULTIPLE LENGTHS IS THE FLEXIBILITY IT GIVES YOU TO TAKE THE PRESSURE OFF A TAUT CABLE,




AN 8-FT CABLE
CAN BRING
RELIEF TO A G-FT
CABLE THAT IS
STRETCHED TO
ITS LIMIT.

HERE'S A LIST OF THE AVAILABLE LENGTHS FOR THE CX-13292/VRC SPECIAL PURPOSE CABLE...

		A 1					
		13 /					
	M		(	Length (feet)	NSN 5995-01-		
	1 /			2	302-0059		
		/\		3	219-7010		
		\ <b>\</b> \	$I \setminus$	4	219-4703		
	W	MM	1	5	300-9291		
V	W			6	219-4704		
Ŋ		1		8	259-9283		
	100	200		11	225-1657		
	J ( iii		1	13	259-9282		
V		111112	-5	14	219-4705		
R	165	0000		18	219-4706		
Z				19	303-4950		
	T See			21	219-1844		
_	J			50	358-1078		
				100	382-6869		
				anni a	annananananananananananananananananana		

PS 688 46 MAR 10 PS 688



Check the control grip for missing or loose screws and the grip indicators and controls for damage. Feel the GPR sensitivity knob on the control grip for looseness. Over time, the knob sometimes works loose and can fall off. Your support can tighten the knob's set screw.

Check that the lanyard screws for the battery box and its lid are in place and secure. If screws are missing or loose, the lanyard can come off. No lanyard often means the lid will soon go missing. Support can replace screws.

#### **Before PMCS**






#### **Battery Bits**

Remember new BB-390B/U rechargeable batteries, NSN 6140-01-490-4317, must be charged within six months of their manufacture date, which is shown on the bottom of the battery. If you wait longer to charge it, the battery may not work.

But before you charge any battery, you must first completely discharge it. Otherwise, the gas gauge will give a false reading. The battery develops a memory, which prevents the visual indicator from indicating a full charge. The battery won't power the mine detector as long as it should.





The best way to discharge the battery is with a discharger, NSN 6130-01-490-4310. The discharger doesn't come with the mine detector—you must order it separately. It generally takes an hour to fully discharge a battery.

When you remove the battery box from the storage case, make sure it clears the clamp for the search head cable. If you bang the box against the clamp, you'll damage the clamp. Your support can replace the clamp. If the clamp is too damaged, the detector is NMC. Watch out for the clamp when you're putting the battery box back in the storage case, too.


When you slide the control grip forward during assembly, make sure the cable to the controls is outside the cradle. If it's not, the cable will be pinched, which can tear its covering. That can lead to shorts and poor detecting.

## Assembly






PS 688 49 MAR 10





When you disassemble the detector, ensure the securing latch is up. If you put the detector in the case with the latch down, the latch will be bent and then it won't stay in the operating position.

Make sure the storage case's rubber seal is in good shape. If it's torn or eaten up with dry rot, the case won't seal out water and dirt.

When you shut the case, be careful not to catch the lid cables between the lid and the case. That can damage the cables, which keep the lid from banging all the way back.








Sometimes the control grip cable for the AN/PSS-14 mine detector catches and rubs on body armor and other equipment, particularly for left-handed users.


That chafing can lead to shorting in the cable, which puts your detector out of commission.

Now you can protect the control grip cable with a kit, NSN 5999-01-578-0840, that brings together two lengths of corrugated tubing. The kit's directions show how to slip the tubing over the cable to shield and protect it.

Order a kit for every AN/PSS-14 in your unit so that none of your detectors suffer cable chafing.




PS 688 51 MAR 10





When you disassemble the detector, ensure the securing latch is up. If you put the detector in the case with the latch down, the latch will be bent and then it won't stay in the operating position.

Make sure the storage case's rubber seal is in good shape. If it's torn or eaten up with dry rot, the case won't seal out water and dirt.

When you shut the case, be careful not to catch the lid cables between the lid and the case. That can damage the cables, which keep the lid from banging all the way back.








Sometimes the control grip cable for the AN/PSS-14 mine detector catches and rubs on body armor and other equipment, particularly for left-handed users.

That chafing can lead to shorting in the cable, which puts your detector out of commission.

Now you can protect the control grip cable with a kit, NSN 5999-01-578-0840, that brings together two lengths of corrugated tubing. The kit's directions show how to slip the tubing over the cable to shield and protect it.

Order a kit for every AN/PSS-14 in your unit so that none of your detectors suffer cable chafing.



PS 688 51 MAR 10

Risky Business:

Unauthorized Purchase of OCIE

ANY OTHER
OLD-TIMERS
OLIT THERE
REMEMBER
THAT CLASSIC
BOARD GAME
CALLED
RISK?

ANY OTHER
OLD-TIMERS
OLIT THERE
REMEMBER
THAT CLASSIC
BOARD GAME
CALLED
RISK?

WORD ON THE GRAPEVINE IS THAT TOO MANY
SOLDIERS ARE ORDERING
THEIR ORGANIZATIONAL
CLOTHING AND INDIVIDUAL
EQUIPMENT (OCIE) FROM
UNAUTHORIZED SOURCES.


UNAUTHORIZED SOURCES INCLUDE INTERNET WEBSITES SUCH AS GENERAL SERVICES ADMINISTRATION'S ADVANTAGE AND LOCAL RETAIL STORES AND VENDORS.



SOME SOLDIERS ARE EVEN ORDERING THEIR BALLISTIC PROTECTION ITEMS, BODY ARMOR AND ADVANCED COMBAT HELMET PAPS THROUGH UNAPPROVED CHANNELS. THAT'S JUST ASKING FOR TROUBLE.

FOR SAFETY'S SAKE,
PON'T ORDER OCIE FROM
UNOFFICIAL SOURCES.
IN MANY CASES, THESE
ITEMS PON'T MEET ARMY
PROTECTION AND SAFETY
STANDARDS, AND MAY
HAVE FAILED ARMY
SAFETY TESTS.





TAKE MY
WORD FOR IT—
THE INTERNET IS
A HANDY THING,
BUT YOU DON'T
WANT TO RELY
WANT TO RELY
PLUCKED FROM A
BARGAIN BIN:





REMEMBER, SOLDIERS
ARE ONLY AUTHORIZED
TO GET PERSONAL
PROTECTIVE EQUIPMENT
AND SAFETY ITEMS
FROM THE DEPARTMENT
OF DEFENSE SUPPLY
SYSTEM, AND THE
APPROVED LIST OF ITEMS
SOLD AT THE ARMY & AIR
FORCE EXCHANGE SERVICE
MILITARY CLOTHING
SALES STORES.

PROPER SOURCING
IS THE OWLY WAY
TO ENSURE THAT THE
PROTECTIVE EQUIPMENT
YOU'RE GETTING HAS
MET ALL OF THE ARMY'S
RIGOROUS TESTING AND
SAFETY STANDARDS.

LEADERS,
STEP UP AND
ENSURE THAT
YOUR SOLDIERS
AND UNITS ARE
PURCHASING
THEIR PERSONAL
PROTECTIVE
EQUIPMENT
THROUGH
AUTHORIZED
CHANNELS.

LINALTHORIZED CLOTHING AND EQUIPMENT ARE NO SUBSTITUTE FOR OCIE PROVIDED DURING INITIAL FIELDING, ISSUED FROM SUPPLY ROOMS, OR SUPPLIED FROM CENTRAL ISSUE FACILITIES (CIFS).





SOLDIERS, IF YOU OR YOUR BUPDIES HAVE PROCURED YOUR PROTECTIVE EQUIPMENT FROM UNAUTHORIZED CHANNELS, NOTIFY YOUR UNIT SUPPLY ACTIVITY.

THEY CAN ORDER
REPLACEMENTS THROUGH
APPROVED SOURCES.

OR, THEY CAN SEND YOU TO YOUR LOCAL CIF FOR THE **RIGHT** GEAR.

**MAR 10** 

PS 688 53 **\*** 

## GET A RECEIPT FOR OCIE







You may be glad to lose the bulk and weight of Organizational Clothing and Individual Equipment (OCIE) when it's time to turn some in. But your bank account may also get a little leaner if you don't get and keep receipts for any OCIE you turn in at a Central Issue Facility (CIF).

Every year some Soldiers are unpleasantly surprised to discover that Army records still show them in possession of OCIE they no longer have. In fact, they are darned **sure** and tootin' they turned it in a long time ago in a CIF far, far away. But, when push comes to shove, Army records always prevail over verbal protests.

For your own protection and peace of mind, get receipts and take your own notes detailing exactly what OCIE was turned in when, where and in what condition. Now that your OCIE records are linked to you via modern technology and AKO, keeping the slate clean and current is essential.


When turning in OCIE, you should receive documentation from the CIF. You will need to sign and date both copies of the manual and/or automated DA Form 3645/3535-1, Organizational Clothing and Individual Equipment Record. You'll receive a worksheet that shows the items that were issued to you, and this identical information is entered into the CIF installation support module (ISM). If you don't get a receipt, speak up and ask for one.

**Tip:** It's also smart to develop a filing system to keep your copies and notes organized in case they are needed months or years later.

If you need to dispute any OCIE listed in your name, first try working with your nearest CIF facility. Most CIFs can clear/reconcile discrepancies at the local level, but sometimes, more research will need to be done that involves the initial CIF.



- Soldier must notify the local CIF immediately upon identifying any discrepancy in OCIF
- CIF should verify the Soldier's clothing record (DA Form 3645) to validate the discrepancy.
- If a discrepancy is identified involving a previous CIF, the property book officer (PBO) or CIF manager of the current CIF needs to contact the initial CIF to resolve the discrepancy. (The initial CIF is the prior CIF that issued the OCIE to the Soldier).
- If an investigation reveals that the Soldier was negligent, the Soldier must initiate a DD Form 362, Statement of Charges, or the unit commander must initiate a DD Form 200, Financial Liability Investigation of Property Loss (FLIPL).
- During processing of a FLIPL, once the equipment in question has been identified and given a document property number by the CIF PBO, the identified equipment will be removed from the Soldier's clothing record (DA Form 3645). If the Soldier agrees to pay for a lost item through payroll deduction, a DD Form 362 will be processed. The unit or activity commander will complete and sign the blocks immediately below the statement by the organization commander (Block 10). Prior to forwarding the document to the Finance Accounting Office, the accountable officer will assign a document/voucher to the DD Form 362. Then the DD Form 362 should be returned to the CIF with the signature of the finance officer (Block 11a through Block 11d). This step will result in document closure within the CIF-ISM system.



YOU CAN DOWNLOAD YOUR CLOTHING RECORD FROM THE AKO MY CLOTHING LINK: https://www.us.armu.mil/suite/page/230892

PS 688 55 MAR 10

Advanced Combat Helmet...

## ACH Chin Straps Available

IF YOU'RE IN NEED OF A NEW CHIN STRAP FOR YOUR ADVANCED COMBAT HELMET (ACH), YOUR UNIT CAN ORDER JUST THE CHIN STRAP WITHOUT PURCHASING THE ENTIRE RETENTION SYSTEM WITH ALL OF THE HARDWARE,

If you need to order just the chin strap without hardware, use NSN 8470-01-531-3351. This chin strap fits all ACH models. However, if you still need to order the chin strap assembly with hardware, use NSN 8470-01-530-0868.

#### Chinstrap, NSN 8470-01-531-3351 (strap only)


TM 10-8470-204-10 (Mar 08) is full of information on maintaining your ACH. Instructions on how to replace the chin strap can be found in WP 009, "Removing and Replacing Chin Strap Retention System."

ACH chin straps can be purchased through an authorized source, the DOD EMALL:

#### https://dod-emall.dla.mil/acct/

EMALL ordering assistance is available from customer service representatives: CONUS 1-877-352-2255, OCONUS (269) 961-7766, or by email:

dod-emallsupport@dla.mil



For more information about the ACH, contact Lillie Vinson, DSN 224-6725, (703) 614-6725, email:

lillie.p.vinson@us.army.mil or Phillip Jackson, DSN 224-0927,


(703) 614-0927, email:

phillip.jackson1@us.army.mil or Philip Manuel, DSN 654-4717,

(703) 704-4717, email:

philip.manuel@us.army.mil

# LEFT-BEHIND EQUIPMENT AND BASIC ISSUE ITEMS



The losing activity is responsible for recording all BII/COEI shortages on a shortage annex using a DA Form 2062, and ordering replacement items as required by AR 710-2, *Supply Policy Below the National Level;* DA PAM 710-2-1, *Using Unit Supply System (Manual Procedures)*, and the applicable technical manuals (TMs).

The ASC will confirm all shortage annexes and ensure updated findings are noted on a DA Form 2062, unless otherwise directed by ASC headquarters. All equipment must also meet TM -10/-20 standards before it is transferred to another Army activity.

## PROPERTY ACCOUNTABILITY COURSES

MANTA BITE ON GINTE (WHOA, CONBOY!

TIME TO ROUND UP THESE PROPERTY **BOOK OFFICERS** AND HERD THEM STRAY DOGGIES BACK TO THE BOOKS.



CENTER AND SCHOOL OFFERS ONLINE PROPERTY ACCOUNTABILITY COURSES, WHICH MEANS YOUR UNIT'S PBO DOESN'T EVEN HAVE TO LEAVE THE DESK TO LASSO UP THE LATEST IN DISTANCE LEARNING.

## **Property Accountability Courses Online**

The Army Training Information Architecture website: http://www.train.army.mil/

- 92A Basic Supply Principles—3 hours
- Report of Survey Officer Orientation—1 hour
- Financial Liability Officer Orientation—1 hour
- Unit Supply Specialist (DL) (92Y)—10 hours; also available on CD from Defense Imagery (see URL below)

The Defense Imagery website: http://www.defenseimagery.mil/index.html (Enter course title in 'search' box, and choose the IMI [Interactive Multimedia Instruction] tab)

- Supply Management Training 92A30—39 hours
- Intermediate Level Unit Supply Procedures—25 hours
- Unit Armorer Training Program—19 hours

The Army's Learning Management System website: https://www.lms.army.mil/

- 92A10 Non-Automated Sustainment Training—54 hours
- S-4 Staff Officer Course—53 hours
- Property Accountability for Leaders in the Contemporary Operating Environment-15 hours


Send comments and suggestions for future courses:

Note: Information provided in this article courtesy of Army Sustainment magazine.

PS 688 58 MAR 10



# KEEP THE FORCE VITH YOU!




BFT SYSTEMS ARE CURRENTLY TRACKED IN PBUSE BY THE SERIAL NUMBERS (SNS) OF VARIOUS MAJOR COMPONENTS, SUCH AS TRANSCEIVER SNS, PROCESSOR UNIT SNS, POWER SUPPLY SNS, ETC.

BFT TACTICAL OPERATION CENTER (TOC) KITS AND BFT SATELLITE VEHICLE VERSIONS WILL NOW BE TRACKED BY THE SNS CORRESPONDING TO THEIR MT-2011 TRANSCEIVERS.

THIS CHANGE WILL STANDARDIZE THE METHOD OF RECORDING THE BFT SYSTEMS IN PBUSE.

THE FOLLOWING CHART SHOWS THE END ITEM NSNS THAT MUST NOW BE TRACKED BY THE MT-2011 TRANSCEIVER SNS...



	Item	Model	LIN	NSN	Now tracked under S/N for:	NSNs of different versions of the MT-2011 transceiver
	BFT	AN/GYK-62B	Z01248	7010-01- 554-2356	MT-2011 Transceiver	5895-01-503-3932 (E version)
	TOC Kit	AN/GYK-62C	FJ101N	7010-01- 569-0604		5895-01-551-7316 (F version)
Sat	BFT- Satellite	AN/UYK-128 (V)3	C18378	7010-01- 513-8459	MT-2011 Transceiver	5895-01-503-3932 (E version)
	version					5895-01-551-7316 (F version)



## M900-Series Tanker Engines

When the Onan engine used on your M900-series 5,000-gal fuel semitrailer is no longer repairable, replace it with a Lombardini engine, NSN 2815-01-471-4411. To switch out the old engine, which Onan no longer builds, you must use kit, NSN 2815-01-459-0006. The kit has frame components and all hardware with installation instructions.

## FEO LOG Offers Handy

Put the calculator away. It's quick and easy to convert US customary measurements to metric, and decimals to fractions right in the FED LOG program. Virtual buttons in the top right-hand section of the screen will do speedy calculations for you, plus you can switch back and forth between the two systems. For more information regarding FED LOG, call the Defense Logistics Information Service at DSN 661-7766, (877) 352-2255, or email:

#### SAFETY CENTER ADDS WEB-BASED TOOL FOR DEPLOYED SOLDIERS

The U.S. Army Combat Readiness/Safety Center at Ft Rucker has launched a new Web application to help leaders and Soldiers reduce risk while deployed to areas with limited Internet connectivity.

The Safety Center's homepage is now available in a "lite" version, so the page only loads elements necessary to help users with limited Internet connectivity quickly find what they need. Visit the Safety Center's lite site:

https://safety.army.mil/lite

## **M915 Front Suspension Kit NSNs**

Need to beef up the suspension on your M915 tractor trucks that have add-on-armor? Installing a front suspension modification kit can solve that problem. Get the kits for M915A2P1s using NSN 2510-01-569-4196, NSN 2510-01-569-4198 for M915A3P1s, and NSN 2510-01-569-4193 for M915A4P1s.

## M1151 STEERING GEAR

NSN 2530-01-554-3441 gets the steering gear assembly for the M1151 HMMWV. This NSN replaces the parts info shown as Item 1 in Fig 32 of TM 9-2320-335-13&P.

#### **HELMET BAG**

Without a flight helmet bag, your integrated helmet and display sight system (IHADSS) is not protected. Order one with NSN 8415–01-406-6909.

## **NEW WATER HEATER**

The Army has a new water heater in the supply system. It's the Army water heater 400 (AWH 400), NSN 4520-01-566-6669. The AWH 400 is an alternative to the old M80 and M85 heaters.

The new heater runs on a variety of fuels, including DF1, DF2, DFA, JP-5 and JP-8. It's used primarily to heat water for the Army's 12-head portable showers.

## PS 688 60 MAR 10

## M1117 ASV URL Update

On Page 13 of PS 686 (Jan 10), the URL we included was wrong. The website is secure and must begin with "https". Here's the correct link:

https://weblog.logsa.army.mil/Veh\_reg/main\_input.cfm

## **GPP URL Update**

On Page 58 of PS 685 (Dec 09), the original URL we gave for the Federal Green Purchasing Program has changed. Here's the new link:

http://www.fedcenter.gov/programs/buygreen

## **GRAT Goes SIPRNET**

The Ground Risk Assessment Tool (GRAT) developed by the U.S. Army Combat Readiness/Safety Center now has a mirror image on the Secret Internet Protocol Router (SIPRNET). The GRAT-S helps identify, assess and control hazards associated with specific missions or tasks.

**Note:** An AKO-SIPRNET username and password is required to login to GRAT-S. The following URL is accessible only from SIPRNET terminals:

#### http://safety.army.smil.mil/GRAT-S

For more info, contact the Ground Task Force at DSN 558-2101/3641, (334) 255-2101/3641, or email:

GRAT@conus.army.mil

## PBUSE: No More Entry via AKO

PBUSE is no longer accessible through AKO. Now, users must enter the PBUSE website directly:

https://pbuse.us.army.mil/ Questions? Call the PBUSE help desk: DSN 259-8619, (866) 547-1349.

## **D5B Engine Starter**

Use NSN 2920-00-425-5932 to get the engine starter for the D5B tractor. This NSN replaces the one shown as Item 4 in Fig 46 of TM 5-2410-236-24P. By the way, this is the same starter that's used on the D7F and D7G tractors.

## **ATLAS FORKLIFT SERVICE KITS**

Two service kits are available for the 10,000M Atlas forklift. The 500-hr kit comes with PN 1001111811 and the 1,000-hr kit comes with PN 1001102923. Both kits come with CAGE (1YHH8) and can be ordered on a DD Form 1348-6. You can also contact the kits' manufacturer, JLG, and order them by emailing Ms. Terri Bradley:

tlbradley@jlg.com

DISTRIBUTION: To be distributed in accordance with the initial distribution number (IDN) 340312, requirements for TB 43-PS-Series.

Would You Stake Your Life on the Condition of Your Equipment?

Your helicopter has
thousands of rivels, washers,
screws and bolts to help
make it flyf



BUT IT TAKES
JUST ONE NUT
TO DESTROY IT!



PREVENT FOD and KEEP 'EM FLYING!

