


# Pulling PM



We spend a whole lot of time pushing preventive maintenance here at PS. Today, on this page, we would like to give a little emphasis to pulling it.

Who pulls the string that gets preventive maintenance accomplished?

The general answer is, anyone in a leadership position. The specific answer is the commander, the unit maintenance officer and unit sergeants.

Preventive maintenance starts in the office of the commander. The PM program under his or her command is only as good as the emphasis he or she gives it. If PM does not have a "starring role" in the commander's office, it will be no more than a "bit player" in motor pools and shops.

The weight of a good PM program falls heavily on the unit maintenance officer. If he or she spends all the time "firefighting," being reactive instead of proactive, preventive maintenance will not be done. Preventive maintenance must be an in-place plan that operates regardless of the fires. If PM is put on the back burner every time there is a fire, there will be a fire every time PM is put on the back burner.

Ultimately, a unit's PM program is only as good as the first line supervising sergeant's leadership. Only when that sergeant is on the job giving instruction, reviewing processes, encouraging those doing the maintenance and promoting the importance of PM, will the PM program be a successful one.

Eisenhower knew about leadership. He knew how to "pull the string." When it comes to preventive maintenance, if you are in a leadership position, make sure you are pulling the string so that the world's best equipment stays that way.



# THE PREVENTIVE MAINTENANCE MONTHLY

TB 43-PS-607, The Preventive Maintenance Monthly, is an official publication of the Department of the Army, providing information for all soldiers assigned to combat and combat support units and all soldiers with unit maintenance and supply duties. All information published has been reviewed and approved by the agency responsible for the equipment, publication or policy discussed. Application of the information is optional with the user. Masculine pronouns may refer to both genders.

ISSUE 607 JUNE 2003						
WHEELED VEHICLES	2	AVIATION 35				
HMMWV Tire Maintenance	2-9	UH-60A/L Filter Sleeve Tool Correction UH-60 Cannon Plug Strap Wrench 36-37				
COMBAT VEHICLES	10	CH-47D Tie Bar Pins 38-39 ALSE Distress Marker Infrared Housing 40				
M1-Series Tank Periscope Prism Housing M1A1 Tank Commander's Panels	10 11	OH-58D Crew Jettison Door 41				
M2/M3-Series Bradley M242 Gun MLRS Carrier Vibration Damage	12-13 14	COMMUNICATIONS 42				
Combat Vehicles Lifting Sling Hooks M109A2, -A5 Howitzers Fuel	15	30-, 60-KW DCS TQG Batteries and Fuses 42-43 TQG Replacement Dipstick NSNs 44				
Contamination M109A6 Paladin Segment Board	16 17	PLGR Parts List 44 Commo Shop Safety Signs 45				
MISSILES	18	26-Pair Cable Connector NSNs 45 5-, 10-KW Generators Article Correction 46 MWO Website 47				
Hellfire Missile System  Launcher Installation	18-19	SOLDIER SUPPORT 48				
Hellfire Missile System Launcher Tips TOW 2 Missile System Tripod	20	Lightweight Camouflage Screen PM 48-49				
Locking Clamps	21	Explosive Ordnance Disposal Wire Routing 50-51				
COMBAT ENGINEERING	22	NBC 52				
MICLIC Traveling PM	22-24	M17-Series Decon Spark Plugs 52 M17-Series Decon MOGAS Usage 53				
TOOLS	25	M17-Series Decon Engine Replacement 54 M17-Series Decon Burner 55 M41 PATS Software 55				
Jack Stand Safety Signs Shop Equipment Alternator Bracket Defective 7-ton Trestles	25 25 26	LOGISTICS MANAGEMENT 56				
Defective 7-ton frestles	26	Army Knowledge Online Website 56-59				

You are invited to send PS your ideas for improving maintenance procedures, questions on maintenance and supply problems and questions or comments on material published in PS. Just write to:

t Write to: MSG Half-Mast PS, the Preventive Maintenance Monthly USAMC LOGSA (AMXLS-AM) 5307 Sparkman Circle Redstone Arsenal, AL 35898-5000

Or e-mail to: psmag@logsa.redstone.army.mil Internet address:


http://www.logsa.army.mil/psmag/pshome.html

By order of the Secretary of the Army:

#### ERIC K. SHINSEKI

General, United States Army Chief of Staff

Official:



Administrative Assistant to the Secretary of the Army

0310501

PS, The Preventive Maintenance Monthly (ISSN 0475-2953) is published monthly by the Department of the Army, Redstone Arsenal, AL 35898-5000. Periodical postage is paid at the Huntsville, AL post office and at additional mailing offices. Postmaster: Send address changes to PS, The Preventive Maintenance Monthly, USAMC LOGSA (AMXLS-AM), 5307 Sparkman Circle, Redstone Arsenal, AL 35898-5000.



NINE OUT OF 10
DRIVERS AND
MECHANICS WILL
TELL YOU THE
BIGGEST PROBLEM
THEY HAVE WITH
HMMWVS IS TIRES.

AND ONLY ONE OF 'EM WOULD BE WRONG!


MAKING YOUR HMMWV TIRES HOLD UP FOR THE LONG HAUL TAKES LOTS OF PM. SO LOAD UP ON THSE TIRE ESSENTIALS!



#### Steering Linkage

You may think you can skip an inspection or lubing of the steering linkage every now and then. But when a linkage part fails and someone is injured or killed, you'll find out just how wrong you are!

A couple of inspections and a liberal lubing every six months or 3,000 miles (whichever comes first) is vital for keeping your HMMWV's steering linkage in good shape during normal operations. You'll need to up the number of inspections and lubings when operating in mud, snow or desert conditions, though.



HERE'S
WHAT YOU
OPERATORS
AND
MECHANICS
NEED TO
DO TO
KEEP THE
WHEELS
TURNING
SAFELY...

### • Lower ball joint:

Mechanics, Page 6-60 of the 280-20-2 TM and Page 6-54 of the 387-24-1 TM have the procedures for measuring play in the lower ball joint. No more than 1/8-in play is allowed.



Mechanics, check out Pages 8-54 through 8-57 of TM 9-2320-280-20-2 (Jan 96) and Pages 8-46 through 8-49 of TM 9-2320-387-24-1 for the procedures to measure play in the idler arm. No more than ¼-in play is allowed.







PS 607



#### • Lubing:

Operators, use GAA on the idler arm, tie rod ends, pitman arm, radius rod and upper ball joint as spelled out in the lubrication instructions in Appendix G of TM 9-2320-280-10 and TM 9-2320-387-10.






#### Wheel Balancing

Generally, the steering wheel will shake when the front wheels aren't properly balanced. If the shaking gets serious enough, the wheel studs can loosen or break off, leaving you with no control over the vehicle as you move down the road

To put an end to shaky driving, your mechanic needs to start with the bubble wheel balancer, NSN 4910-01-093-0167, from the No. 1 or No. 2 Common shop sets. Tire balancing procedures are found on Pages 8-30 and 8-31 of the -280-20-2 TM and Pages 8-22 and 8-23 of the -387-24-1 TM.



Wheel weights for balancing are listed in Fig 167 of TM 9-2320-280-24P-1. Here they are along with a few extra weights...

Size (Ounces)	NSN	Qty
1/2	2530-01-261-6844	50
1/2	2530-01-235-8688	360
1	2530-00-848-4581	1
11/2	6670-01-261-6845	50
2	6670-01-261-6846	50
21/2	6670-01-262-8646	50
3	6670-01-261-8011	50
31/2	6670-01-261-8012	25
4	6670-01-261-8013	1
5	6670-01-262-8647	25
51/2	6670-01-263-2268	25
6	2530-00-050-2064	1
6	2530-01-028-1307*	25
8	2530-01-027-6943*	1
16	2530-00-709-5922	1

\*Order on a DD Form 1348-6 and put "NSN not on AMDF" in the REMARKS block.




PS 607

#### Tire Studs and Nuts

Loose stud nuts can also lead to serious shaking problems. So make sure studs and nuts are properly cleaned, inspected and tightened. Here's how:

- Use a wire brush to break loose dirt from studs. Clean the studs with soap and water and allow them to dry completely.
- Look for studs that are cracked, broken, rusted, pitted, bent, or loose. Pay special attention to the threads for damage. Replace damaged studs.
- Stud nuts have to be tightened gradually and in the proper sequence to avoid bent and broken studs. You'll find the right tightening order on Page 8-7 of the -280-20-2 and -387-24-1 TMs.

Tighten all the nuts by hand first, then torque the nuts to 90-110 lb-ft following the proper pattern.





5

#### Front Wheel Toe-in Check and Alignment




All the steering inspections and tire balancing in the world won't do much good unless you mechanics make sure the front wheels are properly aligned.

That means performing a front wheel toe-in check during every scheduled semiannual or 3,000 mile maintenance interval. 'Course, if abnormal vehicle handling or control is reported earlier, you'll need to do it then, too.




IF YOU'RE CHECKING AN M1037 OR M1042 MODEL HMMWV, MAKE SURE THE S250 SHELTER IS INSTALLED BEFORE PERFORMING THE TOE-IN CHECK. THEN FOLLOW THESE STEPS...

- **1.** Place the vehicle on level ground with the wheels set straight ahead.
- 2. On the front side of a front tire, mark a line on the center tread 16 1/2 inches up from the ground.



- **3.** Mark a second line at the center point of the tire's width. At that point, both lines should form a +.
- 4. Repeat steps 2 and 3 for the other front tire.



**5.** Measure the distance between the center points of the two + marks and write it down.



**6.** Rotate the tires by moving the vehicle straight forward until the center points of the two + marks are 16 1/2 inches above the ground at the rear side of the tires.



7. Measure the distance between the center points of the two + marks again and write it down.

NOTE: If the front-side tire measurement is larger than the back-side tire measurement, the tires have toe-out.

**8.** Subtract the front-side tire measurement from the rear-side tire measurement. Then compare the result with the specifications in the following chart:

	Bias Tire		Radial Tire			
Vehicle Payload	Models: M998, M1025, M1035, M1038, M1043, M1044	Models: M966, M996, M937, M1036, M1037, M1042, M1045, M1046	Models: M996, M996A1, M998, M998A1, M1025, M1025A1, M1025A2, M1026, M1026A1, M1035, M1035A1, M1035A2, M1036, M1038, M1038A1, M1043, M1044A1, M1044A1, M1045A2, M1045A1	Models: M997, M997A1, M997A2, M1037, M1042	Models: M1097, M1097A1, M1097A2	Models: M1113, M1114
Vehicle at curb weight	7/16 ± 1/8 in.	5/16 ± 1/8 in.	1/4 ± 1/16 in.	5/16 ± 1/16 in.	5/16 ± 1/16 in.	1/4 ± 1/4 in.
Vehicle at normal operating weight (optional)	1/4 ± 1/8 in.	1/4 ± 1/8 in.	1/16 ± 1/16 in.	1/16 ± 1/16 in.	1/16 ± 1/16 in.	1/4 ± 1/4 in





IF THE RESULT MEETS
THE SPECIFICATION LISTED
IN THE CHART ON THE
PREVIOUS PAGE, YOUR
VEHICLE IS IN ALIGNMENT,

IF NOT, YOU'LL NEED TO ADJUST IT LIKE SO...

- **1.** Loosen the two locknuts from the clamps on each adjusting sleeve.
- 2. Turn each adjusting sleeve an equal amount, but in opposite directions. For example, if the difference in measurement was 1 inch, you should turn each adjusting sleeve 1/2 inch. Remember, both tie rods *must* be the same length (±1/8 inch) after the adjustments have been made or the toe-in is out of adjustment.



- 3. Roll the vehicle backward and then forward to the original position.
- **4.** Repeat the toe-in check and alignment until the measurement falls within the specifications outlined in the chart.
- 5. Retighten the two clamp locknuts to 30 lb-ft.

#### **Rear Wheel Toe-out Alignment**



- 1. Place the vehicle on level ground with the wheels set straight ahead.
- 2. On the forward side of a rear tire, mark a line on the center tread 16 1/2 inches up from the ground.
- 3. Mark a second line at the center point of the tire's width. At that point, both lines should form
- 4. Repeat steps 2 and 3 for the other rear tire.
- **5.** Measure the distance between the center point of the two + marks and write it down.
- **6.** Rotate the tires by moving the vehicle forward until the center points of the two + marks are 16 1/2 inches above the ground at the rear of the vehicle.

7. Measure the distance between the center point of the two + marks and write it down.

**NOTE:** If the rear-side tire measurement is larger than the front-side tire measurement, the tires have toe-in.

**8.** Subtract the rear-side tire measurement from the front-side tire measurement. Then compare the result with the specifications in the following chart:


Bias Tire		Radial Tire					
	Vehicle Payload	Models: M998, M1025, M1026, M1035, M1038, M1043, M1044	Models: M966, M996, M997, M1036, M1037, M1042, M1045, M1046	Models: M996, M996A1, M998, M998A1, M1025, M1025A1, M1025A2, M1026, M1026A1, M1035, M1035A1, M1035A2, M1036, M1038, M1038A1, M1043, M1043A1, M1043A2, M1044, M1044A1, M1045, M1045A1 M1045A2, M1046 M1046A1	Models: M997, M997A1, M997A2, M1037, M1042	Models: M1097, M1097A1, M1097A2	Models: M1113, M1114
	Vehicle at curb weight	7/16 ± 1/8 in.	5/16 ± 1/8 in.	1/2 ± 1/16 in.	1/2 ± 1/16 in.	1/2 ± 1/16 in.	1/2 ± 1/4 in.
	Vehicle at normal operating weight (optional)	1/4 ± 1/8 in.	1/4 ± 1/8 in.	1/16 ± 1/16 in.	1/16 ± 1/16 in.	1/16 ± 1/16 in.	1/2 ± 1/4 in.



- 1. Loosen the two locknuts from the clamps on each adjusting sleeve.
- 2. Turn each adjusting sleeve an equal amount, but in opposite directions. For example, if the difference in measurement was 1 inch, you should turn each adjusting sleeve 1/2 inch.
- 3. Roll the vehicle backward and then forward to the original position.
- **4.** Repeat the toe-out check and alignment procedures until the measurement falls within the specifications outlined in the chart.
- 5. Retighten the two clamp locknuts to 30 lb-ft.



PS 607 8 JUNE 03 PS 607 9




Jamming the driver's AN/VVS-2 night vision viewer into its mount without adjusting the wiper blades will break the viewer housing and damage the wipers and flexible shaft parts.

Normally, the wiper blades are left in the upper left or right positions so they're not in the driver's field of vision. But when the scope comes out, the wipers retract into the hatch housing just enough to become trapped between it and the night vision viewer.

Once you tighten down the wingnuts, the prism housing cracks and the wiper blades are damaged. To make matters worse, moving the handle to operate the jammed wipers can damage the flexible shaft and linkage parts of the wiper mechanism.

Make sure this doesn't happen by placing the wiper blades in the vertical position (straight up-and-down) and holding them away from the opening before removing the center scope just like it states in the -10 TMs. That way the wipers still work and the prism doesn't get cracked.



tank's -10-1 TM.

Page 1-45 on the tank's NBC system says there are only three configurations of the tank commander's panel. But now there are five.




PS 607

So, until the TM is updated, replace Para 2 with the following:


"There are five configurations of the tank commander's panel. Part numbers 9376322 and 9377879 will start NBC System when engine starts unless turret networks box circuit breaker CB3 is turned off. Part numbers 12549797, 12549797-2, and 12549797-3 will not start NBC System automatically."

YOU'LL FIND THE PART NUMBER ON THE PANEL'S DATA PLATE,

JUNE 03



Never put the M242 in the solvent washer or use CLP. Solvent ruins the M242's seals, O-rings, and bearings. That means major repairs. For the same reason, don't use CLP for cleaning and lubing the M242. CLP breaks down graphite grease in gears, sprockets, and the track and bolt assembly, which quickly wears out bushings, gears, and bearings. It takes four hours for support to tear down an M242 and regrease it. Lube the M242 with GMD and general purpose lubricating oil like TM 9-2350-252-10-2 says.



#### **Troubleshooting Help**

If you have a misfire or jam, don't drop the vertical drive shaft. That throws off the timing between the receiver and feeder. Don't turn off the relay assembly. That clears out the logic from the turret distribution box and prevents firing. Your best bet is to ask the master gunner for help.


If the reticle jumps around during firing, you probably have a loose resolver. Tell your repairman. A loose resolver ruins accuracy. It's a good idea to have the resolver tightened before you go to the field.

If the M242 jerks from side to side, the traverse drive assembly probably needs to be adjusted. Tell your repairman.



#### **Advice for Repairmen**

When you fill the recoil mechanism with damper fluid, put the mechanism in a vise like TM 9-1005-200-23&P shows. Some repairmen try to just lay the mechanism on a table to do the job and end up bending the push rod. Then the whole recoil mechanism must be replaced.



PS 607 13 JUNE 03


MLRS Carrier...

# GUARD AGAINST VIBRATION DAMAGE




That old enemy, vibration, is claiming yet another victim: the vane axial fan on your MLRS carrier. Stress and vibration can cause one or more of the fan's mounting bolts to loosen or snap. If that happens, even more stress is put on the remaining bolts. Eventually, the vane axial fan can fall off.


During your PMCS, eyeball the mounting bolts closely. If you spot signs of loosening (shiny spots around the bolt heads) or missing bolts, report 'em.



While you're there, take a look at the fan drive guard, too. Vibration can weaken and snap the guard at its mounting bolts. When that happens, the guard can fall into the fan blades.

Look for cracks or breaks to the guard and report any you see. Your mechanic can replace a damaged guard with NSN 4140-01-315-3959.








Water in the fuel system of your M109A2-A5 howitzer is trouble. It promotes the growth of microorganisms that clog fuel lines and filters.


Wondering how water gets in the fuel? Look no farther than the fuel filler neck opening.

Water pools around the filler neck opening. If the fuel cap gasket is old or worn, it lets water seep past and go straight into the fuel system.



So eyeball the gasket, NSN 5330-00-179-0414. If it's missing, torn or cut, have your mechanic replace it following the procedures on Pages 6-4 and 6-5 of TM 9-

16




- Make sure the filler cap is snugged down tight after each refueling. A loose cap keeps the gasket from doing its job.
- Check for any visible damage to the cap or the filler neck. Dents or gouges prevent a good seal.
- Use a rag to soak up any water that has accumulated around the filler neck before fueling. If you don't, that water will pour into the fuel tank as soon as you open the fuel cap.

JUNE 03

M109A6 Paladin...

# Prevent Pad Problems




Crewmen, after you've cleaned the segment board on your Paladin, don't forget to remove the green pad from the cleaning block.


If you leave it in place, dirt and other debris begin building up. The pads eventually make contact with the segment board causing interference and distortion on the intercom.

When you **do** remove the pad, make very sure that you get the block locked back down on the cleaning mechanism.

If it's not locked down properly, vibration makes the cleaning block pop up. In that position, the cleaning block rubs against the segment board until—zap!—the segment board shorts out. You're left without turret power or commo.


Ensure the cleaning block is locked down by eyeballing it. Look for a slight gap between the cleaning block and the cleaning mechanism. A gap means the cleaning block is not locked down. Try again.





No gap? The cleaning block is locked down and you're good to go.


PS 607 17 JUNE 03




- Don't rush when you install the launcher. Just a little carelessness can damage items like the J511 umbilical connector. Repairers, not crewmen, install the launcher. That's repairers plural. Because of the launcher's weight and size, it takes four people to safely install it.
- Before you install the launcher, repairers, make sure the jettison ejection foot is up far enough to let the launcher clear it. If the ejection foot is screwed down too far, it can dent the launcher or make it difficult to lock in the launcher.


Once the launcher's installed, screw down the foot so that it almost touches the launcher. Otherwise, you can't jettison the launcher during an emergency.

• Hook up the P511 cable to the launcher's J511 connector before locking the launcher on the ejector rack. If you install the launcher first, you won't have enough clearance to maneuver the cable, so you'll strip the connectors or bend pins.






• After the launcher is installed, check the two suspension lugs. If you see more than three threads on the lugs, the lugs are not screwed in far enough and the launcher may not be secure. See Para 2-39 in TM 9-1425-475-23&P for information on tightening the lugs.








18 JUNE 03

PS 607




Take it slow and easy. Slide the missile slowly down the rail. Watch the springs of the upper/lower rail wiring harness. When the springs slightly compress, move the holdback latch handle to the latched position.



A Hellfire should slide easily into the launcher. If it doesn't, something is probably wrong with either the launcher, missile shoes, or umbilical connector. Jamming the missile in place will damage both the missile and launcher. So try loading a different missile. If that doesn't do the trick, ask your repairman to take a look.

20

**Don't put your feet on the launcher.** It's not a step. If you put your weight on the launcher, you can bend the rails or break the connectors. That puts the launcher out of business.



PS 607

Guide the locking handles into the LOCK position. If you let the handles flip down, it wears out their springs and could damage the microswitch that tells you the missiles are locked in. It also wears out the missile mid-shoe.




JUNE 03



If you ignore your TOW's tripod, it won't have a steady leg to stand on. For a line-of-sight system like the TOW, that's the end of accuracy. Several units have even seen their weapons take a tumble because of tripod problems.

The best way to prevent tumbling TOWs is to pay attention to the tripod's locking clamp. If it works loose, the TOW takes a fall

After you install the traversing unit (TU) and lock down the clamp, try to twist the TU back and forth. If there is **any** movement, tighten the clamp with a 3/16-in hex wrench, NSN 5120-00-240-5300.







Turn the TU again. If there's still play, it's time for a new tripod. Also make sure the locking clip for the clamp locks the clamp securely. If it doesn't, the clamp can work loose. Report a bad clip.




Last, check the tripod crossbars on all four sides for cracks. Just one crack signals the tripod is shot.




PS 607 21 JUNE 03



THE DIFFERENCE
BETWEEN YOUR MICLIC
BEING ON THE ROAD AGAIN
OR SITTING BROKEN DOWN
ALONG THE ROAD CAN BE
AS SIMPLE AS HEEDING
THIS TRAVELING ADVICE.



When you pull your MICLIC behind a tracked vehicle, tie the brake hoses to the trailer frame to keep them from dragging or getting torn off. You'll need the hoses to work the brakes when you pull the MICLIC behind a truck. When you use a truck, hook up the hoses, then tie up the hoses so they don't hang down.



JUNE 03

22

or track. It's worth the trouble. The cables are expensive.

Keep brake hoses connected to keep dust and moisture out of the air brake system. When the MICLIC is just sitting, trailer brake hoses should be stored in the MICLIC trailer.

the vehicle towing the MICLIC. The cables

shouldn't drag the ground where they can

catch on something and be ripped out. But

you also should leave enough slack in the


cables so that when the vehicle makes a sharp

turn the cables won't be ripped loose. You may need to experiment with how much slack to

leave in the cables and where the best places

are to tie off the cables on the top of the truck

Because the MICLIC has both tires and track, it requires even more attention than the average vehicle. Rough country can quickly cause a wheel misalignment and before you know it a tire or track is ruined. Each track costs several thousand dollars.







Before leaving the motor pool, check all 8 tires for gouges or bad wear, especially along the insides of the tires. Look at the track teeth for uneven wear. Check that the teeth are centered between the tires. If you spot problems, tell your mechanic. He can align the track with the procedure beginning on Page 4-38 in TM 9-2330-389-14&P.

The tire listed as Item 23 in Fig 5 in the -14&P is no longer available. Instead, order tire, NSN 2610-00-142-5389, and inner tube, NSN 2610-00-269-7373.

If you're traveling through heavy mud, clean between the tracks and tires at every stop. If too much mud gets packed between the track and tires, the track will come off. It's no easy job to get the track back on in the field.





Use the truck or APC pioneer tools to clean out the mud. Scrape out the mud, move the MICLIC forward and scrape out the rest.



REMEMBER, ANY TIME THE MICLIC GOES THROUGH DEEP MUID OR WATER THE WHEEL BEARING LUBE IS WASHED OUT. WITHOUT LUBE, THE BEARINGS WILL SEIZE, LUBE THEM ASAP, THE LUBE CHART IS IN CHAPTER 3 OF TM 9-2320-389-14&P.



Make gradual turns and avoid dips. Turns that are too sharp let the back of the truck or track shear cables. Steep dips have the same result. If you can't avoid dips, take them slow.

#### M113A3

In case you haven't heard, you need a tow pintle extension, NSN 2540-01-458-4846, if you tow the MICLIC with a M113A3. Without the extension, the M113A3 bangs the heck out of the trailer and eventually the trailer has to be replaced. You don't need the extension with the other versions of the M113.



Jack Stands...

# SIGN OF THE TIMES



Dear Editor,

When jack stands are used on a vehicle, it's easy to overlook them, especially in the close confines of a motor pool bay.

For the safety of our soldiers, we've made it SOP to hang a warning sign on any vehicle that's on jack stands. Since the signs are easy to see, we've pretty much eliminated the danger of a soldier accidentally leaning against a vehicle on jack stands.

Motor Pool 3/18th FA Ft Sill, OK




That's an outstanding safety suggestion!



#### **Shop Equipment Bracket**

The A1 version of the contact maintenance shop equipment vehicle, NSN 4940-01-333-8470, has an alternator bracket for the under-hood welder that's not strong enough. The bracket lets the alternator move too much, which results in loss of power to the welder, bolts breaking, and belts slipping off the pulleys. To get a stronger bracket and instructions on how to install it, contact TACOM-Rock Island's David Muller at (309) 782-4750/DSN 793-4750 or mullerd@ria.army.mil

PS 607 25 JUNE 03



We've said it before and now we'll say it again: If your unit has any 7-ton trestles (jack stands), NSN 3950-00-251-8013, they could be defective.

Trestles manufactured by Martinez and Sons, Inc., in 1979 have a defect that can cause them to buckle and collapse if the load is off-center.

Take a look at the data plate. If it lists the manufacturer as Martinez and Sons, Inc., and has a contract number of DAAA09-79-C-4216, you've got one of the defective trestles. The "79" in the contract number refers to the contract year— 1979.

Defective trestles should be destroyed by crushing, cutting or any other method that makes them unusable. Trestles that are missing data plates and can't be otherwise identified, should be condemned, too.


Martinez and Sons, Inc., had several contracts for 7-ton trestles between 1979 and 1990. So, if your 7-ton trestle was made by Martinez and Sons, Inc., in any year other than 1979 or by any other manufacturer, it's OK to use.

SOUM 092030Z Oct 87 issued by CDR AMCCOM has the scoop. Write to Half-Mast at psmag@logsa.redstone.army.mil for a copy.

PS 607 JUNE 03

# Frouer's Mill Gazette New York:

WAR OF THE WORLDS



# Radio Listeners in Panic

Many Flee Homes to Escape 'Gas Raid From Mars'

A wave of mass hysteria seized thousands of radio listeners th out the nation between 8:15 and 9:30 o'clock last night whe broadcast of a dramatization of H.G. Wells's fantasy, "The War led thousands to believe that an interplanetary conflict had started. invading Martians were spreading death and destruction in New Jersey and New York.

AND HIS MERCURY THEATER ON THE AIR DRAMATIZING A MARTIAN INVASION AT GROVER'S MILL, NEW JERSEY HAS BEEN A PART OF HISTORY FOR 65 YEARS, THE BELIEF WAS THAT IT WAS NOTHING MORE THAN A COMBINATION OF RADIO DRAMA AND A POPULATION ON THE EDGE. BUT... WAS IT?

injury to lif aveling fr me in Do sey, he b eaming h Kilg

Sma Cart Crip

Ame for V


Artis

Concer

Sketch ar Joseph Kul

delivered h

of the Mart at risk of gr









BUT, ANYWAY,... MOST OF MARS IS DESERT. LOTS OF MOVING SANDS AND ROCKY FLATS. BUT, I WAS SURPRISED TO FIND WATER ON MARS.






"CONTRARY TO POPULAR
BELIEF, MARS IS NOT
ALWAYS COLD. THEY'VE
BEEN FOOLING OUR
CLIMATOLOGISTS FOR
YEARS WITH A TEMPERATURE MASKING
PEVICE. MARS IS VERY
HOT IN THE SUMMER.
OUR SOLDIERS WILL
FEEL EXTREME HEAT
AND BE BLASTED BY
PUST AND SAND."



PS 607 29 JUNE 03




























PS 607 30 JUNE 03 PS 607 31 JUNE 03

























PS 607 32 JUNE 03

"WE NOW HAVE COMPUTERS BUT LET ME ADD A FEW OTHER NEW THINGS.




"ALL THESE ARE SUBJECT TO SAND, HEAT AND MOISTURE DAMAGE, PREVENTIVE MAINTENANCE WILL KEEP THEM IN WORKING ORDER.




















EDITOR'S COMMENT: WE TOOK THOSE MARTIANS TO SCHOOL AND TAUGHT THEM A HARD LESSON, WE LEARNED A FEW THINGS THAT HELPED US WHEN WE BAILED OUT EUROPE PURING WORLD WAR II.

THE MARTIANS ARE NO LONGER A THREAT, BUT THERE ALWAYS SEEM TO BE "MARTIANS IN EARTH-ING CLOTHING" WHO WANT TO RULE THE WORLD. SOME OF THEM WE MIGHT FIND IN ENVIRONMENTS SIMILAR TO MARS. IF WE DO, WE NEED TO BE READY WITH OUR GREATEST WEAPON: PREVENTIVE MAINTENANCE.

PS 607 34 JUNE 03




**OOPS**, we goofed! On Page 37 of PS 596 (Jul 02), the drawing measurements to make the positioner tool are off.

The diagram did not show that the critical distance between the two pin bolts is 5 inches from the outside of the first bolt, across the center of the tool to the outside of the second bolt.

With the previous instructions the positioner tool won't fit properly, and you'll have to grind off about .030 inches from each bolt on the outside edge to make the tool fit.

HERE'S A CORRECTED DIAGRAM TO MAKE THE TOOL, MAKE A NOTE UNTIL THE TM IS UPPATED. PS 607



.250 Dia.

219

.350 Dia.

# STRAPPED FOR TIME










#### Dear Rotor,

Banged-up knuckles show up first when mechanics work with tools in tight places on an aircraft. That's bad enough, but factor in the extra time it takes to maneuver a tool around in cramped space and you really get the picture.

Many Black Hawk cannon plugs require plug pliers to remove the plugs. In tight spaces, the pliers are ineffective in tight spots, and are almost impossible to use. And it takes a long time to loosen a plug.

But we've come up with a cannon plug strap wrench that can be a useful work aid in removing plugs much easier and faster without the bruised knuckles and wasted time.

Here are the plans to make the tool:





After the tool is made, make the strap from 6 1/4-in of webbing strap, NSN 1680-00-967-1821.

- 7. Fold one end of the strap over and sew it so it's approximately .125-in thick. Burning the other end prevents unraveling and eases installation.
- Insert the thin end in through the .188 slot and bring it out through the .125 slot.
- 3. Once it is started through the .125 slot, pull until the sewn end is through the .188 slot. Pull strap tight until the sewn end is nested clear of the .188 slot.

Use the strap wrench by wrapping the strap around the cannon plug and feeding the end of the strap through the .188 slot. Then pull it tight. Turn the wrench counterclockwise to loosen the plua. Be careful not to damage receptacle pins.


> Sgt Andres Chamorro Jr. MA Army National Guard





Great tool! That's a wrap for this problem. Rotor Blade


JUNE 03 PS 607 37



Chinook repairers, tie bar pins are **not** like a Timex. They can't take a lickin' and keep on tickin'!

So don't pound them in! Tap, tap, tap lightly is the way to go when you install tie bar pins into the rotary-wing head, like it says in Chapter 5 of TM 1-1520-240-23-6.

You have to remove the tie bar pins from the pitch housing and the hub shaft to visually inspect the tie bar. To replace pins, place the phenolic drift on the outer rim of the pins and tap in lightly with a soft mallet.




Damaged pin can't be used





JUNE 03

If you pound on the tie bar pins instead of tapping on the pins, you can misalign the pins and they won't seat properly in the pitch housing and the hub shaft. Then the retaining washer won't seat properly on the pin in the hub, either. You'll wind up with damage to the rotary-wing head and the pitch housing.



Also, make sure you never tap on the inner surface of the pins, either. That'll push the inner portion out of tolerance. Then you'll have to replace them. If the pins are dropped on a hard surface, forget about tapping on them, too, because the pin's outer circumference will be flared out.



KEEP IN MIND
THAT BEAT-UP
PING COST YOU
ABOUT \$63 A POP
TO REPLACE, \$0
TAP 'EM, BUT
DON'T BEAT 'EM
IN, THAT'S THE TM
WAY TO GO,

PS 607 38



techs, if you've noticed visible light coming from the housing of a SDU-39/N distress marker strobe light, you have a defective infrared red (IR) housing.

Inspect the light marker data plates for NSN 6230-01-411-8535 or NSN 6230-01-448-8340, and contract numbers SPO500-98-D-2710 or SPO560-00-F-0162.


If you have any of these light markers, request replacement housings by calling Ann Schrage, Defense Supply Center Philadelphia, at DSN 444-8103 or (215) 737-8103, or email her at

#### aschrage@dscp.dla.mil.

Include in the request your unit, number of replacement housings needed, unit identification code, applicable NSN and a mailing address with a POC.

When you receive the replacement housings, remove the defective housings and return them to:

Industries For the Blind 6350 Burnt Poplar Road Greensboro, NC 27409-9710



Install the new housings on the body like it says in PM ACIS message (AIS02-02) and test for light leakage at all angles. If no light leaks, you're good to go. Check out all the details in the PM ACIS message.



Grew chiefs, "look out below" might be what you'll holler if you lose the left hand crew jettison door when your Kiowa Warrior's .50-cal gun is fired.


You can keep the door in place by performing a thorough pre-flight inspection first, like it says in TM 1-1520-248-10 and AMCOM maintenance information message 98-MIM005.

Make sure the jettison rod extends through the door hinge halves at least ½ inch and that the jettison release handle safety wire is secure prior to .50-cal gun firing missions.

If the safety wire is missing, or the rod isn't extended properly through the hinge halves or the pin is not in place, vibration will work the door mechanism free. Then the door falls off the aircraft as the gun fires.

Also be sure not to use the jettison handle as a handhold or a handrest. If that happens, you could accidently jettison the door.

So don't let another door bite the dust. Pre-flight your bird before you take off and inspect the door mechanism like it says in TM 1-1520-248-PPM.



PS 607 40 JUNE 03 PS 607 41 JUNE 03

# LOW BATTERIES & BLOWN FUSES


THERE ARE SOME NEW KIDS ON THE BLOCK WHEN IT COMES TO LARGE TACTICAL QUIET GENERATOR (TQG) SETS, THESE KIDS ARE EQUIPPED WITH DIGITAL CONTROL SYSTEMS (DCS).

WE'VE NAMED THESE KIDS THE MEP-805B (30-KW, 50/60 HZ), NSN 6115-01-461-9335; MEP-815B (30-KW, 400 HZ), NSN 6115-01-462-0290; MEP-806B (60-KW, 50/60 HZ), NSN 6115-01-462- 0291; AND MEP-816B (60-KW, 400 HZ), NSN 6115-01-462-0292.



These new guys are pretty cool, but like all kids, they can be a bit cantankerous at times. One of those times is when the charge on the batteries is low.

When the batteries are low (from excessive cranking and not starting and operating the generator on a regular basis) and in need of a charge, operators reach for the NATO slave cable and get a battery boost from their vehicle.



CRUNK switch in the CRUNK position, the K2 relay coil is enagriced to initiate engine cranking without energizing any other starting The generator set can be started without batteries by connecting an external 24 VDC power source to the NATO/SLAVE RECEPTACLE The generator set can also supply power to another set through the NATO/SLAVE RECEPTACLE. The batteries are charged by the battery charging alternator which is belt driven by the engine. The CIM display screen BATTERY

So far, so good. But when the slave cable is removed and the generator is started, the 30 AMP in-line alternator fuse blows! The fuse will blow as soon as the battery charging alternator has an opportunity to charge the batteries. According to the digital readout on the display panel, 50-60 AMPS are pulsating through that fuse. With that much amperage, the fuse is going to do its job and blow. Then your generator is down for the count.

#### **Keep Extra Fuses**

If you're operating one of these new DCS TOGs, keep extra fuses, NSN 5920-00-644-0366, on hand.


(If you are in an emergency situation, you can jump around the fuse with some 16-gauge wire. Or run a second 30 AMP fuse in parallel with the first from the positive side of the battery to the positive side of the alternator. For safety reasons, neither of these are recommended as permanent fixes, though, and the generator should be restored to the single in-line 30 AMP fuse when the emergency has passed.)

Check for an ECP that increases the size of the wire to safely carry the full potential output of the battery charging alternator—it's rated at 45 AMPS continuous and replaces the fuse with a 50 AMP slow blow circuit breaker. It also moves a wire so the batteries won't be drained if the fuse or circuit breaker should blow on start up. This should permanently fix the problem.

When these new generators arrive at your unit, bone up on the info in their TMs. TM 9-6115-671-24P handles the 30-KW and TM 9-6115-672-24P takes care of the 60-KW. They also have operator's manuals, TM 9-6115-

IT'S ALSO A GOOD IDEA TO CONTACT YOUR LOGISTICS ASSISTANCE OFFICE (LAO) AND GET A CECOM POWER GENERATION LOGISTICS ASSISTANT REPRESENTATIVE (LAR) ON THE JOB.

WE LARS WILL KNOW





JUNE 03 PS 607 42

# TQG DIPSTICKS







When your
tactical quiet
generator engine
oil dipsticks take
a walk, here are
the NSNs to order
new ones

r t	Generator	NSN 6680-01-
•	5-KW	457-8680
٤	10-KW	472-8495
٩	15-KW	472-9712
r	30-KW	363-0501
	60-KW	363-0501


# PARTS PARTS

HERE'S A QUICK-REFERRAL LIST OF AN/PSN-11 PRECISION LIGHTWEIGHT GPS RECEIVER PARTS...

Item	NSN			
AS-4333/V remote antenna	5985-01-375-4660			
Remote antenna cable	6150-01-375-8662			
Personnel carrying case	5895-01-375-7528			
Lithium power battery	6135-01-440-7774			
AA alkaline battery	6135-00-985-7845			
Lithium memory battery	6135-01-301-8776			
AC power adapter	6135-01-376-2168			
Vehicular mount	5975-01-375-1302			
External power cable	6150-01-375-8661			
PLGR-to-PLGR cable	6150-01-375-8663			
Personal computer cable	6150-01-375-8664			
AA battery holder	6160-01-385-4358			

JUNE 03

# SICUS OF SAFFIY



Legend: Caution	NSN 9905-
Hearing Protection Required	01-100-8205
Hearing Protection Required in this Area	01-031-1247
High Noise Area Wear Ear Plugs	01-122-1140
Eye Protection Required	01-100-8203
Do Not Operate Without Eye Protection	01-100-8204
Highly Flammable	01-054-0428
Watch Your Step	01-054-0450

The **Highly Flammable** sign also comes in a smaller size, 7 x 10 inches, with NSN 9905-01-054-0427. One more 7 x 10 inch sign you might need is **Wear Goggles When Using This Machine,** NSN 9905-00-956-6324.

If you have noisy gear that requires a black and yellow noise caution plate, order it with NSN 9905-00-198-2728. The sign is 4.6 x 2.13 inches and has an adhesive backing.

Check out the US Army Safety Center's Safety Color Code Markings, Signs, and Tags Information Guide, February 2003. The guide provides a list of references for specific commodities, hazardous materials, and operations. The guide is not in electronic format, but you can obtain a printed copy by calling DSN 558-2062 or (334) 255-2062. Or send an email to: ForehanS@safetycenter.army.mil.

## 26-Pair Cable Connector NSNs



HERE ARE A
FEW OF THE
NSNS YOU NEED
TO ORDER
REPAIR PARTS
FOR CABLE
CONNECTORS...

**Part** NSN Electrical contact assembly 5999-00-823-3262 Hock cover 5935-00-883-4265 4010-00-575-6233 Wire rope Swaging sleeve 4030-00-431-5536 Hock gasket 5935-00-542-1433 Hock rubber boot 5975-00-874-3541 Contact cap kit 5999-01-073-5507 (enough for 10 connectors) Electrical tape 5970-00-685-9059

45

JUNE 03

# WHY THE "Y" BATTERY ARTICLE?








The wet battery for the 5-KW generator is the 2HN, NSN 6140-01-390-1969. The dry battery for the 5-KW is NSN 6140-00-057-2553.

The battery for the 10-KW is the Optima 800/U, NSN 6140-01-457-4439. This is a sealed, lead-acid battery that is virtually maintenance free.

The 6TMF and 6TLFP are vehicle batteries, not generator batteries.



We were right when we said the 6TN and the 6TL are no longer available for your generators, but then you probably knew that before we did the story!



No one knows modification work orders (MWOs) like the Modification Management Information System (MMIS). And now you can know what they know by visiting their secure web site at: https://www.mmis.army.mil

Once there, click on the Login Request form icon and apply for a password.

Once you have your password, you can find MWOs—emergency, urgent or routine—by entering an equipment model number or its UIC or its serial number. Additionally, you can determine the MWO status of your serial numbered equipment end-items—which MWOs are applicable, which one have been applied, and which ones remain to be applied.

So far, the only MWOs on the site are those applied by an equipment program manager, an AMC major subordinate command or a MACOM MWO coordinator. So your equipment may not be there.

If it's not, then its MWO data has not been reported. You can remedy that situation by submitting MWO information on your equipment through the MMIS on-line reporting module or email it to:


#### MMIS@calibresys.com

If you have questions about MMIS, contact Elizabeth Bieri, HQDA, at (703) 614-3895, DSN 224-3895 or email her at:

#### Elizabeth.Bieri@hqda.army.mil

The MMIS web site has been established as the official Army MWO database by the new AR 750-10, Army Modification Program.

PS 607 47 JUNE 03





• Heat is murder on camouflage screens. They can melt or even burn if they touch anything hot, like a space heater or exhaust pipe.


Prevent this by cutting the screen and folding it back away from the hot pipe. Leave at least 8 inches between the pipe and screen edges. Make sure you repair the screen after it's removed from the vehicle or heater.

Keep screens out of artillery back blast areas, too. The screens are no match for that heat and power.

• Never spread screens right on top of equipment. Sharp corners, armament, bumpers, antennas, exhaust stacks and the like will rip them before you know it. Use batten spreaders to keep the screen away from sharp edges.








The batten spreaders for woodland/desert camouflage come with NSN 1080-00-108-1545. You'll also need an adapter, NSN 1080-00-108-1595, to connect the spreaders. For winter use, NSN 1080-01-073-3196 brings a batten spreader for LCSS snow camouflage. NSN 1080-01-081-1022 gets the adapter.


• When using aluminum stakes to tighten screens, be sure the stakes catch only the screen's edge cord. Screen material wrapped around the stake will tear.

Need new stakes? NSN 1080-00-108-1654 brings a stake for LCSS woodland/desert camouflage. In winter, use NSN 8340-01-075-4017 for an LCSS snow camouflage stake.

• Keep aluminum poles smooth by filing off any nicks or burrs with a metal file, NSN 5110-00-242-5384. They'll go together easier and won't snag the screens. The poles will also mate easier and weigh less if you keep mud, sand, dirt and other crud out of the ends. Wash and dry the poles before storing them.



- The poles aren't made for heavy lifting jobs, so don't use them as pry bars. They're for holding up screens—period.
- Before striking a screen, clear the ground underneath of all sharp objects, like stones and sticks. Otherwise, you'll end up with a torn screen when you fold it for storage.
- Keep screens clean by washing them in water with a mild detergent, NSN 7930-00-252-6797. Rinse the screens in clean water, then spread them out to air-dry.



• Operators should mend rips or tears as soon as they occur. That keeps the holes from getting larger and making the screen unserviceable.



Repair kit

Repair kit

Repair kit

NSN 1080Radar scattering, desert (Type II, III & IV)
Radar scattering, snow (Type IV)
Radar scattering, woodland (Type II, III & IV)
Radar transparent, desert (Type I)
Radar transparent, snow (Type I)
Radar transparent, woodland (Type I)


Radar transparent, woodland (Type I)

O0-107-8563

CHECK OUT TM 5-1080-200-13&P, LIGHTWEIGHT CAMOUFLAGE

SCREEN SYSTEMS AND SUPPORT SYSTEMS, FOR MORE INFO
ON MAINTAINING YOUR CAMOUFLAGE SCREENS.

PS 607 49 JUNE 03



"THERE ARE TWO PLACES THE WIRES GET CROSSED: AT THE CIRCUIT BREAKER UNDER THE RADIO SPEAKER OR AT THE BATTERIES."


"AT THE CIRCUIT BREAKER, THE #17 WIRE SHOULD GO TO THE 12 VDC BREAKER AND THE #10 TO THE 24 VDC. SEE THE WIRING SCHEMATICS THAT CAME WITH YOUR BEOD."




1. Disconnect batteries to prevent damage or injury.

- 2. Disconnect the #17 and #10 wires.
- 3. Connect the #17 wire to the 12 VDC breaker.
- 4. Connect the #10 wire to the 24 VDC breaker.

"AT THE BATTERIES, THE #I7 WIRE SHOULD BE ATTACHED TO THE POSITIVE TERMINAL OF THE 12 VDC BATTERY (THE ONE ON THE LEFT) AND THE #I0 TO THE POSITIVE TERMINAL OF THE 24 VDC BATTERY. IF THEY'RE NOT, RECONNECT THEM."






IF THE REAR ELECTRICAL OUTLET IS PUTTING OUT 24 VPC INSTEAD OF 12, THERE COULD BE A SHORT IN THE INVERTER.

CHECK THE VOLTAGE
WITH A MULTIMETER. IF
THE INVERTER IS BAD
AND IS STILL UNDER WARRANTY, CONTACT THE
MANUFACTURER ABOUT A
REPLACEMENT.

THE MANUFACTURER'S APPRESS AND PHONE NUMBER ARE LISTED IN THE BEOD COMMERCIAL MANUAL.






The two engines used with the M17 decon use different spark plugs. If you use the wrong plug, the engine runs poorly.

The JLO engine uses Champion RL87YC spark plug, NSN 2920-01-072-3380. Its thread is 1/2 inch long. The Cuyuna engine uses Champion RN3C spark plug, NSN 2920-01-142-3174. Its thread is 3/4 inch long. The ID number is printed on the plug's porcelain insulator.

An easy way to tell which engine your M17 has is to look at the fan guard. The JLO engine has a silver fan guard and the Cuyuna has a black guard.

52






IF YOU HAVE BOTH ENGINES IN YOUR CHEMICAL COMPANY, MAKE SURE YOU KEEP THE DIFFERST SPARK PLUGS SEPARATE IN BOXES MARKED JLO AND CUYUNA.

PS 607





#### Dear Editor,


The M17-series decon's burner is designed to run on all kinds of fuels, including diesel and MOGAS. But we've discovered that if the burner sees nothing but diesel, eventually its fuel valves will gel up. Then you won't be heating much water or doing much deconning.

MOGAS is the answer. If you run MOGAS through the burner at least

25 percent of the time—one can of MOGAS for every three cans of diesel—the fuel valve won't plug up. Remember, you need to use MOGAS at least part of the time for PMCS, too.


It's also good to get all the diesel fuel out of the burner at shutdown. The best way to do that is to run MOGAS through the burner for 5 minutes and then shut down normally. The burner pump will purge the diesel fuel.

MSG Kenneth Graham SGT Ramon Perez SPC Yonelvi Alvarez 21st Chemical Co Ft Bragg, NC



PS 607 53 JUNE 03

## MAKING NEW ENGINES FIT



When we replaced the JLO engines in our M17 decons with the newer Cuyuna engines, NSN 2805-01-356-3654, the Cuyunas didn't fit right. The new engine was about 1/4 inch different in size, which caused belts to wear out fast. Is there anything we can do about this so we don't have to keep replacing belts?

SGT L.C.

Dear Sergeant L.C.,

You can't slide the old JLO engine out and simply replace it with the Cuyuna. To mount the Cuyuna you need the engine mounting kit, NSN 2805-01-357-6566. The kit contains a new engine mount that takes care of the 1/4in mounting offset. It also contains hardware, wiring and a transformer to manage the Cuyuna's higher alternator output of 37 VAC. If the transformer is not installed between the alternator and the electronic control module. the high voltage will damage the module.



Half-Mast

NO BURNER, HO MISSION IT SAYS RIGHT HERE, I'M GOOD THAT'S TO GO EVEN IF WRONG! MY BURNER IS AND SO BURNT OUT! ARE YOU! YOU'RE NMC!

Dear Half-Mast,

TM 3-4230-228-10 doesn't mention anything about the M17 being deadlined if its burner doesn't work. But you can't decon very well without hot water. Is this a mistake?

Dear Sergeant R.M.,

Yes, it is a mistake. SBCCOM Maintenance Advisory Message 02-11 stated that the M17 is NMC if the burner doesn't work. The next change to the -10 will add this information. Thanks for pointing this out.

SGT R.M.

M41 Protection Assessment System... YOU'RE THAT SOFTWARE THEY'RE TRYING TO SELL TO NBC NCOS! G'WAN! GET OUTTA HERE! I DON'T NEED Needed YOU! I COME WITH ALL THE INSTRUCTIONS I NEED!

Do you NBC NCOs need the software and printer offered by the PATS manufacturer to effectively use PATS? Absolutely not.

The software, which isn't authorized by the Army, repeats information on using PATS that's already on the video or CD that comes with PATS and explains how to use it. If you don't have the CD, contact SBCCOM's David May for a copy. Contact him at David.May@SBCCOM.APGEA.army.mil or (410) 436-5926/DSN 584-5926.

The software also lets the user change the PATS pass/fail level, which could be dangerous if PATS passed a mask that didn't fit properly. PATS is set at the factory for a pass/fail level that makes sure the soldier will be protected by his mask.

The printer for PATS simply isn't needed.

So save your money, NBC NCOs. You've got all you need to use PATS without additional software and a printer.

JUNE 03 PS 607

# 

THE FOLLOWING
ARTICLE DESCRIBES
THE ARMY KNOWLEDGE
ONLINE PORTAL AS
PRESENTED BY THE
INTERNET EXPLORER
BROWSER.

IMAGINE HOW HANDY IT
WOULD BE TO HAVE YOUR OWN
PERSONAL LIBRARY, A PLACE
FILLED WITH INFORMATION
ABOUT THE ARMY, YOUR
CAREER, EDUCATION, FINANCES
AND BENEFITS,

WELL, NOW YOU CAN HAVE YOUR OWN LIBRARY AT YOUR FINGERTIPS,


IT'S CALLED **ARMY**KNOWLEDGE ONLINE
(AKO), AND IT'S AS CLOSE AS
A PERSONAL COMPUTER AND
THE WORLD WIDE WEB.



#### Set Up an Account

To access the AKO home page, go to:

https://www.us.army.mil



Once there, you'll need to register for an account. Click on <u>I'm a New User</u>. Enter the required information and submit it. After your account is activated, you can go back to the home page and sign in using your user name and your password.


#### **Gateway to the Army**

AKO is known as the Army Portal. It's a gateway with many links leading straight to information, services and online tools—all of it geared to you, the soldier.

Here are some of AKO's basic features:

- Channels, or small windows, that group similar kinds of information.
- Personal Pages that you create to fit your needs.
- Email and Instant Messenger.
- Search Engine that focuses on the .mil domain.
- Online Tools and Storage Space.

#### World of Knowledge



One feature in particular can open up a world of knowledge for you. It's the Reference drop-down menu, located under "AKO Services" in the left-hand column on the home page. The menu has links to news articles and commentary about defense, travel regulations, legal services, desktop tools, pay rates and more. You'll find it especially helpful if you work in maintenance or supply. It's your doorway to web sites for publications, forms, Army regs, schools, education and careers.



#### **Publications and Forms**

Here's a closer look at finding publications, regulations and forms through AKO:

Open the <u>Reference</u> drop-down menu under "AKO Services." You'll see a number of links.

- Click on the <u>Pubs & Forms</u> link to find
   —Official DA, DOD, GSA and OPM forms.
- —Doctrinal and training, engineering, medical, and technical and equipment publications.

Direct links to electronic publications and forms

Official Department of the Army Publications and Forms

Official Department of Army (DA) publications and ferms are managed by the Army Publishing Directorate (APD) under the direction of the Administrative Assistant to the Secretary of the Army (AASA). The Army uses the latest unbising bethonologies to produce beity admissible enhanced, electronic publications and forms. This is the latest collection of electronic Army publications and DA forms.

Administrative
Technical Doctrine
and Equipment and Training
Engineering Medical
Efforms Ordering System

- Manuals links you directly to field manuals in the General Dennis J. Reimer Training and Doctrine Digital Library.
- <u>Libraries</u> links you to the Army Library Program and the Military Reading Room. From there, you can track other links to reading lists, E-Journals, Army newspapers, newsletters and publications such as Armor, Army Aviation, Army Logistician, NCO Journal, Signal, and PS, the Preventive Maintenance Monthly.
- The <u>Regulations</u> link takes you to a web page for administrative publications, including Army regulations.

# Career and Education

Open the <u>Reference</u> drop-down menu under "AKO Services." Click on <u>Education</u>. It takes you directly to the US Army Education home page. Next, open up <u>Links</u> on the top right-hand side of the page for a variety of educational opportunities:

AND HERE'S

A LOOK AT

AKO LINKS TO

CAREER AND EDUCATION

WEB SITES ...



- eArmyU.com. Web-based distance learning programs to help soldiers get a certificate or degree when traditional classroom courses are unavailable. Programs include technical, undergraduate and graduate courses.
- The Army Correspondence Course Program.
- goarmy.com. Military Occupational Specialties, and the major duties and the training required for them.



- TRADOC. Links to all the TRADOC schools, including Armor, Engineer, Field Artillery, Infantry, Intelligence, Signal and Transportation.
- The Army Distributed Learning Program, which includes MOS qualification courses.
- Servicemembers Opportunity
   Colleges Army Degrees (SOCAD) Army
   Careers Degree Program. Learn how to translate your Army training into college credit.





#### • Money For College

Scholarship programs and financial assistance for education.


#### Credentialing

Learn how to meet civilian occupational certification and license requirements related to your MOS.

#### • Earn a Degree

Transcript service, basic academic skills training, college credit for military service, earning a high school diploma.







# **BLADE MOTOR**

Use NSN 6105-01-502-9448 to order a new lifting motor for your mine clearing blade. This motor has been tested and approved for use as a replacement for the current motor, NSN 6105-01-277-0295. You'll get the new motor faster.

#### OE-254/GRC Mast Section NSN

Mast section, NSN 5985-01-072-8066, is now NSN 5985-01-324-3463. Many of you are still ordering under the old NSN and entering an advice code of 2F—"obsolete. but still required." Stop it! Your request will just be rejected. Use the new NSN and the mast sections will come your way.

#### PS 607

# should be NSN 5935-01-109-7541.

M1-SERIES TANK

CANNON CLEANING

TFF RADAR TEST SET

7194, in Sep 04 as free issue test equipment.

If you have questions about the test set, con-

tact AMCOM's John Fields at DSN 987-2934.

john.fields@redstone.army.mil

ROWPU Hotline

If you have questions about the operation,

maintenance and logistics support for the

600-GPH and 3,000-GPH reverse osmosis

water purification units (ROWPUs), write to

WaterSystems-ROWPU@tacom.army.mil

**UH-60** Engine Control

Quadrant Update

The connector plug (P105 & P106), NSN 5935-

01-108-4483, shown on the control box parts

list on page 39 of PS 601 is incorrect. It

the ROWPU's Hotline e-mail address at:

医 基

19th

(256) 313-2934 or email

#### M1-SERIES TANK LRUS

Before storing or shipping line replaceable units (LRUs) from your M1-series tank, check to see if it has a shipping container. These specially designed containers prevent damage to expensive LRUs. A quick look at the parts manual is all it takes. Then order a container if the right one's not on hand.

#### UH-60 External Fuel Tank Access Panel

Mechanics, Fig 122, Item 24 of TM 1-1520-237-23P-5, lists the wrong screws (NSN 5305-00-137-3043) to mount the external fuel tank access panel. The correct screw is NSN 5305-01-343-1185. Make a note until the TM is updated. 

#### FIBER OPTIC CABLE

Order 300 meters of CX-13295/G fiber optic cable with NSN 6020-01-220-5435. Order 1,000 meters with NSN 6020-01-208-

#### **AVLB** Engine

Use NSN 2815-01-166-2051 to order a new engine and container for your AVLB. The NSN shown for Item 1 in Fig 1 of TM 5-5420-202-24P and TM 5-5420-226-24P is no longer available.

#### UH-60 Cargo Hook Impulse Cartridge

Need an NSN for the Black Hawk cargo hook impulse cartridge? Order NSN 1377-01-211-7211. The current cartridge, NSN 1377-01-254-1683, is no longer available in the supply system.

#### BRADLEY TURRET JAMS

Clean up brass cartridges from the catchers and the floor at every opportunity. Bradley crewmen in Iraq have had several turrets jammed by loose brass. Not good when you're engaging the enemy

#### No Annual ACADA Wipe Test

Unlike the CAM/ICAM and M8A1 chemical alarm, the M22 ACADA does not need the annual wipe test to check for radiation leaks. The ACADA needs to be wipe tested only when the radioactive source module is removed from the source assembly. And that can be done only at depot. So do not turn your ACADA into support for a wipe test. It's

DISTRIBUTION: To be distributed in accordance with the initial distribution number (IDN) 340312, requirements for TB 43-PS-Series.

## Would You Stake Your Life # the Condition of Your Equipment?

For Sale by the Superintendent of Documents, U.S. Government Printing Office nternet; bookstore.gpo.gov Phone; toll free (866) 512-1800; DC area (202) 512-1800

