## HELICOPTER Ground Guide Signals

**Note:** When directing a taxiing helicopter, the signalman's position is slightly to the right, in full view of the pilot, at a safe distance of no less than 40 meters (or no closer than 20 meters during slingload operations). The signalman should *never* stand in front of an armed helicopter.

