

1956 Series

PS

Issue 43

THE PREVENTIVE MAINTENANCE MONTHLY

FROM 1956
THE AIR-CONDITIONING SYSTEM
IN 1956



AN
SHADDERY

IT'S
SHADDERY
HERE

WINTER
YOUR
OWN
SPRING
IS
HERE

Here's How On Your New—

100-AMPERE AC CHARGING SYSTEM



JUST WHAT I
NEED!
THE 100-AMPERE
AC CHARGING
SYSTEM!
YES!

SHUT UP! SHUT UP!
PLEASE! I'M
NOT JUST
ANY CHARGING
SYSTEM!




Everybody who has to keep a constant radio contact from a jeep or command truck or command carrier has been screaming for a bigger capacity charging system to keep their batteries up. So it's on the way.

The new 100-ampere, modified AC charging system is being installed on original equipment in the M39 command personnel carrier, and will be installed in the new M39 Commando's jeep, command trucks and other vehicles which are required to keep constant radio contact.

This system is different from any battery charging system now installed on military vehicles. Instead of a bigger DC generator, it uses an alternator which puts out alternating current. They chose the alternator because it offers several advantages over the direct current generator.

In the first place, an alternator can be built which has a 100-ampere capacity and is only slightly larger than the Thompson generator it replaces. Also, the alternator has lower output at low RPM's, so it can keep your batteries up and supply your radio when the engine is idling or running slowly. This is just what you need when you are standing ready waiting for orders. Another thing, when the alternator has



surplus slip-rings instead of commutator bars or many segments like the rotor, you don't have any extra resistance to overcome, and brushes will last longer on the smooth slip ring. And the brushes do not dirty the whole 100-ampere system as they do on a generator, but only the field current. When they are wearing too much, they naturally last longer.

Of course, you're not going to do anything, so the AC system does have a couple of disadvantages. The main one is that you can't charge a storage battery with an alternating current. So you have to have something to switch it on the back and forth between from the alternator output and get them all loaded the same way as your battery.

That's what has to be added, so it is installed just in front of the radiator on the 14 and 16-ton vehicles where the air stream cools it. Unfortunately, it isn't the only thing that cools the radiator—in fact any mud you happen to run through. If you run the radiator when it is covered with mud or dirt, it can get too hot and burn out, so wash the radiator when you wash the vehicle.

But the many advantages of the system far outweigh the few disadvantages. So, let's look at what you've got. First of

all there is the alternator. This looks much like the generators you are used to. It is belt-driven from the cooling fan pulley of the HSC and from the crankshaft pulley of the other vehicles. You may notice that, unlike the completely sealed 24-volt waterproof generators, the alternator has a fan and fan air holes which permit cooling air to pass through the machine. However, it still can go under water. It may stop charging for the time you actually have it under water, but it will pick right up again when you come out.



ALTERNATOR

Out of the alternator comes a distilled battery with plug-in connections covered down just like the direct current generator. This battery runs to the rectifier. The rectifier is mounted ahead of the radiator and in the cooling air stream, both in the HSC and in the wheeled vehicle line.



BATTERY

Another waterproof and distilled battery comes from the rectifier and runs to the voltage regulator. The voltage regulator is a sealed box with the carbon pile in a casing as well. From the regulator a third battery runs to the battery and also feeds on the vehicle.

This system is durable. Generally speaking, it won't give you any trouble unless you give it a hard time. But there is one thing it will not stand behind for—if you put either your batteries or a drive cable into this system backwards—if you reverse the polarity of the battery your rectifier and regulator are gone!

That's gone means there is no reverse current cutoff in this system. The rectifier serves as positive battery current running back to the alternator. So if you bank the battery up backwards there is no protection, and full battery current goes flooding through the alternator and the rectifier. This kills the rectifier right off and causes a short circuit across the battery terminals through the load relay contacts.

But outside of getting it up by mistake once, this system is pretty rugged as long as you keep the rectifier clean. However, no machinery runs forever, so here's how you think it out, just in case it does let down on you.



VOLTAGE REGULATOR

The second-circuit maintenance on this system is just the same as on the direct-current system, with one exception. In other words you only test to find out whether the three units, alternator, rectifier or voltage regulator is bad, or which feature is faulty, and replace the unit. You are authorized to set the output voltage on the voltage regulator. Move along, this time.

Remember that you have a baggage with this system installed and you think it's not working. Either you are having trouble starting or your battery indicator does not go over into the green when you run your engine.

There are two ways you can check this system, depending on what equipment you have at hand or can get. The simplest and the most sure way the first method—call for an AC/DC voltmeter which is carried under Federal Stock No. 11-V-406. This meter recently became a part of the second-circuit test kit. If you have lots of vehicles

equipped with this AC system, your Christmas supply store may be able to pry one loose for you. Or you may be able to borrow the loan of one from the common section of the fire-control boys. The other way is with the low-voltage circuit tester.

For those having only low
Voltage Circuit Tester

117-5-1573-500 jump to page 12.

See page 29 in this book for
more on the voltmeter.



CHECKS WITH VOLT-OHMMETER



Now, assuming you have such a voltmeter here's how you can use it to check the system out. (Later, we'll get down to how you do it with the low-voltage circuit tester.)

You start by making a battery check. With the meter set for 50 volts, DC, you connect the leads to the three terminals of your MFI, or from the meter post to ground on your wheeled vehicles. (If working on an M17 and M41 you can make this check faster by hooking up to the battery directly, which means they can have the meter right inside them in the cab.)

First of all you read off the battery voltage with no load. (Remember to turn on the master switch in the MFI's.) This will be close to 14 volts, no less than 13. Now crank the engine with the starter, with the ignition switch off for not over 30 seconds. Watch the meter. The voltage should not drop below 18 volts. If it does, replace or exchange the batteries and get on from there.

Next, you turn the ignition on and start the engine. The voltage will either come back to your first reading, battery voltage, or it will rise to a higher level. If it comes up to 27.1 volts, your system is OK. If the voltage comes up above battery voltage but is greater than 28 volts or less than 27.5 volts, the system is working, but the voltage needs adjusting.

In order to properly adjust the regulator, run the system for 15 to 20 minutes with the headlights on to provide a load. You



make this regular adjustment by way of the plug in the voltage regulator box. On the M50's you take out the plug on the side of the control box and look in. You will see a threaded shaft, into which you fit a screw driver. Turning this shaft, which controls the voltage adjusting rheostat, clockwise will increase the voltage. Turning it counterclockwise will decrease the voltage. On the M55's, adjust voltage with the master switch open.

On the M57's and some other vehicles equipped with the 180-ampere AC/DC system, the regulator box also has a plug in the cover, removable with a wrench. Looking down this hole will reveal a black knurled disk which is on the shaft of the rheostat. Use a small screwdriver to turn the disk.


As installed on the M77, you would turn the top of this disk to the center of the vehicle to increase voltage, upward to decrease it. If you find that by this adjustment you cannot get the voltage at 27.5 your troubles lie over, below things down and take off.

But if the voltage shows on your meter does not climb above battery voltage when the engine is running, or drops out when you open the master switch, it means you have some sort of trouble in your system, and you've got to hunt it out.

First of all, you make a visual check. Do over the belts are not loose or broken, and that the alternator is working. Then kill the engine and check for loose hardware—all the connections tight? Take a good look at the cables—has there any burned or corroded points? Any bent or obviously damaged points? Anything you find by looking, you correct, of course. If this doesn't cure your troubles you have to go on into the meter checks.



With the meter still set on the 50-volt DC scale you disconnect the regulator to battery harness at the regulator. Check from contact "A" to ground. This should show you battery voltage.



Now connect a jumper from contact "A" to contact "B", turn on the ignition switch and check from contact "F" to ground. The jumper isn't necessary on MFI. Just check "F" pin to ground. This also should show you battery voltage, or nearly so. If the fuse has malfunctioned then the battery harness is OK, and then the circuit which is controlled by the ignition switch is also OK. If not, of course, you run your trouble down in this circuit.

Now while the regulator, or battery harness, is disconnected, you can make Ohm's meter test of the regulator. With your meter set on the "RX100" scale you check like this:

Pin "F" to pin "C", has resistance, 175 to 18 ohms.



Reverse regulator to verify battery check by repeating regulator harness disconnection. With your meter set on RX1 scale check like this:

Socket "A" to socket "D", has up control as usually checked in position—approximately 50 ohms. With voltage control set in fully restricted position—approximately 21 ohms.


Socket "C" to socket "E", voltage pin, approximately 11 ohms.



Any place you don't get the reading that's indicated for it, you've spotted a trouble spot.

If you get the above readings from your regulator, chances are excellent that it is OK and your trouble is elsewhere.

If you now remove the regulator to another harness from the meter, pin, and by using your Ohm's meter check the harness for open circuits.



Now from pin "A" to socket "C", use one wire with the meter on "RX100" scale. You should read approximately 100 ohms. (On these models this will be open circuit—reading "infinity").



Check through "F" as second to socket "C" as the above, from pin "D" to socket "E" and so on. You should not get any resistance indication in any of the circuits. On vehicles which use the meter on the "RX100" scale, check from each pin to the meter shield, and from each pin to the others. You should get infinite resistance (no reading) on all checks. If either of these tests indicates a faulty harness, replace it.

Things you do now to your meter. Disconnect the meter on alternator harness from the meter, and check the meter box as follows.



With the meter on the "RX100" scale, connect the red lead (+) to the "D" pin on the meter to regulator side and touch the other lead to each of the three large sections on the meter to alternator side (contacts "A", "B", & "C"). You will get high resistance reading 100 to 150 ohms. If you get a resistance of more than 21 ohms, your meter may be faulty.

This checks half of the circuit. On the other half place the black (-) lead on pin "C" (right on regulator side and touch the other lead (+) on each of the three large sockets on the regulator-alternator side sockets "A", "B" and "C". You should get the same reading.

Before passing the meter on OK, check the belt drive through it. From small pin "B" to socket "D" and from small pin "B" to socket "E" you should have an approximate resistance. While you cannot repair the rectifier, you can check this check for loose wires, also in engine shop of two jumpers (connecting them one connector right next to the other one).

Your next step is check out the rectifier-alternator harness (as you did the rectifier-alternator harness. It has all five leads are OK, and that there are no shorts. (Usually, the thing that happens is nearly certain.) Unless you can see evidence of current damage (100 to 1 they are OK, but it's usually a good to check and be sure.

Now you have come down to the alternator. This should check out like this. Pin "D" to pin "E" approximately 1 ohm. This is the rotor and stator. However, since you are checking through the brushes and the slip rings, any reading from 1.2 to 5 ohms is probably OK. Now from any one of the big pins "A", "B" or "C" to the others, you should have no measurable resistance. With the meter on "DC 500" scale, take a resistance check from each pin to the alternator ground. The reading should be infinite.

Somewhere along this list of checks you should have to find out that the system will work. However, the point of the pulling comes when you look everything up again except the alternator. While running the meter on the ignition switch, listen carefully to the regulator box. You should have the belt ring alone. Now check with your meter on the 10 volt DC scale and see if you get approximately battery readings (between small

voltage "D" and small voltage "E" at the alternator end of the alternator-to-rectifier harness. Kill the engine and finish connecting up, being sure all the connections are right. Start your engine and run it at about 700-800 RPM.

With your meter on the 10 volt AC scale, check from each of the three AC connections on the rectifier to the other two. I follow this on the connections, close together on one side of the rectifier, in front on the wheeled vehicles.)

Now watch this one as it will find you. Due to the polarization of AC current, your meter doesn't read the peak voltage of each back-and-forth (alternating) cycle, but only gives an average value. So, even though you have an average of 11.5 or more volts on the direct current side of the circuit, you will only get a reading of about 12 volts on the AC side. It may not even be exactly 12 volts, but the point is, all three possible checks here should be very close to the same voltage. If they vary more than a volt, replace the alternator and send it back for checking.

Now on the MTP's, you can switch your meter back to the 50 volt DC scale and check the DC voltage at the three receptacles, which should be 27.6 if your adjustment is OK. On the wheeled vehicle, it is almost impossible to get to the DC terminals of the rectifier, so you go back to the stator terminal. Make your final adjustment of output voltage and harness up. (NBS) On MTP's, the voltage adjustment should be made with the meter switch open and no load except the ignition.)

TESTING THE 100-AMPERE AC CHARGING SYSTEM WITH THE LOW-VOLTAGE CIRCUIT TESTER

That's the way off to if you don't get a voltage above 14.00 volts. Now if you can't get a bit of a boost, you can get by with the old Low-Voltage Circuit Tester 17-T-2271-50 and a 24-volt test lamp. The tester takes longer to make, and use may be accurate, but you can locate the faulty part of your system and change it. Here's how you do it!

If all you can get your hands on to check out your system is the Low-Voltage Circuit Tester, you will also need a couple of jumper leads—with clips on their ends if you can get 'em—and a 24-volt test lamp. (The driver's warning lamp from a truck makes a good one.)

Your series of tests follows very closely those described above for the alternator, with some differences due to the limitations of the equipment.

You start with a battery check, which can be made at the driver's compartment of the MTR's, or at either the batteries or the master terminal of the selected vehicles. If you find you have less than 18 volts while the motor is cranking the engine, a MTR's MTR master-wired 400, right ignition switch 400, left ignition switch 400 and power left master-wired and don't crank for longer than 30 seconds you replace or recharge your battery.

Then start your engine, and observe the voltmeter again. If the voltage rises above the battery voltage, your system is charging.



In order to properly adjust the regulator, you should run the system for 30 minutes with the headlights normal on to provide a load. This will also top up your battery charge. Now, on the MTR's, you open the master switch to read the voltage, which should be 27.5.

Now, on the MTR's you take out the plug on the side of the control box and look in. You will see a slotted shaft into which you fit a screwdriver. Turning this shaft, which controls the voltage adjusting rheostat, clockwise will increase the voltage. Turning it counterclockwise will decrease the voltage. On the MTR's and some other vehicles equipped with the 100-Ampere AC-DC system, the regulator box also has a plug in the cover, accessible with a wrench. Looking down this hole, you will see a black knurled disk which is on the shaft of the rheostat. As knurled on the MTR you would turn the top of this disk to the inside of the vehicle to increase voltage, outward to decrease it, for your voltage is 27.5, and you're on.



If your system voltage shows no rise above battery voltage after you start the engine, you have a problem, and must run them down. The first check you make is to the regulator-voltage regulator harness. With the positive lead plugged into the screw at "Voltage-Connector" and the negative lead plugged into the "old-world" post on the motor, you check (from socket "A") (Positive) to socket "C" (Negative) and you should get battery voltage. (Remember, on the MPV's, the motor-cable must be OK.)



Using a short piece of No. 16 welding rod, a hairpin or two mill or an open paper clip to get into the small holes, you connect the positive lead from your voltmeter to small socket "C". Next you leave the other jumper from the small terminals from large socket "A" and large socket "B". This will only need the jumper for related related.

Now when you turn the ignition switch on, you should indicate approximately battery voltage on the meter. (You can leave your voltmeter negative lead to socket "C", or to get more sure to work, you can move it to any good ground on the vehicle.)

OK, as your first harness is in good order. Now you remember it is the regulator, and disconnect the regulator-voltage harness at the regulator end. Your first check here is to determine that the lead going to starter and that the connections are OK. You put your positive voltmeter lead into large socket "C" and the negative lead into large socket "D". When you turn on the ignition switch, you should get battery voltage. If not, replace the regulator.



At this point you must now check the lead circuit. Using your plug to get into the small holes, connect your voltmeter positive lead to socket "B" and the voltmeter negative lead to socket "C". (These are the old-world sockets on this motor.) Again if you fail to indicate approximately battery voltage, you replace the regulator.

If the regulator is OK, you remember, the regulator-voltage harness is the regulator, and disconnect it from the meter. You replace your checks at this end of the harness, back on the heavy sockets and on the field circuit.



Now you are ready to check the meter. As told above, you first give it a thorough visual check. Be sure it is clean, not bent or damaged, and that there is no evidence of burned and blistered paint. (A slight blackening of the paint does not necessarily indicate a faulty meter, but blistered or flaked paint and a reddish-brown means that's gone.)

If the meter looks OK, you are ready to make the electrical checks on it. These checks are not 100% satisfactory, but are the best you can make with the equipment you have, and they will give you a hint from which to replace the meter or you know it is bad.

Follow this one closely. (Again, if it's wrong, disconnect the meter-to-voltmeter jumper from the meter.) (Without which step you will have taken this off top to get to the rear harness for the low check.)

Now, connect your short jumper from large socket "C" of the regulator-to-voltmeter harness to large pin "C" on the meter. With your meter/switch and ignition turned on, you will have battery voltage at this point, remember?

OK, now you ground the negative clip of your voltmeter lead either to the vehicle frame or to large socket "D" of the harness. (Leave the negative lead plugged into the 50-watt post of the meter.) Now, with the positive lead from the meter, touch the three large sockets on the alternator side of the meter. You should get no appreciable voltage. (A slight flicker of the needle is OK.)

Now move the jumper lead over to large pin "D" under meter connection. (Remove the jumper from the hot socket "C" while changing the connections so you won't see it, except if what you are checking.) This time you should find battery voltage at all three of the large sockets. OK?

If and when you have available either the Carlson File and Field Diagrams here or the new Low-Voltage Circuit Tracer with the inside-in Carlson File, you will make this test the same way, but you will use the alternator and the carbon pin, and will lead the pin until you get drawing H appears through the meter instead of just checking for voltage. This will reveal any pending breakdown in the circuit. But in the meantime, the voltage test will give you a fair idea how things are.)



REGULATOR-TO-VOLTMETER HARNESS



Now, before moving on to the alternator, you have one more "check" to make in the harness. First your ignition switch off. Reconnect the regulator-to-voltmeter harness to the meter. Now take your pin and use them to measure the positive lead of your voltmeter to small-sized socket "B" on the meter-to-alternator connector of the meter. Connect the negative voltmeter lead to small-sized socket "D" in the same connector. When you run your ignition switch back on, you should get appreciably battery voltage here.

This is the last time at which to check out your meter-to-alternator harness also. Disconnect it from the alternator. Now take your jumper and connect it from any one of the large pins, "A", "B" or "C" to the hot socket "C" on the regulator-to-voltmeter harness. Connect the jumper to the pin first, then to the hot socket, to prevent arcing. With your voltmeter still grounded to either the frame or the ground socket "D", check that socket on the alternator end of the small 50-watt-connection harness which corresponds to the pin you are applying current to. You should get battery voltage. Repeat the test with the other two large pins and sockets. (This simply shows you there here is no open circuit or break in the heavy leads within the harness.)



OK, now turn off the ignition switch again and reconnect the positive-to-vehicle, negative lead to the positive lead on the alternator and repeat this field circuit check. For your plus in the small-circuit system, and connect your voltmeter positive lead to "D" and the negative lead to "B". When you turn on the ignition, you should again have approximately battery voltage.



Now, with the ignition switch off, connect your jumper from small marker "D" of the positive-to-vehicle harness to any one of the three large pins at the alternator connection. With the ignition on, you should get battery voltage at both of the other two large pins. Check with the positive lead of your voltmeter, ground the negative lead to the vehicle frame.



Turning the ignition off again to prevent arcing, move the jumper clip from the large pin to small stud pin "B" or "F" on the alternator connection. For your positive voltmeter lead to the other small stud pin ("B" or "F", it doesn't matter which way you make this check) with the voltmeter negative lead grounded to the vehicle frame, turn the ignition back on. You should get approximately battery voltage from this too. If either of the above tests fail to work out, replace the alternator. Get a 15-amp test light. Use it to check for shorts from all pins to ground. It should not light.



Now turn off the ignition, then get your 15-amp 10-volt test light. Connect one lead to the "D" pin on the alternator harness then turn on the ignition switch. With the test light's other lead touching pin in the alternator connection, if test light "flashes" at any pin replace alternator.



Now you have established the fact that you are getting field current all the way down to the alternator. You know that the alternator field circuit is not open. With the test light on you know that the alternator is not shorted out, either in the field or in the stator. You know, then, that the alternator will produce current. Let's see if it is done.



Checking all the harness for tightness, start up the engine and run it at about 700-800 RPM (high idle). With your 15-amp test lamp, check from any one of the three AC terminals on the rear of the alternator. (On most cars all on one side, the front side is selected vehicle installations, and coded with yellow dots) to the other two in turn. Your lamp should light up each time. If not, repeat the field circuit test on the alternator, and if you have battery voltage there, replace the alternator and try again.



OK, so you now know that your alternator is putting out. Go back to your slave receptacle on the MTP's or the master port on the wheeled vehicle, and connect your voltmeter again as you did in the first run of the test. You should now get an indication that the system is putting out. If you have replaced either the alternator, the meter or the regulator to get it to work, you will have to warm the system up for 15 to 20 minutes with the headlights on and then check and possibly adjust your voltage to 27.5.

All this reads like a hell of a lot of work. Actually, after you have checked out a couple of systems, you will find that you can do it, either with the Ohmmeter or the LVCW a lot quicker than you can read these instructions. One short cut you may want to use. Some guys prefer to go right from the battery voltage test to the check of the field current in the alternator on another battery to see if the field circuit is open. Can it you like.



**JOE'S
DOPE**

**'Tis Spring
FOR YOUR
TRUCK'S
COOLING SYSTEM**





LET'S GOVERN **DRAINING**

IT'S NOT THE JOURNAL, DRAINING
THAT WE MEAN HERE, A GOOD IDEA
IT'S THE FLOODING OF THE JOURNAL
THAT WE MEAN THE MOST TO ALL.



Check Your System For Leaks



NOW'S THE TIME
TO CORRECT ALL
LEAKS OR DIPS,
ESPECIALLY MIL-
LANCE TRIP LIKE
REPLACING HOSE
CLAMPS



1



START UP YOUR ENGINE AND RUN IT AT
A FLOW RATE... CHECK THE FLOW RATE
READ AT NORMAL, OPERATING TEM-
PERATURE

2



IF THAT HOSE
AND SEAL
WILL BE TIGHTENED
UP BY THE
ACTION AND
THE FLOW RATE
WITH THE
COOLANT
TANK

3



ARMED WITH
YOUR TRUSTY TA,
LOOK FOR THOSE PLAYS AND BEANS
WHICH LET WATER OUT... NO YOU
CAN'T RUN THE ENGINE AND WATER
COOLED COMPRESSORS AND AIR
DRIVE WATER PUMPS (AIR) AS WELL
AS THE ENGINE

4



TURN OFF THE ENGINE

UNSCREW YOUR PRESSURE PLUG CAP
AND TURN OPEN COCKS, VALVES, AND
DRAINS... THE FLOW INDICATOR ONLY



YOU WANT TO SAVE THE AIR-
BRIVE, SO CATCH IT IN CLEAN CON-
TAINERS FOR FUTURE USE.



AND TAKE ALL CONTAINERS FOR REE-
LING AND STORAGE...YOUR LOCAL
EPA WILL GUIDE YOU ON WHAT NEXT.

IT'S THE TIME TO CHECK YOUR THERMO-
STAT IF IT HAIN'T BEEN ACTING RIGHT.
REMOVE IT FROM YOUR COOLING SYSTEM AND
IT SAFE IN YOUR TM AND CHECK IF OK. IF
IT DOESN'T CHECK OUT DON'T RISK WITH IT...
GET A NEW ONE.

CLEANING

IT'S THE CLEANING-REPAIRING AND
REPAIRING OF THE AIR-CONDITIONING
SYSTEM.



THAT'S WHY THE HOUSE IS CLEANER
AND THE AIR IS CLEANER. THE
EPA HAS A PROGRAM FOR
GIVING A FREE GROUND
SYSTEM.

THE HOUSE IS CLEANER
AND THE AIR IS CLEANER.



THE HOUSE IS CLEANER. THAT
IS WHY THE HOUSE IS CLEANER.
THE HOUSE IS CLEANER. THAT
IS WHY THE HOUSE IS CLEANER.
THE HOUSE IS CLEANER. THAT
IS WHY THE HOUSE IS CLEANER.



THE HOUSE IS CLEANER. THAT
IS WHY THE HOUSE IS CLEANER.
THE HOUSE IS CLEANER. THAT
IS WHY THE HOUSE IS CLEANER.
THE HOUSE IS CLEANER. THAT
IS WHY THE HOUSE IS CLEANER.



THE HOUSE IS CLEANER. THAT
IS WHY THE HOUSE IS CLEANER.
THE HOUSE IS CLEANER. THAT
IS WHY THE HOUSE IS CLEANER.
THE HOUSE IS CLEANER. THAT
IS WHY THE HOUSE IS CLEANER.

JOE'S

Dope Sheet

There's a dove who just dodged in the spring,
And escaped of a pretty young thing,
Has he finished winter's work—
From the gutter of his truck—
Had avoid was neglect's sure to bring.



WE HAVE THE WORLD'S BEST EQUIPMENT...Take care of it

OK, Let's Go



ENGINE COCKS OFF
EXHAUST AND CREW-
ROOM DEAN COCK WHICH
THE CAPTAIN CANNOT



FROM CLARENCE
COMPOUND INTO
THE RADIATION
1-4-1-7
AND THE
LIFE OF
THE PEOPLE



100

100

100

[illegible]

2001 年 12 月
 第 10 卷 第 10 期
 第 10 卷 第 10 期
 第 10 卷 第 10 期
 第 10 卷 第 10 期
 第 10 卷 第 10 期
 第 10 卷 第 10 期

2 PUT ON BACKPACK
JAP AND
BUN BACH-
AT FOOT OF
LITTLE THE
REACHES HER
MORNING
OPERATING
TRIP...
DON'T ALLOW
COUNTRY TO
GO



3 After the addition of 50 mg/mL of 10% sodium citrate, the solution turns blue. The color change is due to the formation of the blue copper complex.



• **Check Exhaust Fan**
• **Cap with Mesh** to
keep **moths** through **holes** in
bath **cage**, **birds** not
due to **water** **leak**



S **ELLER** **CO.**
1000 **1000**
1000 **1000**

1. **Introduction**
 2. **Background**
 3. **Methodology**
 4. **Results**
 5. **Conclusion**
 6. **References**



6 **CLIMATE** **CHANGING**
WATER **RESOURCES**
AND **ENVIRONMENT**
IN **INDIA**



7. 参考文献

100



1. **Introduction**
 2. **Background**
 3. **Methodology**
 4. **Results**
 5. **Conclusion**
 6. **References**



100



100



FLUSHING

NO NO NO...
THE... JAMES WAS
THROWING IT TO THE
GROUND AND
THROWING THE
PLASTER IN
THE... PLASTER
WAS... PLASTER
WAS... PLASTER

Do It This Way



1 CLOSE DRAIN
COCKS AND
FILL SYSTEM WITH
FRESH WATER



2 PUT CAP ON... RUN SH-
OWERS AT MAXIMUM OPEN-
ING TIME FOR 2 HOURS



3 CAP OFF... CHECK
OPEN. CHECK DRAIN
OFF. IF WATER IS DISCO-
LORED, DRAIN AND REFL.
AGAIN. DONE. IT'S DONE

After You've Finished

USE IT WELL



ADD REFRIGERATOR... WHICH ARE NOT
PERMITTED BUT BUT DOES NOT CLEAN
IT OUT... THAT'S WHY YOU SHOULD
CLEANING AND FLUSHING



ADDED SERVICES

CHECK THE WATER
FOR LEAKS ONCE
MORE... ALSO CHECK
THE... AGAINST OF
ALCOHOLISM FOR
PERMANENT...


CHECK THE WATER ROOM IF
NEEDED IT. CHARGED OR
ALIGHT WITH IT, IT WAS TO
BE PLEASE, BUT WILL CHECK
CONNECTIONS


BEFORE THE WATER
PUMP WHEN DO YOU
USE IT LAST?



BLOW-OUT THE
BATTERY, BUT
DON'T USE STEAM!

A cartoon illustration of a man in a white shirt and red shorts climbing a large red tree trunk. He is holding a blue object. Below him, three men in military uniforms are watching. One man in a green uniform is climbing the tree trunk. Two men in brown uniforms are standing on the ground. Speech bubbles contain text about a 'SECRET SERVICE' and a 'MILITARY'.

Comic Book's
 "DON'T BE TRICKED BY IT!"

"I never saw any
 pictures of this
 before!"

"I never saw any
 pictures of this
 before!"

Point your meter's nose

A new superdiode tool has been added to your standard solution supplemental tool set that's going to make working with that 24-watt electrical system a breeze, let alone. It's known as the calibration meter (Ord Stock No. 11-Y-808).

This meter is a small, compact job that'll check out any and all resistance for you in those electrical lines.

The meter has been authorized for inclusion in Tool Set, Organizational Maintenance (Ground Scheme), for

File 1, Supplemental (Ord Stock No. 41-T-0118-801); and in Tool Set, Organizational Maintenance (Ground Scheme), for File 2, Supplemental (Ord Stock No. 41-T-0118-802). The authorization came from Change Notice ORDWD-TRE-CA-03118 (30 Sept 91) and ORDWD-TRE-CA-14815 (16 Aug 93).

Why not keep down to the supply room and use it your meter's waiting for you?



100% OF
 100 100 100
 1000-1000
 1000 100 100
 100 100



Driver shipments



Seaguing truck drivers are in for some pleasant reading in THE 10-100 (Jan 11), the new handbook for drivers of the 1½-ton fleet, amphibious work.

The publication book covers the DURW's driving habits and its preventive maintenance needs from start to finish. And it goes into other things a good DURW driver must know . . . like the amphibious (land flag) signals, lane tying tricks and the International Motor Code plus a sprinkling of seaguing flags.

Commercial-type publications

If you've been asking the shops on how to get manuals for your commercial-type vehicles, well here 'tis.

Write to: Chief of Ordnance, Department of the Army, Washington, D. C., 20315. ORLFORM-Pub, and if your justification's good enough, they'll ORL your request (Use AR 100-80 para 11).

Here's something to remember—if you do only the and don't utilize motor services, then you won't get a shop manual. And the shops won't get a driver's manual.

Now if it's the power tools that you're lacking a manual, write to the same ad-

dress. Be sure you include the info given on the data plate when you request a manual.

Risky switches

That's right—although the mounting will let you switch these instruments between your G740 and G740 1A-1000 cranks, it's a risky thing to do.

It's possible for you to make that switch but funny things can start happening to your crank. Your vehicle's efficiency will be cut and instead of peeling out with good performance it may start lagging on you, all because the fuel-air ratio of the carburetor isn't different.

No, if you need a new carburetor, order the one that belongs on your crank.



GET HALF-MAST MECHANICS

ANTIFREEZE

GIFT.

ANTIFREEZE—IN OR OUT?

Dear Half-Mast,

How come all this fussiness about adding ant freeze to the coolant, storing it and replacing it next winter? My experience with my new car is that if I have enough about I can go on safely from year to year on the same antifreeze.

My car is now four years old, I've had her ever since she was new, and I'm still using the same antifreeze I put in the first winter. Of course, I cleaned the radiator before I put that antifreeze in, and I have kept plenty of rust inhibitor in the coolant ever since. Fact is, I also have a coolant filter on my car. But still this, I have never had any trouble with my cooling system.

I add water to the radiator in the summer to make up for evaporation losses, and just before cold weather, I check the specific gravity of the solution and add enough antifreeze to correct it to -20 degrees.

It seems to me this is a heck of a lot simpler than trying to drain and refill antifreeze. Why doesn't the Army do the same thing?

Sgt P. E. E.

Dear Sgt P. E. E.,

About this antifreeze problem of yours. Seems to me you've been lucky to get away with your program. Of course, having that coolant filter, and keeping plenty of rust inhibitor in your radiator no doubt helped. But on top of that, you must've been mostly in a fairly mild-to-fairly warm water area, and have never had to use any dirty water in your radiator, like from a water hole or muddy creek.

The Army isn't always that lucky, and so they have to figure on giving their radiators a good cleaning twice a year, just before adding antifreeze and again after it's removed (See Change 1 to TM 9-3844).

Another thing, your local garages must have been real good and tight all the hot years you've had your car, or you'd have had some degradation of your antifreeze when the combustion gases got into it. But maybe that filter stopped what little you did get.

I'm in the other school of thought myself. I have dumped my antifreeze on the ground every spring and given my radiator a good flush, rolling with

plain water for the winter. Then I clean the radiators again and put in a new charge of glycol for the winter. Costs me a few bucks, but I have had no trouble.

The Army has no damned money vehicles that they can hardly afford to drive out all the maintenance they need, and besides, I doubt we'd find enough glycol for civilian use if the Army was filling every radiator with new stuff every year. So until somebody changes his mind, I'm afraid you'll have to go on saving and storing your coolant each spring.

Half-Mast

POURING IT DOWN



Dear Half-Mast,

We've got a couple of deep-water fishing lks lying 'round here in unworkable condition. What do we do 'bout ordering parts for these lks?

Sgt C. R. W.

Dear Sgt C. R. W.,

When these deep-water fishing lks are leased, there should be a package contract point with each lk. On these points, some of the parts are listed without Ordnance stock numbers. There're the parts you can't order from supply. In other words, if any part is damaged or missing, you've got to reorder the whole lk. The parts without Ordnance stock numbers are parts which are used only for the deep-water fishing lk.

On the other hand, if you're ordering or got a damaged part which has an Ordnance stock number, you can reorder the part without reordering the whole lk. The parts with stock numbers are used for other purposes besides the lk.



Let's say you check the package contract point against your unworkable fishing lk. If you find a damaged part or there's a part missing, and if this part has an Ordnance stock number pack up the lk and return it to supply with a D.A. Form 447 (Turn-in Slip).

If the lk just came from the inventory, do the same thing, but instead of a D.A. Form 447, use a DD Form 5 (Report of Damage or Improper Shipment). In case you haven't got a package contract point, return the whole lk to supply with a D.A. Form 647.

Half-Mast

COVER STORY

Dear Half-Black,

Can you give me the correct name: shelter and TIE (I) and/or the M&B tent cap? Also what portion of the tank the tarp is supposed to protect?

Capt D. B. P.

Dear Capt. D. B. P.,

Sure can. You'll find it listed in the O&M section of the latest M&B supply manual (Oct 7 SNL 6-214, Jan 71), on page 7 under Tools and Equipment: Cover, canvas, 12 x 12 ft, Oct Stock No. 0208-0457-109.

Frank you won't find the use of this cover covered in a TIE, though. Or in any other directive or manual.

But—the product's chief purpose is to cover the turret when the tank is

parked. As you see, some turrets tend to leak a little when it rains. And they contain a lot of delicate instruments which are not helped a bit by water.

So, use the tarp to cover the turret. And whatever's left over can be stretched to give the engine compartment as much shelter as possible.

Course the cover can be used for a lot of other things. Like for making sun shelter in a dry area, laying out tools and equipment, camouflage, etc. (Just even heard of 'em being used to help shelter a crew.) But—in main purpose is to keep that turret dry, as a smaller bug's hole.

Half-Black



NINE BREEZE



A Reel Hot One

Dear Staff-Man,

Here's a problem that's been causing some rather heated arguments around these parts.

Cables used in the guided missile (and jet control) systems come in metal reels in various designs. But in an installation you find that one cable size or a combination of sizes won't always give you the exact cable length needed.



In the question comes up as to how to handle the extra cable when there's more on the reel than you need in the circuit.

Some say leave the excess coiled on the reel—they say that this is not only convenient but causes no adverse effects

to the circuit. Others say take it off the reel—that inductive action in the coiled cable will generate a lot of heat and that counter-emp? (electromagnetic force) will cause a greater line loss in the cable run.

What do you say?

Mr. F. D. C.

Dear Mr. F. D. C.,

I say you'd get a real hot reel, all right, by leaving that extra cable on it. But it wouldn't be from the added inductance. It's just that the heat that comes from normal power loss (I²R) in the cable would be concentrated in the reel, and ventilation around the spool'd be so restricted that the temperature would shoot up. This concentrated heat not only adds resistance to the line, it can damage the cable.

Though the inductance of a coiled cable doesn't produce heat, it will cause a slightly bigger voltage drop across the coil in alternating current circuits. And in control cables carrying high-frequency currents, the coil could cause standing waves—and lower your power transfer.

So the thing to do is to take the extra cable off the reel and keep it laid out in loose figure 8's. Preferably under your antenna. (This'll protect it from damage by weather and moving vehicles.) Free circulation of air around the cable will keep it cool—and you'll avoid unnecessary power loss.

OK?

Half-Wave



Replacing Nike's AGC Chassis ? **READ THIS ...**



Before you install a new automatic gain control chassis in the Nike's range and antenna cabinet make sure its rotation mechanism is turned fully clockwise ... and please always take time to turn off the plant rules.

Anytime you overlook these small details when replacing this chassis you'll have the pleasure in the weeks of amplification to meet in the chassis maker's court.


Loose Jack Nut

The nut holding the (often high voltage) pulley (output jack) on the Mite's and the Mite's acquisition video head later, has a way of working itself loose which causes arcing around the jack. Normally the arcing isn't visible cause it goes on inside the magnetron, but you can hear it loud while something else that'll shut you to a loose J4 nut is creating magnetron current readings.

If you don't open the loose nut and stop the arcing, you'll soon have power output loss, and before you know you'll be left with a burned jack, which'll put you out of business.

To keep the nut tight and you'll avoid trouble and jack replacements. For a nut to work in it must, and then check it is at least assembly. When you're tightening make sure there's good electrical and mechanical contact with the magnetron. The jack's contact base must sit only in its recess in the nut's washer or's not in contact with metal or metal contact. After you tighten the nut, work the base gently away from the nut to make sure it's not clamped. It's also a good idea to check now and then that the base isn't caught under.

Should you find that arcing continues after you've tightened the nut and made sure the base is free all around the nut ... don't deal with it any further ... it's time for Ordinance to take over the arcing problem.



FOR NUTS WITH 1/4" DIA. CONTACT 1/4" DIA. NUTS IN THIS CASE MUST NOT BE CLAMPED BY THE WASHERS. CHECK FOR PROPER POSITIONING OF THE NUTS.

ARMAMENT



SHOOTING TOO FAST?

Feeling your 188-mm revolver rifle like a machine gun is pushing her beyond her safety limits.

Whether you're shooting real fast for a short time, or fast as you can for an hour, or fast as long as you can by giving the pieces rest now and then, you've got a limit to keep in mind.

Thinking's kinda like a formula. The base of the rule is related to its duration according to how often you shoot. In other words, the 188 can heat up over 100 degrees F during too long a period of sustained firing, which is too hot for the chamber and barrel to meet safety standards.

To play it safe and make your piece last a long time, remember these rules and you'll be around to shoot on other days.



1 You can fire 11 rounds fast as you can load 'em providing the rifle is not over 115-degrees F or has just had a 15-minute cooling period.



2 Maximum Rate of Sustained Fire — Don't shoot more than 36 rounds per hour.



3 Prolonged Irregular Fire—After a maximum short burst, don't fire more than 36 rounds in the next hour. A 15-minute cool-off is needed between two maximum short bursts. Let her cool for 15 minutes after sustained fire before firing a maximum short burst.

BLANK PROBLEM

Dear Ray/Mike:

What do I do now? The short-circuited rope on 188's, 44 and 46 (300) machine guns for the cartridge action won't fire. Now comes RFPD 46 W/F, Ch 2 and RFPD 45 W/F, Ch 1 to tell us to check it on.

OK, we state it. Now, how do the blue-eyed world do we get the damned

thing off for black firing problems? This is normally a job for the unit, but since breaking off a few elements goes, we send our guns to Ordnance for this change. I think it is a disaster when you get your orders at 1100 to fire a problem next day at 0800.

We have heard it said that we're supposed to receive a few guns for black fire use and not apply this RFPD to those guns. Is this correct? And if so, is it covered by any directive, or reflected in a change to the TCM? We can't decide to fire our available machine guns on problems unless we have an authority request, and we don't want to be gipped for unneeded guns which we're interested there, too. Can you help us?

Sgt L. M. G.



Dear Sgt L. M. G.,

Here you. There's a new cartridge map attachment out for the guns which can be installed without removing the shortwood stop. The wood went out in a circular letter (13 Apr 55) from Rock Island Arsenal to all Army units. The new gadget is now available from supply.

So, you men in your Artillery, black firing, Ord Book No. 4000-1145073, and acquisition Artillery, black firing, 800, Ord Book No. 4000-841 2102.

See? No problem.

Half-Mast

CHECK YOUR CHANGE



When ordering special tools for your M41 self-propelled howitzer make sure you check all the changes to your supply manual. Here some people've been overlooking the changes—and getting the wrong tools. Such as medium-tank wheel. When and end-mounted wheel jacks—which's about as useful as your M41 as belly on a tank.

Your Ord 7 500, G-275 should be complete with Changes No. 1 130 Aug 54). This contains the group you need—except that the following listed items are now obsolete and/or have been removed from Special Tool Box, B, 41-B-1445-00; the latest Ser 41-T-1542-003, 41-T-1543-003, and 41-T-1544-004. And who'd want to try to make one with an obsolete tool?

Obsolete Item	Ord Stock Number
HEAVY	41-4-134-000
HEAVY	41-4-137-040
HEAVY	41-4-137-020
HEAVY	41-4-137-027
HEAVY	41-4-137-024
HEAVY AND REPLACE	41-4-137-140
HEAVY AND REPLACE	41-4-137-010
HEAVY	41-4-138-05
HEAVY	41-4-139-030
HEAVY	41-4-139-030

*All used in your tool sets and completely obsolete.

END-FOR-END

When you want to be sure that the quadrant you're using with your work-loop pliers is on the level, better give it the end-for-end test.

It's easy: Set the quadrant at zero direction, using the black numbers on the M1. Place the quadrant on the leveling blocks with the "Line of Fire" arrow pointing forward and center the quadrant bubble by elevating or depressing the gun tube. Then give the quadrant its share just as the arrow'll point in



the opposite direction.

If your quadrant's OK, the bubble will read up-centered. If it's off more than four-tenths of a mil either way (+0.4), then it should be turned in to Ordnance. Go there to do the adjusting.

A LITTLE LUBE



Many AAA crews are having trouble resetting the gun clamp on the rear overrigger of the 90-mm M1 mounts in different positions. Daily lubrication will correct that.

The clamp won't reset because pin A34000 is locking or freezing to bracket C3400, lifting the hinge action. Lube the hinged assembly every day and the clamp will reset okay.

A little daily lubing goes a long way.

MAKE YOUR LATEX LAST



Oil and grease are enemies if the white latex headsets and compound coverings on your tank sighting equipment are crumbling.

Try and keep barrels and base clean free of grease and oil when in contact with the headset, and tell the loader to go easy on the last gas. It'll help preserve the rubber.

Real cold-weather weather is also tough on that latex. The boys in the lab got a clue or all that and are designing synthetic rubber coverings which are tougher. Meanwhile, keep grease and oil away from those coverings.

LOOK OUT FOR THAT 90MM

Time 90mm MG needs a look-over now and then to add to its regular inspection to keep her going strong.

Check your piece against this chart for any possible trouble spots that may need fixing.



90MM



- 1. **BARREL** - Check for cracks, pitting, or scoring. If any are found, the barrel must be replaced.
- 2. **BARREL** - Check for cracks, pitting, or scoring. If any are found, the barrel must be replaced.
- 3. **BARREL** - Check for cracks, pitting, or scoring. If any are found, the barrel must be replaced.
- 4. **BARREL** - Check for cracks, pitting, or scoring. If any are found, the barrel must be replaced.
- 5. **BARREL** - Check for cracks, pitting, or scoring. If any are found, the barrel must be replaced.
- 6. **BARREL** - Check for cracks, pitting, or scoring. If any are found, the barrel must be replaced.
- 7. **BARREL** - Check for cracks, pitting, or scoring. If any are found, the barrel must be replaced.
- 8. **BARREL** - Check for cracks, pitting, or scoring. If any are found, the barrel must be replaced.
- 9. **BARREL** - Check for cracks, pitting, or scoring. If any are found, the barrel must be replaced.
- 10. **BARREL** - Check for cracks, pitting, or scoring. If any are found, the barrel must be replaced.
- 11. **BARREL** - Check for cracks, pitting, or scoring. If any are found, the barrel must be replaced.
- 12. **BARREL** - Check for cracks, pitting, or scoring. If any are found, the barrel must be replaced.
- 13. **BARREL** - Check for cracks, pitting, or scoring. If any are found, the barrel must be replaced.
- 14. **BARREL** - Check for cracks, pitting, or scoring. If any are found, the barrel must be replaced.
- 15. **BARREL** - Check for cracks, pitting, or scoring. If any are found, the barrel must be replaced.
- 16. **BARREL** - Check for cracks, pitting, or scoring. If any are found, the barrel must be replaced.
- 17. **BARREL** - Check for cracks, pitting, or scoring. If any are found, the barrel must be replaced.
- 18. **BARREL** - Check for cracks, pitting, or scoring. If any are found, the barrel must be replaced.
- 19. **BARREL** - Check for cracks, pitting, or scoring. If any are found, the barrel must be replaced.
- 20. **BARREL** - Check for cracks, pitting, or scoring. If any are found, the barrel must be replaced.

While You're At It

There are other checks to keep your gun running maintenance up to par. Clean painted metal surfaces with a dry cloth and unpainted surfaces with an oily cloth. . . grease and lubricate should be done and covered. . . replace those of grease and oil. . . check tubes and connections for leaks. . . use that oil. . . bearings are removed on sight by and that seals are OK. . . look over all internal electrical connections for grounds and breaks. . . all soldered joints should be covered with plastic tape.

Roll a Card of Load and eye over the gun and assembly with a lookover for general smoothness of operation. . . observe and observe the mount by hand between upper and lower steps. . . observe in 90mm with an check function of movement and report action loading or for loads to Command.



On Hummel's 17½-KW Generator.

SAVE THOSE ROO BEARINGS

Dear Sgt. Dyer,

How often a roo bearing get lubed on a Duplex gas engine on Hummel's 17½-KW generator?

REPLY L. F. E.

Dear Sergeant L. F. E.,

Sure glad you asked that question, because we really came a cropper on burned-out connecting rods on the 17½-KW Hummel generator during a recent maneuvers. It wasa doggone shame, too. All that was needed was a little preventive maintenance.

The lubo orders and tech manuals for all models of the 17½-KW Hummel generators tell you to add a small amount of oil with the gasoline every time you fill the tank. That little bit of oil in the gasoline lubes those rod bearings and keeps the engine running like a hopped-up nag in a clanking race.

When you let your generator engine go without oil, you can bloody well expect trouble. Take a look at LO's 1-5814 and 5-9056 on the Hummel models H881A and H88A. They tell you to mix ½ pint of P-3 HRC-lubricating oil with

each gallon of gasoline every time you fill the tank.

Be sure and do the mixing in a separate container. Shake until the oil and gas are mixed and then pour the mix into the gas tank. If P-3 HRC isn't available, you can use DEO.



The amount of oil you add to the fuel will vary with the different engines, so be sure and check your lubo order closely. On the Hummel Model 24-KW 180-24, you add ½ pint of oil to each gallon of gasoline. You'll find this info in LO 1-1340. Some generators have a measuring cup built in as part of the gas tank cap. Use it to measure the oil.

Yup, you ought to keep those EO's with every piece of Engineer equipment. By using 'em, you'll be lubing by the book.

Sgt. Dyer

Carroll What Kind Of Load-Off For Give Road Builders ...

NOBODY LIKES TO RECEIVE CRUMPLED EQUIPMENT

When you're preparing random-type rail cars for shipments—like Buffalo-Springfield Models RT-16 and RT-15—remember that the drive rolls get blocked and secured on all four sides, and that the blocks you use for and at must run the length of the roll.


But, when it comes to blocking the guidorolls, you secure only two sides. Guide-rollers are no-drawbars and sit only on the sides. And a close glance will tell you why—and where—it hurts if this type rail builder is shipped with its guidoroll wedged right.

With the guidoroll rightly anchored the roller's knaggle will get bound with

the first heavy jolt the equipment gets in transit.

If you want to be sure all the equipment you ship gets a fair and square load-off, take time to study Pamphlet MTA-7, which is published by the Association of American Railroads. Get it at your post transportation office. It's all on loading. Department of Defense material on flat cars, and pages 180-182, Figures 11 and 12 give detailed instructions on blocking random-type rail rollers.

The guy at the other end will love you like a brother if you do all you can to make sure his machines arrive in working order.



WINCH CABLE TIPS

When you're using your tractor's winch for heavy pulls, you're going to be exerted of the cable. Serious injury can be caused by cable breakage, but you—the operator—can guard against this hazard by being extra careful when your winch is in operation.

A cable'll stretch when it's under heavy strain. If it happens to break, the



line whip like a snake and you're got to look out.

The greatest danger to the operator comes if the break's near him. Some drivers who play it safe all the way have diminished good winches and placed 'em right behind the tractor seat. They figure the winch can stand the force of a cable lash better than their head.

For trouble-free winch operation, make sure the cable is in good condition and of good quality. Also, look it over often for weak spots. Although careful operation'll prevent it, cables sometimes get bent sharply, pressed against a sharp edge, or dragged on rough surfaces. This'll weaken 'em and make 'em break easier.

To keep your cable feeling hale and hearty, wash it every now and then and wipe it clean of mud and sand. Then put some heavy oil on it—providing the cable doesn't have a kink curve.

And when spooling the cable on the drum, take extra good care to bring it right so you'll have even and secure layers. This could lead to real bad-cable damage when you want to winch.

You'll be way ahead if you work a winch at less than its maximum capacity. Your cables and winch parts and you will enjoy long lives if you only put moderate loads on 'em. For heavy work, you can reduce the strain by using pulleys.



And here's something else to remember: Handling cables sometimes leads to ear burns and nose chafes. A pair of leather-padded gloves can save a lot of wear and tear on your skin as well as make cable handling easier.

EVERYBODY'S BUSINESS IS NOBODY'S BUSINESS

When it comes to maintaining the little engine-powered tools and equipment treated as "English" tools, you individuals are usually responsible for the care of power axes, air compressors, small pumps and so on.

Even though these items are not so "fancy," they should be kept on a PM basis. What's more, they should be dispatched on a DD Form 130 or other operational record card—just what had 'em run when.

This places the responsibility for looking after the engine and other parts, and can prevent you getting gipped for somebody else's goof if you all of a sudden find a burned up engine when you go to check your equipment.



There are some more jobs you can add to your job:

ENGINEER'S RESPONSIBILITIES
 1. Maintain the engine and parts in good condition.

ENGINEER'S RESPONSIBILITIES
 1. Maintain the engine and parts in good condition.

ENGINEER'S RESPONSIBILITIES
 1. Maintain the engine and parts in good condition.

ENGINEER'S RESPONSIBILITIES
 1. Maintain the engine and parts in good condition.

ENGINEER'S RESPONSIBILITIES
 1. Maintain the engine and parts in good condition.

ENGINEER'S RESPONSIBILITIES
 1. Maintain the engine and parts in good condition.

ENGINEER'S RESPONSIBILITIES
 1. Maintain the engine and parts in good condition.



GUIDE RIGHT

Dear Editor,

How about putting a guide pole on both sides of the M4's front bumper for our civilian drivers?



That'd help the green drivers learn the difference between these monstrous warhunts and their tiny civilian cars.



Especially on the right side—they can't see the fender. A guide would tell them how close they are to moving when they make strategic turns on their narrow mountain roads. Or keep them from smashing into other vehicles. After

they've got the feel and know-how to judge the distance, their guides can be removed.

That's easily made, here's all you've got to do: Drill a 1/4-in hole about an inch from each end of the bumper. Get a piece of 1/2-in stock rod, 1 foot long, thread one end and insert it about 10 inch into the hole. There is no the bottom within two. Any piece of round strip metal can be soldered or welded to the top of the rod to serve as a guide arm.

You can paint the rod OD-color and the tip white.

ERIC R. H.

New Hampshire National Guard

Old Man—Good deal if it'll make better drivers and keep checks from getting lost up. But first get your Old Man's OK. Section 3e of AR 15-15, Man 31, says "Each commander at every echelon is responsible for incorporating adequate safe practices and provision for safe physical standards in all operations..." So I'm sure you'll get his okay. Also why not attach the rod on the edge of the bumper so it'd leave a 1/2-in hole when you remove the guide rod, since this is just for training situations?

SMITH'S HELPER

Dear Editor,

Here's a sketch of an awl we are using in our motor pool. It's made out of a chunk of scrap "I" beam. One happens to be a half-inch beam, but any you find handy will do. We painted it with our painting north and cut it to convenient length, in this case about 18 inches.

I reckon lots of the boys might find this handy in their own shops.

Ltj. Earl G. Bernard
R. Lewis, Washington



Ed Note—Your awl looks like a fine idea. We'll also give these made in much the same way out of a short length of railroad iron.)

JEFF'S CLUTCH-KICK

Dear Editor,

After getting tired of replacing broken Jeep clutch levers (and Jeeps No. 6240-7112824) about every three minutes, our motor pool came up with this idea. It's over three minutes since we put the first one on, and haven't broken any yet.

To make one, use these Old stock parts:

- 1 4240-7112824—Old pedal, close to my 1/2-in. rod
- 1 4240-7112824—Idler
- 1 4240-7112824—Idler
- 1 4240-7112824—Idler
- 2 other pins, use 1/2-in. x 1/2-in.

Cut the rod to 44 1/2 inches and put a 3/4" MF thread on approximately 1 1/2 inches at one end. And on the other end make a pin. Then screw the second pin to the threaded portion of the rod. And you're set.

Besides not breaking, they're great for clutch pedal adjustment. It not only saves time, but it allows greater range in making adjustments and won't leave you with the clutch released.

M/Ltj. J. J. Darnon
Camp Stewart, Ga.



Ed Note—Good idea. A lot of other men have used it and it has stood its ground. The MFU will tell you about this. This should stop those rods from breaking.)

Connie Rodd's BRIEFS

Trailer connections

Scenes like *anytime* would have better, but plenty trailer electrical accessories are being tested by somebody getting their equipment of that what-ya-calling. So, please, let's remember that we want to break connections and the connector—pull 'em straight up every time.

Free shuttle

On the 120-mph job, keep your car/shuttling underway. That of point and well ahead. If it starts to vibrate, it's abnormally short road at low elevation and a great stride on the cartage. To take a quick look at 18 8,280 and 12 9,280, and then check your straps.

3 1/2-ton supply manual

That lower 3 1/2-ton 120-mph (page 18) for your 3-ton truck is now available, sometimes. It's the first of publication you'll want to look over and become familiar with. So, why not take down to the supply room and take a gander at it.

BRIEFS

Time for a change

Are you having trouble loading your 120-mph 120-mph generator to your 120 120-shut truck (120-120)? If so, you probably have one of those low that were tested with 4-point connections. Since the van's power cables are for 3-point connectors, and your supply range for the entire Assembly, 1-point, 120-120-120, 120-120-120. With the 1-point 120-mph mounted in your truck your 120-mph will work OK.

New M74 Ord 7

For you guys who are interested in the 120-mph recovery vehicle, that new Ord 7 (120, 120-120) (120 Sept 12) is available. Just check with your supply range and he'll give you the lowdown on it.

Dial "B" for blimp!

Good way to keep from growing old is to be certain around 120-mph—like getting up and using your radio with some time. To take 1/2 the transmitter on, there's almost sure to be a spark. For times and spark together, and that's 1/2 the 120-mph—BAM—BLOOM!





HANDLE 'EM

LIKE EGGS . . .



THAT'S THE WAY TO HANDLE
THOSE PARTS THAT DON'T WORK

WHEN YOU TAKE THEM OFF YOUR
ARMY EQUIPMENT, GIVE 'EM
YOUR BEST GENTLE CARE SO THEY
CAN BE REPAIRED, USED AGAIN.

NEVER KICK A PART WHEN IT'S DOWN

GIVE IT AN E-A-S-Y LIFT

**TO YOUR ORDNANCE OR
ENGINEER SUPPORT UNIT**