

Issue 67

**PS**  
★

1958 Series

# THE PREVENTIVE MAINTENANCE MONTHLY



START IN A  
READING MATTER  
1958 Series



Even Your Fuel Gets  
The Needle With The Man—

## FUEL INJECTION SYSTEM

That's right, there's a lot of similarity between the new fuel injection systems used on the Continental 400, 400L, 471 and 470L engines and the type the needle used on you. Of course, the needle is inserted into the intake manifold of the engine, pressure like, instead of stabbed into you. But the idea is the same.

Whether that's Well, it seems that by using fuel injection they can solve some of the problems that have been plaguing these engines, and get better performance out of them.



THE FUEL INJECTION SYSTEM IS MUCH THE SAME THING YOU FIND ON OTHER ENGINES.



It does not inject fuel directly into the cylinder, and the fuel is not fed by compression ignition.



As the air passes the air is drawn into the intake manifold, or forced in by the supercharger on the 400 and 400L types, and the fuel is injected into the intake ports just outside the intake valves while the valves is open. This feeds the cylinder. It is compressed and fed by a sparkplug. No any other gasoline engine.







Starting from the fuel tank, your fuel comes through the same kind of lines and filters as before, and through the fuel pump. This pump delivers it to a vapor separator on the AOCB-205-1 at 1 to 1 pounds pressure. The vapor separator does just that: it lets any vapor bubble out of the fuel and go to the intake manifold. Solid fuel is then led to the so-called "Train" pump. This is a vane pump which boosts the fuel pressure up to 10-21 PSI and delivers it to the fuel injector pumps. (1798-0's in the 205's get their fuel from their tie pumps in the fuel tank which feed right to the Train pump.)

There are two fuel injector pumps on 1798-0 engines, one for each bank, but only one on the AOCB-205-0 engines. These fuel injector pumps are not clever gizmos. They think like Uncler only by different means. The pump has to take into account the speed of your engine, the compression, and the load (derived from the intake manifold pressure); then it figures the exact amount of fuel each cylinder will need under these conditions, and delivers it exactly the amount the cylinder needs it. It's almost impossible to see cylinders by the fly-wheel timing marks (just like a magnet.) And then, for "extra safeguard devices," the pump has to learn for your final flight rating you are finished with engines. This is done in one manner by way of a solenoid cut-off valve when you punch the "Wheat" button on your ignition switch. Righty, wot?

From the fuel injector pumps, your lines carry the fuel to the fuel injector nozzle assemblies, one for each cylinder, located just inside the intake valve ports. This is the nozzle of the type, and consists a filter, a filter support and retaining screw, and a device called an injector pressure which guides a spring-loaded valve. The valve keeps the nozzle closed except when fuel is coming from the injector pump (at a pressure of 50-75 PSI or more). The fuel forces the valve open and sprays into the manifold.



# MAINTENANCE

Fortunately for the boys in the woods, all the seasonal repair of the Ford Injection pumps is done by experts. All the second school shop is responsible for is adjustment and replacement of assemblies. From this involves quite a bit of very careful work.



## FUEL AND GOVERNOR INJECTION ADJUSTMENT, 170-4 ENGINE



First: Disconnect the throttle control cable from their own shaft lever.



Second: Put the throttle control lever in full open position. Be sure the governor bellows is fully extended. The governor valve assembly for 170-4 takes time to stop. If not, loosen the governor control rod lock nuts and adjust its length.



Third: Using the throttle control lever (they were for the throttle) in the closed position—full idle, back off the cable screw on the butterfly valve control lever until you are completely clear the butterfly to the gas horn.



Keep the butterfly closed and re-connect the throttle control cable, adjusting 'em as necessary.



Fourth: Run using the throttle control lever back to full open. The butterfly valve—should now be fully opened to full open position. Be sure they don't open to the full open, neither is, in full open stop. What you have meant.



glided to be in a state to prove that the throttle valve will fully close when necessary the lever, and fully open when you open it. The two characteristics of an inch diameter on the governor control controls you the governor must operate when you need full open throttle. If the butterfly do not come to the control position, check the fuel control cable or butterfly. Read your 1968-1971 the same way.



#### ADJUSTING THE THROTTLE LINKAGE



Both throttle assemblies in the No. 1 intake manifold take air each bank, you'll find a 7/16-in. Allen plug to let you tie both off the idle adjustment screw on each injector about one and a half turns from fully closed as a starting point.

Insert the idle engine and start about 2500 RPM. Then balance the pressure in the intake manifold to within one inch steady. You do this by opening the butterfly on the low bank until producing the butterfly on the high bank, by adjusting the throttle control rods.



This tells you that your throats are very professional. It's more important than the valves give you the same manifold pressure on each bank than that they happen to be probably the same diameter open. (M400-RT-2 engines have a balance tube between the manifolds—so this step isn't needed.)

#### Idle Adjustment



You are now ready to adjust the idle stop screws to maintain 650-RPM stable.

At the same time you adjust the idle control screws on each injector to get a smooth and balanced idle. This adjustment has been eliminated on the latest injectors, and on M404-2 tanks. (If adjusting the idle control screws does not affect the idle of the engine, check for loose fittings or plugged lines.)

**KEEP YOUR HANDS OFF OF THE WHEELS OR LINK, OUT OF THE FUEL SYSTEM, ADJUSTMENT—THAT'S ALL UP AT THE FACTORY, AND TRAINING WILL SHOW YOU UP...**

That's it for adjustments, which are all you'll have to make most times. The injector needles are designed to be self-cleaning, and you probably won't have any trouble. Remember that a properly-working injector gives a slight squawk when operating. If you don't hear it, give the engine a couple of starts and knock again. If you should have to take apart the injector system or lines, don't let them drain whenever you put them together. It'll clog the needles and injector lines that a drop of CR on the threads helps.

## REPLACING INJECTORS

No machinery runs forever, so it may happen that you'll have to replace a fuel injector at some time. As few things, this seems to be an awful job, but actually it's not so bad. You're gonna have the power pack across the back, of course. Remember that the fuel injector provides a squirt of gasoline just when the intake valve is open. So, the injector pump has to be timed to the crankshaft's rotation, sorta like the magnets.



First, you'd better check your valve and magnet timing. This is the same as on the car before you plug, so your manual has the steps. When you're sure this is OK, you can install the injector.

On your 1960's, you'll find a set of marks on the flywheel for "F-1960-18-1N" (Five Engines, No. 1 Eight-Cylinder, Injection) and "F-1960-11-1N" (Five Engines, No. 1 Left-Cylinder, Injection). Be sure you don't confuse 'em with the "IGN" ignition timing marks which look about the same. "1N" is what you want. You'll go by with a little less handbraking if you install the right injector first, but either one will work OK. Just be sure you use the correct timing mark.



First, fix your angles. You can turn the 117°s from either end you like, 90°s from the necessary end only. Remember to turn it in the direction of normal rotation. (Clockwise when seen from the necessary end.) One thing. If you should happen to go past a timing mark, either turn it on forward over complete revolutions or else back up at least 1/2 quarter turn. This is to make sure any backlash in the necessary drive. In other words, you must arrive at the timing mark while turning the engine in the direction it runs. (We'll assume that you've just checked the ignition timing. Therefore you have returned the valve cover from No. 1 cylinder of each bank so be sure that it was on the compression stroke—both valves closed—when you closed the magnets for that side.)

After setting the left injector (V-2250-1L-2250), you turn the engine on for-wards about 90° to the right injector mark (V-2250-1R-2250), and carefully stop with the mark right at the point of the timing pointer. Be sure nobody nears the engine while you're getting the injector set and installed.



For the A-654-803-1 engine, the flywheel reads "TOP END 1 & 2 IN." Take the valve box cover off No. 1 cylinder and rotate the engine until the intake valve starts to open. You have just passed the injector timing mark. Back the engine a quarter of a turn and come up to the mark, very like.

Next, you've gotta set the injector so that it's ready to put out fuel from the "A" port. Ya see, this injector has six pump cylinders, but it can run on 'em at a time to supply gas to a cylinder. To do this, it has an internal valve that directs the output from each pair of pump cylinders, first to one output port and then to the other. You've gotta make sure that when you line up the arrow on the injector pump shaft with the timing dot, this valve is set for the "A" port, not the "D" port. (That's the other one served by the same pump cylinders.)



To do this, you gotta a little light oil from the "A" output port. Then turn the injector pump shaft in the direction of rotation until this oil starts to rise up in the glass. This shows you the valve is set for this "A" port. You now set the shaft until the arrow on the front of the spline shaft is within the arc stamped "A" or "D" on the distributor block. If the oil does not rise in the "A" port while this arrow is in the arc, make one complete turn of the shaft and try again. That'll work unless the injector slipped by with an incorrect internal timing. If for any reason you can't get the oil to rise in the "A" port while the shaft arrow is within the "A" or "D" arc on the distributor block, don't fiddle with the injector. Turn it in and get another.

When you do find the oil rising in the "A" port, set the arrow right on the timing dot (located below the stamped "A" or "D" on the distributor block). The injector pump is now ready to install on the engine, and the engine is set right to receive it.



#### **ADJUSTING MOUNTING ADAPTER:**

If you are lucky, your pre-timed injector will slip right onto the mounting pad of your pre-timed engine. If it doesn't, don't force it. What you have to do to get a perfect alignment on 1997's is remove the Tilton pump, or injector pump assembly from the end of the magnetron-bearing assembly. Backlash and drive out the fuel injector pump-drive-shaft and gear. Then install your pre-timed injector. You'll be able to reach inside the bearing and move the fuel injector pump-drive level-gear enough so that it is the splines on the injector drive-shaft. Be careful not to disturb the setting on the injector. Bolt up your injector-pump.



Now you can replace the injector-pump drive-shaft. You'll find that the number of splines on the lowest splined end of this shaft is different from the number of gear teeth, so by trying it in several different positions, you'll find one that will mesh. Don't force it. When the shaft mesh, replace the Tilton pump.



There is another way the pump can be installed on 1997's without removing the Tilton pump if you prefer. If the splines don't mesh when you bolt it, remove the injector pump.



Then slide the mounting adapter so that it is on off its pad. This will separate the drive gear from the drive gear.



Push it a few degrees and slip it back. Try the injector pump again.

The same thing applies here as when removing the drive shaft. Due to the different number of splines and gear teeth, there will be one position which will allow the shaft to mesh.

The important thing is not to move either the injection-pump shaft or the engine crankshaft.



After you have fitted the right injector, turn the engine clockwise 120° to avoid blocking the airway and to the "1-000-0-00" mark and install the left injector the same way.

### CONNECTING FUEL LINES

Each part on the injection-pumps is marked by a stamped letter. You hook up the fuel tubes to the cylinders like this—

	CYC	400 - FC
	THE LINE IN EACH CASE	
INJECTOR PORT	A 1 1 0 1 1	A 0 0 0 1 1
INJECTOR NUMBER	1 3 3 1 4	1 4 3 1 4

Start on the firing order, see!

That's it, hook up your fuel supply line from the booster pump, the governor and the temperature lines, and the electric lead to the solenoid valve, and you are ready to run.



The only other thing you ever touch on this system would be a clogged injector nozzle which didn't clear itself when you gunned the engine.

You can remove the fuel tube, valve and the injector nozzle, and carefully tap its ball tip against a clean metal surface. This will shake out the little fibers and filter material. Watch for the little gasket that may or may not follow 'em out. You can carefully remove the filter retaining screw and remove the little filter screen if it appears clog. Clean and replace. Reinstall the injector nozzle and try again. If the still doesn't squawk, get a new nozzle. (Naturally you'll be sure the fuel tube is clear.)



That 14-1900 model (and only one) can get hotter than the boilers from hot water. Things can get hot for the operators, too, if these safety important points are overlooked.

Take the boiler blower valve, for example. It has to be open all the time when you're operating to keep air pockets from building up in the boiler. These

are the same kind of pockets you get when the water boils first. Air pockets get steam hot spots in the boiler. And hot spots can build a big enough head of live steam to blow it open. So make sure that blower valve is open before you start operations. There should be a trickle of water and steam coming from it all the time you're operating.

Speaking about the boiler, here's another important thing to watch for. Always make sure the boiler is filled with water before you fire the heater. There



NOTE  
TYPE  
NUMBER  
DATE  
P. 1073

boiling coils need water to keep the water down, and if they don't get too hot, the coils heat up and you're out of business.

Most of the trouble here comes around the pressure switch. If it isn't working right, you may not be getting any water into the heater. So to play it safe, make sure there's water coming from the shower-heads before firing up the boiler.

Which brings up a little caution about firing the heater.



If the heater falls asleep when you turn on the hot-water line.

Close the manual control fuel valve to keep any more fuel from entering. Then run the engine at governed speed for about 15 minutes to drive off the compressed untreated fuel.

If you don't, those fuel vapors can build up on you, again, and explode.

Here're a couple more points that are pretty simple but probably the important for trouble-free operation.

The fuel-oil pump's gotta keep well-oiled to give smooth performance. Course, when you're using fuel-oil, there's no water.

The fuel is capable of doing its own lubricating. But if you have to switch to gasoline, here's a heads-up keep in mind: One quart of engine oil for each five gallons of gasoline. That'll keep the pump oiled and running right.

Use yellow, 55-gal drums for the mixing operation. Pour in 11 quarts of Oil 50 engine lubricating oil—and then fill up the drum with gasoline. By pouring the oil in first you get a better mixture.

And the gasoline pumped into that drum will be even cleaner if you use a fine mesh screen to filter out the dirt.

If there's anything worse than running the fuel-pump without lubrication, it's running it without anything at all. Like when the fuel line leading the pump gets clogged, broken or disconnected. It goes to keep an eye on the fuel line, especially near the right-side door assembly panel. It can get clogged up there easily and shut off the fuel completely.





# JUICE



As you HSS and Milwaukee guys know, the frequency converter has the job of giving you with the power that keeps your equipment operating. If the converter goes on the fritz, you have to get your steamy generator into operation until you get it back on the train.



The converter has a couple of jobs to do. First, it has a motor-generator unit that gives you 120/240 volts, 60 cycles, AC. That's the main power supply for your rig. The transformer-welder unit supplies the 28-volt DC to operate the relays.



The voltages on the panel will tell you in trouble on the AC circuit. If the needle starts fluctuating, shut down the converter and check out the breakers. If they're tripping or making poor contact, it could give you a voltage drop and blow a fuse.



Same goes for the transformer. Check it out for heat... plating... loose connections.

Use your 20-250V multimeter as feedback if the meter is playing you false and re-check the voltage output right at the converter while it's running. To get the right AC output, check each phase of the three-phase 60-cycle current.

# TROUBLE

your meter should show 120 volts across a clean capacitor on TV.



## Capacitors and Ind.

You have two AC-DC capacitors. Take the data sheet from one of them. If either are connected to both, rearrange both cables. Each capacitor has 28 connections and each capacitor is numbered.



Before you go any further, make sure the capacitor(s) switch is in the final position. You put the switch in final to prevent damage to the converter when you're operating it with the cables disconnected. If you find up here, you'll be in for more than your share of headaches. If the rest is having voltage trouble, it could be in the cables. If the circuit is open in the normal electrical circuit... on the cables... or connections... you can't control the voltage with the switch in normal.

Use an ohmmeter to R-verify and see a range scale of 100 ohms.



For the negative lead (black) it may be the ground terminal 1, 2, 3, or 4. They're all connected to the same place. For the other lead, look in either pin 14 or 15... they're the neutral common.

You should get a reading of 120 volts.

Test the control phase by getting the black lead in panel 7, 8 or 9.

Disconnect plug in panel 10.



In the third phase, use the same control section and get the steel leader pins 11, 12, 13, 14 or 14. You need a reading of at least 100 volts in each of the phases. If you're not getting a good call in the highest resistance group.



It's important to test the direct current output for the same resistance, only set it at 50 Ohms (approximate) for the 50 Ohm resistance.



Test the control in pin 12. This controls approximately in pin 23. The results are your cable check jump to 50 volts.

If your reading is 50, then check 20 and 21, 22 and 24, and 25 and 26.

You need a reading of 50 volts in each test. If any of the controls show less than that, you're double-checking cables. Tell the highest resistance group again.

Of course, if everything checks out at this point, you follow the troubleshooting routine on the section panel outlined in the TSM.

But remember: If your customer isn't doing right by you, troubleshooting the whole wireless panel isn't going to help a bit.

MY BOSS, THAT'S WHAT SHE SAID! SHE SAID WE CAN BEAT THE HEAT MY way!



That high voltage cable in the P11 channel of your Mike-A-Jay radio was sure enough *does* get mighty warm. Matter of fact... the cable gets so blasted hot in the place where it passes the R-9 and the R-12 resistance the insulation is melted by the heat. Then you get sparking and arcing.

You can roll a ball on the burned cables as fast as it takes to do the job. First... make sure all power is off. Then take off the cable channel.



Next, pull off three inches of tape from the cable harness. That gives you three extra inches of high voltage cable.



These three inches let you reposition the clamp about 180° from its former position and ensure the cable around and above the R-12 section.



Replace the clamp and finish up by slipping a 12 to 13-inch piece of black plastic tape off the roll 3009 0078-011-7772 and wrapping the cable harness.

The cable now will sit in the heat position while you're working for MFG and VLSW and.

## LIGHT-BULB TRICK



You say you experienced 6-watt Mini-bulbs for your Nike-Ajax branching second trailer? And you got the incandescent type instead of xenon-type type?



For the incandescent bulb, TM 428 700-5483. You'll get the same base type bulb.



You got the xenon bulb type bulb—then you got a 402 FC replacement when you use TM 428 700-5483.

## PLUG THE HOLE

You've seen the hole in the accumulator under second 2 at the forward end of the early Nike-Ajax trailer? You?

The hole gets you in there when the switch is stuck. It doesn't do much except let water in. And the water comes out on the forward inside surface of the accumulator shell.



No sense in plugging the hole if it's not already sealed off. All it takes is a piece of 1/2 x 1/4-in tape. The calling name is Tapes: Pressure sensitive, oil and moisture resistant... and has this TM's 424 700-6029. The tape is a Quarter-meter item.

## A REAL HOSEING

Guess the day when your Corporal popliteal is working through the hoses is slowly, you think maybe the hoses are clogged. And...you're probably right.



Pressure-rated hoses in the accumulator supply tubing require special care. After thoroughly cleaning the popliteal, use a hose cleaning solution.



Be sure your cleaner gets to the inside. Don't let the water run through the inside to the outside. If it's covered with rust, decontaminate the inside. Don't remove the water and wash that inside with alcohol.

Keep checking the water before you run another or add through the hoses—like it says in TM 9-4026.

## RIGHT HOOKUP

Even though...the Nike-Ajax 4817000 and 4817100 trailer popliteal was used on a positive grounded system. And this means the positive side of where the power comes from—a 28-volt nickel cadmium battery—is always connected to the ground terminal on the popliteal trailer.

It's tough to get the wrong hookup if you make a difference colored Nike wire connections around each terminal. Make it red ground, No. 1114, PSM 88 80-507. 1114, connect the ground (+) terminal and black ground, No. 1026, 800 8000. 207-212, connect the 28-volt (-) terminal.





Generator Operation

**A FAN MEANS YOU'RE OUT**

Diesel-driven generators can be as dangerous as a mood-up woman. One wrong move, yours or a guy, can get both feet operating generators. Especially from the radiator fan.

The pulsed fan that fan and you're got to reach closer to a fresh egg in a new grinder. It's as powerful as a weight-lifting gorilla.

There's a big chance for an accident when reaching a generator. You're reaching close to the radiator fan while pulling the compression release lever. Clothing could get caught in the fan—and pull you in. Especially loose clothing, of which there shouldn't be any. Or, you could slip or lose your balance or something. And serious handling of tools or equipment around it could really wreck your diesel generator.

Use together with your support tools and maybe they can help you see or what you need.

Wear eye shields on both sides and where the radiator. They should be made of heavy eye shield and it should fit the eye so there is no chance of getting a strand through.

Another kind of work should wear the generator operating in the fan area.

Another kind place is the opening of the generator housing which should be closed around them keep things out that shouldn't get in.

Check with field maintenance. T&E is used, and they'll come up with the material and know-how to fix these generators for better operation. MFRS 3-12761, when one of the Cummins 100405 KW in the branching area.

**FILTERS FOULED? FIX 'EM**

Next time you're on a maintenance detail around the job at your PMA site, take a minute to look at the air filter on the hydraulic system.



Roll off a few disks and use a finger over them. They call the waste.



Put a hand on the filter when the air comes out and you'll know the filter work is gone. Roll it in, and then use the air control to work the air, which is a bad mistake for the hydraulic system.

Every month take the filter apart and check the disks in its housing. When you do this, you can get a good idea of the air filter. When you get a good idea of the air filter, you can get a good idea of the air filter. When you get a good idea of the air filter, you can get a good idea of the air filter.



If you're the better like some of... or the best, they reason it out in your part of the industry... give the hydraulic system a fresh new generation by taking up on air filter. One way is to hold a piece of clean cloth over one or three times and wrap it around the bottom of the filter cap. There's the steps concerning to Clark, Genco, Chevrolet, 90 cc, white, medium, 100 cc, white, 1 quart, 800-1-70-9661 (Q04).

Put a piece of clean cloth over it, and hold the cover down with your hand to hold the cloth in place. It'll help the hydraulic system for a clean air.



## CORPORAL CHAOS GAUSERS

Would you republish a log just to get a slice of bacon? Some guys do almost to that.

Like Pyloratus . . . if a tube flows in a radio-transmitter or signal generator, just talk for a new tube. Don't order the entire transmitter or generator.

Never make like you're in a hurry when you receive a tube from a computer, radio set, or what have you. That is not. If you get enough, you'll shake it like you were jacking up a truck or changing a tire. That shaking business is murder on the tube guide pins.

"Casualization" is rather, too. Shipping a chassis for parts never works out in the long run. But "controlled exchange" will get you out of a pinch when a real



emergency crops up. Emergency, in this case, means when you need a part to keep from ditching a major item. Controlled exchange means removing a part from a spare chassis and then replacing it when you get the new part from supply.

Having any loose parts lying around inside a piece of equipment when you need it back for repair is like putting a rose in a china shop. In . . . don't have a dead tube lying around inside the inside of a radio set—it'll only work when tubes

## GIVE IT A TAP

After sighting the location for attack holes on your Nike-Ajax missile, give the tin a light tap on the tapered end while your hands make sure those locking bolts



are in place. If they're not seated right, you'll be able to hear a slight "click." Double-check the fit by feel to make sure it doesn't move.

# Connie Radd's

"DON'T BE FOLLY BIFT"



## *Wingpin' in it out*

One thing the DDT self-propelled harrow's habit was not meant to do is drag projectiles from a distance. It's only meant to harrow and level projectiles from one spot—and that's "directly in the rear of the lower section of the turret rear door."

Handling heavy projectiles by manpower can get to be a rough deal. You think how much easier work it will be if you raise the harrow and have it mechanically "run" physically up into the vehicle. The best thing is to get out of your tracks with a boom on it and use 'em to do the hard job. Or, if so all possible, get the turret track to drop the projectiles where you can hoist them straight up, rather than drag them into position.



If you're using the harrow for winching chains, the cable will drag and get burned. If winching at an extreme angle, and you get stuck in the cable, it's easy for it to jump off the drum. Then, you'll have a job on your hands.

That harrow'll do the job it's meant to do and no more. Stick to this and you'll have your harrow when you need it most.

## Slip to stop slips

Been looking for a trouble-free way to keep track of MPPC's that've got to be done? Well, here's a way to get rid of the gamebook.



If the modification's already been made, he'll remove the slip and write it on the MPPC jacket.



If not, the name slip'll remind your mechanic to get the MPPC (which you'll have available at the desk) and either do the work or get it done.

## It's no ball

Those MPPC hand grenades (that's how they're called) are beautiful grenades, but before you start winding up for the pitch, better give it some thought.

The first thing to take into consideration when it's the direction of the wind. No matter how much you wind up and how hard you throw, you still might get a soufflé of tear gas if you throw against the wind.

The next thing to remember is that grenades have a fuse with a lot of time and delay.



Do keep your thumb on the safety device after you've pulled the safety pin.



When you throw the grenade, the delay in the fuse will start to burn automatically.



The gas cloud spreads out and fans from the point of burst, so don't be shy when throwing.



## Brake shoe wear



After pulling Direction on D742 trucks which have had MWD Old D742-W01 (5 Apr 51) you can have sometimes run less trouble when re-assembling the brake shoe to the backing plate. They don't always get the washer in exactly the right place.

In fact when you reassemble your D742 (71) new trucks that you get the upper Camshaft between the anti-rattle spring and the brake shoe, and that you get the lower washer between the brake



shoe and the backing plate. Placing these washers any other way will drive the shoe out of line and result in wrong brake operation.

## Substitutes

Getting the studs and plug in the front-end assemblies of your D742, D742, D742, D742, D742, and D742 (10-ton trucks? If your answer's yes... danger too it's a loss



100 WASH  
L-REAR



and washer causing the trouble. This washer's kind of wash for all the jamming around the same assembly goes during towing operations.

If this is your trouble... substitute a thicker the washer, PSM 311444, 4120 (Old). This washer is close to 1/4 (0.1875) inch in thickness. The best one you take off is only 1/8 inch. It's enough of a difference to make the difference.



100 WASH



100 WASH



100 WASH



100 WASH

To be sure you get a good tight lock, change the safety nut, PSM 1514-044-1000, for a new one when you reassemble the front end assembly... and

under the mat in three or more places. Even with the extra thickness of the new winter, there should be more enough on the shovel end of the glass mat to make the mat.

This should stop your cold grip for right now.

## Air supply

Come on like practical individuals when it comes to the air compressors on your heavier M-series trucks—the G742 and G743-series 2½-ton trucks, the G744 3-tonner and the G752 3½-tonner.

There're only two reasons why that air system's put in those trucks. First, they give you that loading power. Next, they give you a ready-made air supply in case you have to blow up a tire. Never use it for anything else than what it's built for—would make it get upset when you need it most.

## Always winterize



I know it is generally a commercial vehicle, but our Mike says here some 1957 Chevrolet owners do TDI stuff.

We've found that as usual, the side view mirrors touch the glass when the window condenser is opened. Strong-arming the view has caused broken glass.



But it's simple to lower the mirror about an eighth of an inch from the glass, no sweat. If your buggy is still in her warranty period, your support unit will get it fixed for you. If not, you can do it.

## An SB that's a BT

Your new SB-54 (8 Sept 57) is a Big Help in finding just what parts you need for your DeSoto equipment. There's something new in this SB... it now tells you who (which retailer) is supposed to have the SB-54's and TB's. It also gives the policy for the SB-54's.



Treat it good and it'll treat you good. Make sure you check those air winterizer each night after using the truck—this'll keep that air system in good shape.

# JOE'S DOPE

## DON'T BE A HEARING BEATER

...n't upon a time there was a fella of hearing name of Ball

Now, this heah fella of Ball lived in a piece of military equipment maintained by a guy who was mighty handy when it come to maintenance... which nocherly led to sub treatment... and that's how come he run off...

... happens he meets  
... she up with Connie Rodd...

... she says  
... she says  
... she says

... so he says  
... so she says

... she says  
... she says  
... she says

SO... she up and... which went like this:

... she says  
... she says  
... she says  
... she says

... she says  
... she says  
... she says  
... she says



... she says  
... she says  
... she says  
... she says



## BEFORE REMOVING



## TO REMOVE

a bearing from a clutch you pull on the lower ring.



If you can't get a grip on the right ring—pull and pry on the other ring to draw the right one so's you can get wheel out.



WASHING  
CARE

Don't pull from inside or outside's inner pulling.

Don't pull from inside or outside's inner pulling.

Don't pull from inside or outside's inner pulling.

Always in position when separated with clean cloth to be used.

If ... the grease is too hot, disintegrating fast, or has come off its rings at its 150° F and made the bearing and the grease is done.

Grease is not an oil. It's a mixture of mineral oil and soap.



**WATER, WATER ...**  
**WATER, WATER ...**  
**WATER, WATER ...**  
**WATER, WATER ...**  
**WATER, WATER ...**  
**WATER, WATER ...**  
**WATER, WATER ...**  
**WATER, WATER ...**  
**WATER, WATER ...**  
**WATER, WATER ...**  
**WATER, WATER ...**  
**WATER, WATER ...**



Try 'em all good ... It's not just 'em' as hole only. The bearings are made.



Use hot blue ring for rubbing and hot blue-green for blue.



Try 'em all good. Use blue-green for rubbing and blue for blue.



Remember, you're looking at the bearings.

# BEFORE LUBING



Check the bearings before lubing.



**RINGS ...**

WATER, OIL, OR GREASE



**OVERHEATING**

RED OIL ...



**GENTS ...**

IN OIL, GREASE, OR WATER



**OR ...**

WATER, GREASE, OR OIL



Don't think of the bearings as a whole. They're not all the same.




The bearing is not a whole. It's made of parts.



Check the bearings before lubing. They're not all the same.

# JOE'S Dope Sheet



For a bearing to keep going  
'round

Like the earth—without making  
a sound.

You must be on the ball  
When you lube, clean, install...  
So no dirt, dents or wear  
can be found.



WE HAVE THE WORLD'S BEST EQUIPMENT... *Take care of it*



When replacing top or base replace both they're needed.



**NOW ... STORING**



Now, just in case you have to leave a bearing in a partially put together assembly or other mechanical surface, be that motor-mount frame than exposed. Lubricate and cover them up with cloth or paper and you're ready to put the assembly back together again.

**LUBING**





**SO ...** in all trades, trades and trade unions—all you'd do is use a little of grease inside these hubs to get it out.

### WHICH GREASE TO USE ...



According to SA 171-1716-1 (22 August 1952) there are the only two grease types or wheel bearing greases.

According to SA 171-1716-1 (22 August 1952) there are the only two grease types or wheel bearing greases.

TYPE	TEMP. RANGE
100	100 to 200
100-100	100 to 200
100-100	100 to 200
100-100	100 to 200





## QUESTION AND ANSWER DEPARTMENT



### BOOMLESS BOOM JACK

Dear Flak-Mack,

We've done about a dozen floor joist assemblies for you since you moved your 800 1-ton machines, but since the boom jack assembly, we've tried to find a stock number on our own only the assembly, but so far, no luck. Can you help out?

SPC R. F.

Dear SPC R. F.,

Your luck won't get any better, 'cause there's no stock number for the whole boom jack assembly.

What you have to do is order each individual part of the assembly. You'll find their stock numbers and manufacturer listed in God 7 800 12744.

And don't forget to put down why you need these parts, 'cause you can't get many of 'em without a justification. In this case, it's because you didn't get the assembly when the truck was bound to you.

Next time you receive a major piece of equipment and it's missing some major bits or parts that're spelled out in the 800—write up a U.R. 024 Form first. That's the best way to stop future shortages like this.



## YOUR TRUCK-MOUNTED SEARCHLIGHT

Dear-Eye Glass.

What's the story on the searchlight set, reflector set, 60-in reflector, DC, 18 volts, and its companion parts? Our searchlights are mounted on 1817 JH-size truck chassis.

The problem is that we must maintain tools and equipment in accordance with the EPG 7 & 8. Some of the tools don't apply since the set is mounted on the 1817 chassis. The searchlight set must have been modified since the EPG 7 & 8 was published.

I sure would appreciate it if you can give me the date on changing the set from trailer-mounted to truck-mounted and include the tools that I should have.

SFC W. K. E.

Dear SFC W. K. E.:

There've been some changes made since searchlight flying gear was mounted on a pair of trailers. The power unit was, at one, the searchlight was on the other, and they were moved from place to place. But, to make them more mobile, they were put on an M18 chassis and became a single unit.

Here's the rundown on that set:

It goes under FSN 6258-100-7082 and is listed as Searchlight Set, reflector set type, 60-in reflector, operating requirements 18 volts, DC, General Electric Co., Model 19414.

Companion parts include Chassis, truck M18, FSN 2130-811-8036, Extended hand control, Searchlight, FSN 6258-101-9405; Generator Set, G.E.D., FSN 6111-241-7746, and Searchlight, FSN 6258-100-7116.

Here's the hard word on tools and jigs you need and how:

TOOL OR JIG/ALL NO.	DESCRIPTION	QUANTITY
41600H1 B20A	Wrench, An. W/throw	1
2110-1410-1007	Wrench, Hand	1
4100-100-8817	Adjusting tool	1
6100-410-9072	Cleaner, Negative	1
4100-410-9072	Cleaner, Positive	1
6113-101-8290 (Head)	Assembler	1
7412-145-7130	Modification Kit	1
EPG 7 & 8 B7112	Searchlight only	1
18 S7111 (Operated)	Searchlight only	2
18 S7112 (Parts)	Searchlight only	2
18 S7113 (Maintenance)	Searchlight only	2
EPG 7 & 8 B7114	Power Unit only	1
18 S7115 (Operated)	Power Unit only	2
18 S7116 (Parts)	Power Unit only	2
18 S7117 (Maintenance)	Power Unit only	2

Call today. Equipment catalog on order!

## BETTER BELTS

WHY CAN'T I FIND  
any more belts like the original  
M&M's? I've tried all the big  
hardware stores and they  
all say they don't carry  
them. Can you help me find  
some more like the original?

Dear Half-Man,

We have found that using the same steel jaw belts, P/N 3019-117-0015, on our M&M PTF's seems to give us much better results than using the cheap jaw belts. They fit in with no problem, they're easily interchangeable, and we get far longer life from them.

Capt S. E.

Dear Capt S. E.,

Here, the belt will do, and that gives you a good cut in an emergency if you can't get M&M belts. But the original belt is reinforced and a little stiffer, so it should give better service.

Are you sure your boys always replace the belts in used? Our old and new jaw belt never work together—all the strain goes on the new one. And have they been adjusting those belts right with a 1/4-in. thick like TM 5-1492, para 183 and Beam adjustment is the worst cause of belt breakage.



## SPROCKET HUB REMOVER

Dear Half-Man,

Taking the sprocket hubs off our M&M tanks is one big lousy job. There must be some way to do it without either damaging the shell or breaking our backs. We made a kind of battering ram from a heavy bar—welded handles to it so four men could grab hold and swing. After the bar hits the center of the hub a few times, the shell pops the drums and we're all set.

What do you think about this idea . . . or have you got an easier way?

Capt F. E. D.

Dear Capt F. E. D.,

Why go through the work of making up a special tool when there's one already in the system which you can have—actually, one you should have. This tool

should be part of every Special Tool Set A or B for the M48 tank. The seal for Rammer head drive, 1 1/4 NF-28 female thread, 1 1/4 in. dia., 17 1/4 in. lg, P/N 5130-834-8441 (2)ea.



In checking over your tool sets make sure you have this seal. If not, it'd be a good idea to order it--it's yours for the asking.

*Half-Shell*

## SCREEN THAT SMOKE



Dear Half-Shell,

Isn't it a fact that when the M48-series tank's main engine exhausts little reflections of properly cut, there should be a trace of black smoke at the exhaust?

SFC W. M.

Dear SFC W. M.,

Oh, old black exhaust smoke means trouble at any time. Main engine exhausts little out of which, too rich fuel mixture, high exhaust flow level, dirt in the exhaust, dirty air cleaners or carburetors out of balance--these are the things that can cause black lag. So, you want to be sure your carburetors and throttle control linkage are tightly adjusted all the time.

You'll find that a vacuum test is the best spill on screen adjustment. Check para 116 of TM 9-702 on the M48 for the way to go about adjusting.



*Half-Shell*

## FLYING FLANGES

Dear Hal-Max,

What sort of power-takeoff or other accessory is described on the front axle of the 20-ton G742 and 3-ton G744-series tractors? And what gear on the rear differentials? I see those flanges whirling around there and I don't know what they're for.

Sgt J. E. D.



Dear Sgt J. E. D.,

No power-takeoff or other device is installed on these differentials. The point is that all the differential axles on one tractor track are the same.

For example, one tractor, marked under PDN 2140-744-6070 covers for the 1-ton differential, the forward rear and the rear rear differential for 3-ton.

To simplify matters, these are shipped with a cast-steel-plate flange installed. They can be turned right in whenever required.

The slight cost of the flange is more than offset by the savings in not having to make one less item instead of three or four.



## ONE AND ONE EQUAL THREE?

Dear Hal-Max,

Our M10 (T7E1) 30-ton self-propelled howitzer has 71 shoes on the left track and 72 shoes on the right track.

Is this right and, if so, why?

SFC T. P.

Dear SFC T. P.,

The road wheel arms and cooling fans on the right side of the vehicle are an 1/8 inch further in the rear of the vehicle than the ones on the left side, because of the machine's hull staggered position. So, to make allowance for this difference, the right track has to have one more shoe than the left track.



# ARMY AFLOAT



## DATA UP TO DATE?

All of you water men know that your Floating Equipment data reports are essential to your support units. These forms give all the necessary data on proper space that be processed and stocked to support your work.

But have you lately have you checked up on yours? AR 700-2900-5 tells you what's required, and sets up the proper forms.

Briefly, it's like this: You fill out the appropriate DA or WELDON forms in the 11-series (DA Form 15-26 through DA Form 59-31) and send them to the place called for in the AR, except that now the original copy goes to the Commanding General, United States Army Transportation Supply and Maintenance Command, PO Box 209, Main Office, Ft. Lewis 1, Mo.

The forms go in 30 days after a new craft is received or its first duty station and any time after that when a change is made which alters the information in the form.

Now, there's work in it, but your chances of finding the right size rubbered deck landing, P'riestman, when you need it, are best when if the support people know there is a craft at your station with that size deck. Or if you change it which for matters of a different make, you'll likely find parts for the old one waitin' for you unless you report the change.

## SICK SICKS

I'd think everybody would know about it by now, but what with the present carnage and war on, maybe we'd better look again at some of the little over-the-hill tricks that can make your MCM's look more sick like.

First of all, of course, there's the simple type who doesn't check his shaft logs after landing operations. Instead of one of these genius types was served in the other day with three feet of water in his engine room.





# STICK-UP JOB



Next time you make your mind to place a few numbers, no need to be robbed of time and wits.

The new gummed-back stencils stick where they're stuck, with no need to juggle a matching board in one hand and the point brush in the other...and the tear-out bridges eliminate re-tooling. And best of all, they're a one-time deal.

So pick out your target... slip on the stencil... and make with the point brush. Can your glimmers see this list of Federal Stock Numbers for the ones you're after?

The how, where and why and when of these stencils is found in AR 741-2000's cat. #1. In formal language, call for: STENCIL, MARKING. Paper, gummed back, black lettering. 1 per pkg.



## SPECIAL STENCILS



STENCIL	SIZE	FPM (QTY)	STENCIL	SIZE	FPM (QTY)
AROUND	2 1/2"	705-02985	HALF SPIN	1 1/2"	705-02787
	2 1/2"	705-02788	NO. 0000	1 1/2"	705-02986
BRIGHT BLUE	2 1/2"	705-02984	(S. 000)	1 1/2"	705-02989
	2 1/2"	705-02787		1 1/2"	705-02788
FOUR	2 1/2"	705-02983		2 1/2"	705-02789
WHITE (WHITE) FOUR	2 1/2"	705-02787		2 1/2"	705-02790
NO. 0000	2 1/2"	705-02788		4 1/2"	705-02791
NO. 00000 (WITH 1/2" EXT)	2 1/2"	705-02982		4 1/2"	705-02792
PLUMB	4 1/2"	705-02793		1 1/2"	705-02794
WHITE (WHITE)	1 1/2"	705-02785		2 1/2"	705-02795
FOR OFFICIAL USE ONLY	1 1/2"	705-02980			

# ALPHABET AND NUMERALS

	1 in	2 in	3 in	4 in
A	7520-015-1007	7520-015-1387	7520-015-1388	7520-015-1389
B	7520-015-1009	7520-015-1389	7520-015-1390	7520-015-1391
C	7520-015-1010	7520-015-1394	7520-015-1394	7520-015-1395
D	7520-015-1011	7520-015-1393	7520-015-1393	7520-015-1394
E	7520-015-1005	7520-015-1392	7520-015-1392	7520-015-1393
F	7520-015-1000	7520-015-1391	7520-015-1391	7520-015-1392
G	7520-015-1006	7520-015-1390	7520-015-1390	7520-015-1391
H	7520-015-1005	7520-015-1379	7520-015-1399	7520-015-1399
I	7520-015-1008	7520-015-1378	7520-015-1398	7520-015-1397
J	7520-015-1007	7520-015-1401	7520-015-1397	7520-015-1398
K	7520-015-1008	7520-015-1400	7520-015-1393	7520-015-1393
L	7520-015-1008	7520-015-1399	7520-015-1394	7520-015-1398
M	7520-015-1007	7520-015-1395	7520-015-1395	7520-015-1397
N	7520-015-1006	7520-015-1397	7520-015-1395	7520-015-1396
O	7520-015-1005	7520-015-1395	7520-015-1395	7520-015-1396
P	7520-015-1004	7520-015-1396	7520-015-1395	7520-015-1394
Q	7520-015-1003	7520-015-1394	7520-015-1395	7520-015-1393
R	7520-015-1002	7520-015-1393	7520-015-1390	7520-015-1392
S	7520-015-1001	7520-015-1392	7520-015-1390	7520-015-1391
T	7520-015-1000	7520-015-1390	7520-015-1391	7520-015-1390
U	7520-015-1008	7520-015-1391	7520-015-1392	7520-015-1395
V	7520-015-1008	7520-015-1390	7520-015-1393	7520-015-1399
W	7520-015-1009	7520-015-1398	7520-015-1399	7520-015-1399
X	7520-015-1007	7520-015-1400	7520-015-1398	7520-015-1399
Y	7520-015-1008	7520-015-1400	7520-015-1395	7520-015-1397
Z	7520-015-1003	7520-015-1404	7520-015-1399	7520-015-1399
0	7520-040-0400	7520-040-0400	7520-040-0400	7520-040-0400
1	7520-040-0407	7520-040-0405	7520-040-0440	7520-040-0430
2	7520-040-0407	7520-040-0431	7520-040-0441	7520-040-0411
3	7520-040-0402	7520-040-0402	7520-040-0442	7520-040-0432
4	7520-040-0403	7520-040-0403	7520-040-0443	7520-040-0413
5	7520-040-0404	7520-040-0404	7520-040-0444	7520-040-0414
6	7520-040-0405	7520-040-0405	7520-040-0445	7520-040-0415
7	7520-040-0406	7520-040-0406	7520-040-0446	7520-040-0416
8	7520-040-0407	7520-040-0407	7520-040-0447	7520-040-0417
9	7520-040-0408	7520-040-0408	7520-040-0448	7520-040-0418



## SOMETHING



Here's something new for you wheeled vehicle drivers—whether you're amateur jockeys or occasional riders.

In this issue and each number down: Compound, cooling system maintenance and maintenance. ORDER CODE: PD #111, type B, annual 11, line yellow-PD# 97964668-911.

This stuff is going to be used in your cooling system to help prevent any seepage of the coolant into the crankcase and combustion chamber. It's also a dandy for sealing up any small holes you may have in your radiator. It'll do all this without having your coolant any, so it's completely safe, although when you dump one of these pellets in, the coolant will get a little bit discolored.

Now, the number of pellets you'll put in your cooling system'll depend on how much coolant that truck's supposed to hold. You'll use one pellet for every 8 quarts of coolant and one pellet for every liter (or 1.1 liter) of 1.1 liter coolant. So, let's say your truck holds 22 quarts of coolant. You can use pellets for every 8 quarts of coolant—that'll be two pellets right off the bat. Then, you can use one more pellet to make up the fraction—a total of three pellets.

OK, here's how you go about getting your cooling system ready for this stuff and some other things you'll need to know—



1. Make sure the coolant is your truck's right type first.



2. For the radiator cap head on, shut your engine off so it can cool a couple normal operating temperatures.

## NEW FOR YOU



3. Check your facts and how many spots the cooling system holds. Then, figure out how many pellets to use—remember the 8-quart rule (plus 1.1 liter), you know, and drop it in the pellet.

4. Put the radiator cap back on and let the engine get to normal 110 degrees—at least—to allow the pellets to dissolve into it with your radiator's old coolant through the cooling system.



5. After you're finished, you'll find a label in the cooling system pellet case. Put this on the upper part of the radiator, near the filler neck. This label tells anyone who's going to use the vehicle that the pellets are already in.



6. By adding the pellets, you should be able to stop any and every leak and even the old leaking the radiator off and patching, testing and replacing it.



7. If you later find that your cooling system is leaking badly, like having had some leak, get it done by your shop and get the leak fixed there. But never—what are more pellets, at least a leak like that fixed.



8. You'll need to use the right number of pellets to your cooling system every time you drive and with the cooling system will leak coolant—either some or sometimes. Also, we mean the old label that the radiator and get us a new label every time you add new pellets. Be sure to get your copy of PD 111 111 111 111.

# DON'T GAMBLE WITH YOUR CD-850 TRANSMISSION BRAKES



A wheelie, hey—that's what the brakes of your CD-850 transmission *should* make you, if they're adjusted right.

Your right and the direct inside the transmission—the ones that give you the braking power when you make a pass at the patch—constantly rub together like a pair of thumb files. Every time you roll yourself under eyes and feel yourself without brakes.

So, why not make your patch? Keep those brakes adjusted right and you'll roll without. Chanking on both sides of the transmission, "adjusted right" goes like this—

## SHARE ADJUSTMENT

Take off both the transmission adjusting screws from the top of the ball.



Take out the brake regulator link plug on the transmission that we want to be the correct.



See that multi-angle window on each side of the top of the transmission housing? With the brakes off, you'll see marks of the letter "A" (this mark is inherent to the vehicle) lined up with a third mark on the edge of the window. Apply the brakes, and the mark at the lower "A" (mark) is applied line-up with the double line.



If you see the "A" above the double line, the brakes are too tight and you're giving a locked gear with those brakes. If it's below the two, they're loose, and, either way, you'd better start adjusting before you brake again.



To get the adjusting screw that's on outside of the transmission, you'll have to take the top off the adjusting screw and loosen the lock nut. Now, to tighten the brake, turn the adjusting screw to say the screw on the facing side you.



Caution with those brake-adjustment screws. They're close enough to the low-range band adjusting screws to make for confusion. The brake-adjustment screws are located right next to the rear end cover and are smaller than the band-adjusting screws. When adjusting make sure you're turning the correct screws.

Reverse the screw on loosen, but here you've got to be mighty careful or you'll make your patch. When loosening the screw, the brake must be in the relaxed position. You apply and release the brake while adjusting to get the "A" line straight up. Never say an adjuster the adjusting screw while the brakes applied.

Whenever you do tighten or loosen—always make sure your final adjustment on the screw is no tighter is. This takes out internal friction and binds in, if you happen to tighten too much so if you want to loosen a tight bracket, back the adjusting screw off well beyond the correct point. Then, slowly tighten till you hit "or right on the nose.

When you're all relaxed, the "A" line should hit the double line when the brakes are off. When you push down hard on the patch, the "A" line should come up over within double line. Now all you have to do is tighten the lock nut, replace the top, and you're got a wheelie-ready bike.



But suppose this doesn't work out ... then you may have linkage trouble. To check this out, remove the linkage wires from both ends under the ball and remove the shock pin holding the linkage to the transmission brake-apply arms. Now


with both apply same way and in the forward return position the checked line should automatically fall on the "R" line.

If it doesn't, then go on further . . . call support because you've got trouble inside the transmission. If it does rest on the "R," then your next step is to check out your linkage.

## LINKAGE ADJUSTMENT

### STEP NO. THREE...

Inspect the brake linkage—rods, connectors, feet and shafts—pull that toward the foot pedal and the brake end to the transmission.



Strengthen any loose linkages and oil all your moveable parts. Also, look shafts or rods will throw the adjustment off. Be sure the operation bar is straight.

### TO THE END...

Before coming to the end of your ride to the true motor imagination rules, when you dismount of the brake apply you have the linkage and pull the linkage toward the rear of the foot till it brings opposite the stop. This breaks up the stick.



## 120 "NO TIGHT"



If you're working on the ball joint, make sure you won't feel any vibration you pull the linkage toward the rear. You'll have to use 1/2-in. diameter alignment pins in the tie rods. Put the pins in these places...

In the rear linkage assembly, near the intersection of the linkage shaft.

In the brake assembly, in the upper right of the brake pedal.

In those places in the frame, which you'll find near to the right cross shaft. Be sure the pins are in far enough so that part of each pin is in the hole in the beam, and the other part is in the hole in the lower mounting bracket.

## 130 "TIE UP"

Make sure the link in the apply-arm lines up with the link in the linkage shaft. Then pull or push or either the apply arm or the linkage to get 'em on line up—then give 'em hell in either dir.

If the link lines up, you're good to make... you put your pins in and make it last.

If they don't line up, adjust the pins on the linkage and they do—that's it.



The linkage should have no wobble as it is either flexed... it should be relaxed and not tight.

## 150 "NO BUMP" NO

Ball joint in the driver's compartment and joint of the pedal-shaft should be plenty of clearance between the lower's ball and the brake pedal. If not, remove the pin from the rod mounting forward to the brake pedal from the rear assembly.

Then, adjust the rod's pins till you reassemble the pin as it'll be positioned at the top end point of the long rod.

Always be sure it's at its top point—that is, as high as it can go with the brake released. That'll give you plenty of brake pedal clearance. Now that everything lines up, you can roll ahead with the brake adjustment again... this time it should check out.



Here's a Quick Guide to—

## BASE SEPARATION



If the rubber rim on your motor vehicle's track road wheel has been breaking away from the disk, that's base separation—and you'd better take a gander at this table. It has some new info you'll need to decide whether you can have the wheel fixed or whether you have to replace it.

DESCRIPTION	TYPE	BASE SEPARATION ON MOTOR
1. 200, 200, 200 assembly, 21 x 2 1/2	110-100-040	1
2. 200, 200, 200, 21 x 2 1/2	110-100-040	1
3. 200, 200, 200, 21 x 2 1/2	110-100-040	1/2
4. 200, 200, 200 assembly, 11 x 2	110-100-040	1
5. 200, 200, 200 assembly, 11 x 2	110-100-040	1 1/2
6. 200, 200 assembly, 11 x 2	110-100-040	1/2
7. 200, 200 assembly, 11 x 2	110-100-040	1/2
8. 200, 200 assembly, 11 x 2	110-100-040	1/2
9. 200, 200 assembly, 11 x 2 1/2	110-100-040	1/2
10. 200, 200, 11 x 2 1/2	110-100-040	1/2
11. 200, 200, 200 assembly, 11 x 2 1/2	110-100-040	1/2
12. 200, 200, 200 assembly, 21 x 2 1/2	110-100-040	1 1/2

One look at your Ch37 will tell you which of these disks belongs on your vehicle. The disk volume in the table tells you how much base separation you can have.

To measure this separation, take a straightedge and dip it between the roller and disk where they're separating. From the rim of the disk, measure in. If the measurement you get is more than the allowable amount given in the table, replace the road wheel, so it can be re-timed and put back into good condition. In other words, don't wait till the thing is so badly bent up that nothing can be done with it.



# BREAK 'EM IN, NOT UP



Remember those push, pull, and your tracks will carry you a lot further—



and come up looking unshredded when inspection time rolls around.



New tracks should be broken in by the numbers when you first put 'em on your tank—because when coming from storage, greasies are likely to be brittle.



Rubber loses its bounce when it's been stored for long.



But, with a proper break-in period, it'll give it back like a runner catching his second wind. Soon after you put the new tracks on, head for a smooth secondary road, or a paved one...

## AND WE'LL AVOID IT—



That should put the bounce back into 'em. Avoid driving faster than 20 MPH if the temperature is higher than 84° F. The greasies heat up to a point where they'll start cracking, churning, or falling out.

Driving on rough roads or rocky ground can push, and may squish 'em loose. Try to avoid it.

Exposing an unroad-or-hard-worked track, the tracks' outside edges will wear down faster than the inside. When this happens, track tracks from one side to the other to even up wear. It's good for the end connectors and corner guides, too.





# LITTLE JOE... A HOT POINT

Even "Old Lucifer" would envy Little Joe when he sits a tank across on a hot summer day. So, consider how Little Joe must feel—cooped up in that hot engine compartment, struggling away to keep up a supply of labor.

Joe's built so that with proper care he'll change like a rooster...even when you may think your owner plans' walking from the herd.

All around his nostrils are air channels and ducts. When he's working full tilt, cooling air goes whistling through and around him like a personalized breeze.

If you make use of his gears and belt cover, you're glad and won't feel a drop, but we will do it cooling job—believe.

These gears and cover, we designed to channel the air flow...if they're out of whack, the cooling system's reduced.



In a hot engine, adjust the belt drive to big cooling rate. In reality, he has to have the right DR at the right level. Especially in hot weather. It's a good idea to double-check these items right at level and weight clean and are hot oil that has your job.

A couple of other things to look to make sure the job's thing in job—keep the air clean clean.

tighten the air intake connections, clean the air filter.



and check for any oil leak on tank.



There are some other possible hot spots to look for. Make sure your vehicle's clean exchange and air filter are DR and not blowing hot air back into the engine compartment.



are if there are any loose electrical-connection connections that might be throwing an extra load on the generator.



understand your hot's spark plug isn't cracked, dry, or badly gapped.

TO GET THE MAXIMUM FROM YOUR TANK, SEE THE TAG.





More Than A mere Midget Motor (Water Around)

## Your 90-mm AA Gun

You can get a real busy some cleaning the 90-mm AA gun. But it sure won't be the kind you expect—see if you do the cleaning with solvent.

When you get to dipping around with the solvent, some of its fumes may get into the regulator or power control unit, which isn't too good a spot for the gas-actuating ring or piston heads.



If sparks ... and WHOO!—you may have an explosion. This can be confined in the regulator (since the window may blow out). 'Course' somebody is looking back over the regulator when she blows!



Don't use any oil and water when you're cleaning around the regulator, and power control unit.

## Handle With Care

Unless you know TM 9-401 like the back of your trigger finger, it'll pay to look it over now and again if you wanna keep your M54 Skywreaper in shape.



A GOOD LOT OF FIGHTING TIME FOR SPRE CANONS IS TRIPPING OVER THEM TO GET IT AND THEN MISSING THE CHANCE TO GET IT.



ON THE LEFT, EVERY OPERATOR SHOULD KNOW HOW TO USE THE SKYWREAPER. ON THE RIGHT, EVERY OPERATOR SHOULD KNOW HOW TO USE THE SKYWREAPER.



Now open your magnets and try if it get wet. If it did, you can rinse it out with alcohol, too. Then give it time to dry. Your magnets will be waterproof all right, but you can't run it with water in the motor assemblies.

Now, fill your fuel tank with a standard fuel and oil mixture and replace the spark plugs. Run the engine for five minutes.

You are now ready to run a pre-flight check and fly your target.

Remember, the key to the whole business is speed. The sooner you can drain, flush and dry your engine, the less maintenance you'll get.

The job is the same for fresh water, except that if your target fell into good clean water, you wouldn't have to drain and give it the alcohol treatment.

## SERVO GROUND LEAD

Normal ground for the H&H coil servo on the CG-1 180 SERVO is through the wing-to-fuselage attaching hole. However, sometimes corrosion or dirt prevents a good ground there, so there's no roll control in flight.



That's all there is to it. The lead assures you that your servos will have a good ground, and the dimensions makes servicing easy, and also prevents any possible damage if the wing comes off on landing.

## It's a Publication

## Formula

Learn the same "top" isn't "top" to the workings of the new initial distribution formula for publications.

File up one of the latest 30's, for example, and you'll notice the formula in the back no longer says how many of that 30 you're entitled to get automatically. The reason is that you get as many as you need for your unit at one stop the first time around . . . no more getting one or two copies of a new job and expediting for the rest.

This new deal was born way back . . . 2 Dec 1911, in fact. This is the date the Army set out an important letter: File #246647 (20) 207 231 Para 150 FOR SUBJECT: Distribution of Supply and Maintenance Publications.

This letter says that each technical service's installation property officer will see to it that your outfit gets automatic distribution of each 30, 31, 32, 33, 34, 35 and 36 that's put out for each class of equipment listed by you. Billed down, the letter gives your tank service the guarantee to get you each manual you need—in the quantity you need—so you can properly maintain and operate the equipment.

### IT WORKS LIKE THIS . . .

YOUR TECHNICAL SERVICE UNIT GETS ONE FOR EACH 30-36 PUBLICATION, THEN THE TECH SERVICE IS CONTACTED BY MAIL AND HOW MANY FOR EACH, ACCORDING TO THE EQUIPMENT LISTED IN YOUR REG LIST THAT YOU CURRENTLY HAVE. LET'S SEE WHAT'S GOING ON FOR THE 30'S IN GENERAL.

THE 30'S DON'T COME DOWN TO YOU AUTOMATICALLY. YOU HAVE TO FILE THEM AND EXPEDITE THEM USING THE PUBLICATION FORMULA.



THE UNIT THAT HAS A TRUCK UNIT, NEEDS A SET FROM IT AUTOMATICALLY FOR EACH CLASS OF EQUIPMENT LISTED IN YOUR REG LIST FOR WHICH YOU HAVE A NEED FOR EACH OF THE 30'S.

The system is planned to leave you more time for taking care of your own maintenance—and it aids down the paperwork by having each technical service expeditize all the publications it used the using unit mail—at one time.

With a tank service carrying the ball, you shouldn't have to worry about keeping up-to-date with jobs. But if you feel an urge to use all the latest manuals the Army's putting out, drop one of your publications and ask to see the distribution bulletin printed up by the Adjutant General publications center.

# CONTRIBUTIONS



## FAST BLOWER REMOVAL

Dear Editor,

Found a way to make things easier when removing the blower on the General Land Truck Amphibious Distributor, Model SOC. Change things around like this, and you won't have to remove the engine hood, control panel, and wiring when taking off the blower.



1. Remove the flexible tubing when it connects to the blower. If you can't pull it out, cut the tubing at the top connection. If you cut it, remove the nipple from the top and insert it in the flexible tubing.



2. Put a 2 1/2-in pipe nipple, (SAE 4700-12-714) (SAE) in the top.



3. Separate a 2 1/2-in pipe nipple, (SAE 4700-12-714) (SAE) and insert half of it on the top nipple and the other half on the tubing nipple. Connect the wires, and they will not be up.

With this setup, you just have to disconnect the wires or take off the blower. No removing the engine hood, control panel, and wiring.

Cpl L. C. L.



## INSPECTION NOTE

Dear Editor,

Both in the shop and on the shop, we found that we were having a lot of duplicated effort in inspecting the King-pin lock nuts on our 2000 P23 trailers and trailers that have been removed from Nike-A-Jet trailers.

Now my inspectors checking these King-pin shells or nuts a little more "King-pin informed and inspected—done" and his hands on the inspection lock cover.

So, the next man along knows just what and by whom it was done. We get the idea from the mouth of railroad freight cars.

Edward W. Hagan  
Fort Wingard, N. Y.



## CLEAN CAN CARRIER

Dear Editor,

Here at Fort Rucker our Combined Barracks public messes sit in a gravel parking lot. On windy days we found that the blowing dust would stick to our oil measures, and we get into our greasy oil.



So, we built this little wood crate and put the cans in it.

The doors take the crates and the oil cans down into the mess, and keep the measuring cans inside away from the dust, except when they are actually adding oil to their vehicles.

This has run down on the dust a whole lot, and cuts in keeping the oil can wiped clean before pouring makes use of the rest of it.

DRG Colbert W. Roberts  
Fort Rucker, Alabama

*(It's not hard if you're there on a regular basis, would it be the trick?)*

## RCAT ENGINE BENCH MOUNT



Dear Sirs,

Here's an engine mount we have in our RCAT repair tent.

As you can see, we cut a salvage propeller flange into the bench top, and then bolted a cross bar to the shaft of an unconvertible windshield.



Two slots of tubing fit the RCAT engine's mounting holes.



The windshield tops and fits down into the prop flange without any keys, of course.



The engine slips into the slot tubes.



The engine is at a handy height and spins around to let you get at any part.

Shag Grogg  
40th A.A.S. (Det. RCAT)  
Orange Flving Range, N. Y.

# Comic Rodd's BRIEFS



## Turn the collar

AFWD Ord G1-4119 IS New AF, which has to do with replacing the front tank like-tube collar bolts on most of your tracked vehicles, L-series support, it means that the old collar bolts let fuel leak out, causing a fire hazard. The fix: wire-tie the collar bolts, so there's no leakage. This AFWD is an Ordnance job, so why not give them a call and see if your leader is authorized.

## How you know

You know what to call for and who gives it to you when your M1A1-A3s enter all-terrain duty to use M.L.L. 4140A? The staff for you is Ordnance, strength, M.L.L. 4140A, Amendment 1, dated 1 Sept 1954. P28 91 20-24P-8120 is worth a 1 lb run. Your supporting depot can get it for you from the Air Force through a Military Inter-department Purchase Request—MIPR for short.

## They're getting to there

Don't do it! Several times you see your M5P armored infantry vehicles without its engine compartment doors parked in position. In the first place, you can get a total dose of carbon monoxide if a leak occurs in the exhaust system. And second, your power plant'll over-heat because the doors are part of the cooling system. Fix this in the back of your head and explain this that's handy. It could save your life.

## Number game

Don't get all shook up because your TB Ord numbers jump from 199 to 2000. You're not making any—not right now, anyway. Page 222 of SA Pamphlet 210-2 (November 1957) does you.

## They're urgent

You might guess the word that the AFWD needs for the M1A1-A3s. They're MWD 1062-1114, 1118, 1122 and 1123. Your support unit does the work.

## Right tools

You're right. There's no battery anti-hey mechanic to an M1A1-A3's. Organizational maintenance is done by a guy called a heavy metal mechanic. He has a 147 MWD and his job is listed in Changes, File AR 671.201.



**HOLD IT,  
THERE MAY BE  
LOTS OF LIFE  
IN ME YET!**



**A Dirty-looking oil  
can LOOK DIRTY  
right? But don't  
let them fool you. I  
GOT OFF SERVICE!**



**When that heavy  
oil and tar deposit  
has covered an  
engine or your  
drift down!**

**DIRTY-LOOKING OIL IS NOT ALWAYS BUNI OIL.**

